


Temperature Controller E5C2

DIN-sized (48 x 48 mm) Temperature Controller with Analog Setting

- Compact, low-cost Temperature Controller.
- Incorporates proportional control and reset adjustment function.
- Consecutive mounting possible using mounting adapter.
- Incorporates a plug-in socket, thus allows to DIN-track and flush mounting.



Model Number Structure

Model Number Legend

E5C2- □ □ □ □
1 2 3 4 5

- | | |
|--|--|
| <p>1. Model name</p> <p>2. Control output R: Relay Q: Voltage</p> <p>3. Control method 20: ON-OFF control 40: P control</p> | <p>4. Input type K: K-type thermocouple J: J-type thermocouple P: Platinum resistance thermometer (Jpt100) G: Thermistor (THE)</p> <p>5. Special type Blank: Standard type D, DIN: Special types</p> |
|--|--|

Ordering Information

Temperature Controllers

| Setting method | Indication method | Control mode | Output | Model | | | |
|----------------|-------------------|--------------|--------|------------------------------|-------------------------------|---------------------------------------|----------------|
| | | | | Thermocouple | | Platinum resistance thermometer Pt100 | Thermistor THE |
| | | | | K (CA) Chromel vs. alumel | J (IC) Iron vs. constantan | | |
| Analog setting | No indication | ON/OFF | Relay | E5C2-R20K | E5C2-R20J | E5C2-R20P-D | E5C2-R20G |
| | | P | Relay | E5C2-R40K | E5C2-R40J | E5C2-R40P-D | --- |

Note: When placing an order, specify the standard temperature range and supply voltage in addition to the model number.
(e.g., E5C2-R20K 0°C to 200°C 100/110 VAC)

Accessories (Order Separately)

| Name | Model |
|--|-----------|
| Front Connecting Socket | P2CF-08 |
| Back Connecting Socket (for flush mounting) | P3G-08 |
| Front Connecting Socket with Finger Protection | P2CF-08-E |
| Protective Cover (for finger protection) | Y92A-48G |

Specifications

■ Ratings

| | |
|-------------------------|--|
| Supply voltage | 100/110/120 VAC (common), 200/220/240 VAC (common) (See note.) 50/60 Hz (common) |
| Operating voltage range | 90% to 110% of rated supply voltage |
| Power consumption | Approx. 2 VA |
| Input | Thermocouple (with sensor burnout detection circuit), platinum resistance thermometer, or thermistor |
| Control mode | ON/OFF or P control |
| Setting method | Analog setting |
| Indication method | No indication |
| Control output | Relay output: SPDT, 3 A at 250 VAC, resistive load (switching capacity: 330 VA) |

Note: Specify either 100/110/120 VAC or 200/220/240 VAC when ordering.

■ Input Ranges

| Input | | Thermocouple | | Platinum resistance thermometer | Thermistor (see note 2) |
|-------|----|--|--|---|--|
| | | K (CA) Chromel vs. alumel | J (IC) Iron vs. constantan | Pt100 | THE |
| Range | °C | 0 to 200 (5), 0 to 300 (10), 0 to 400 (10), 0 to 600 (20), 0 to 800 (20), 0 to 1,000 (25), 0 to 1,200 (25) | 0 to 200 (5), 0 to 300 (10), 0 to 400 (10) | -50 to 50 (2), -20 to 80 (2), 0 to 50 (1), 0 to 100 (2), 0 to 200 (5), 0 to 300 (10), 0 to 400 (10) | -50 to 50 (2) (6 kΩ at 0°C), 0 to 100 (2) (6 kΩ at 0°C), 50 to 150 (2) (30 kΩ at 0°C), 100 to 200 (2) (550 Ω at 200°C), 150 to 300 (2) (4 kΩ at 200°C) |
| | °F | 32 to 392 (10), 32 to 572 (20), 32 to 752 (20), 32 to 1,112 (40), 32 to 1,472 (50), 32 to 1,832 (50), 32 to 2,192 (50) | 32 to 392 (10), 32 to 572 (20), 32 to 752 (20) | 32 to 212 (5), 32 to 392 (10) | --- |

Note: 1. Values in () are the minimum unit.

2. Values in () are the thermistor resistive value.


■ Characteristics

| | |
|--------------------------|--|
| Setting accuracy | ±2% FS max. |
| Hysteresis | Approx. 0.5% FS (fixed) |
| Proportional band | 3% FS (fixed) |
| Control period | Approx. 20 s |
| Reset range (see note 1) | 5 ±1% FS min. |
| Insulation resistance | 20 MΩ min. (at 500 VDC) |
| Dielectric strength | 2,000 VAC, 50/60 Hz for 1 min between charged terminals and uncharged metallic parts |
| Vibration resistance | Malfunction: 10 to 55 Hz, 0.15-mm single amplitude for 10 min each in X, Y, and Z directions Destruction: 16.7 Hz, 2-mm double amplitude for 2 hrs each in X, Y, and Z directions |
| Shock resistance | Malfunction: 147 m/s ² , 3 times each in 6 directions Destruction: 294 m/s ² , 3 times each in 6 directions |
| Life expectancy | Electrical: 100,000 operations min. (3 A at 110 VAC, resistive load) |
| Ambient temperature | Operating: -10°C to 55°C (with no icing or condensation) |
| Ambient humidity | Operating: 45% to 85% |
| Degree of protection | Front panel: IEC standard IP40 (see note 2) Terminals: IEC standard IP00 |
| Weight | Approx. 200 g (with flush-mounting adapter) |

Note: 1. No reset function is incorporated by any E5C2 model with ON/OFF control.

2. The model number of the special watertight cover conforming to IP66, NEMA4 is Y92A-48B.

Nomenclature




Operation Indicator


| Indicator | | Output |
|-----------|---------|--------|
| Red | Lit | ON |
| | Not lit | OFF |

Dimensions


Note: All units are in millimeters unless otherwise indicated.




Dimensions with Flush-mounting Adapter (Accessory), and Back Connecting Socket (Sold Separately)



Panel Cutout



Side-by-side Mounting of N Controllers





| N | 2 | 3 | 4 | 5 | 6 |
|---|-------------|--------------|--------------|--------------|--------------|
| L | 93^{+1}_0 | 141^{+1}_0 | 189^{+1}_0 | 237^{+1}_0 | 285^{+1}_0 |


Note: 1. Recommended panel thickness is 1 to 4 mm.
2. Close side-by-side mounting is possible (in a single direction).

Accessories (Order Separately)


P2CF-08 Front Connecting Socket



Terminal Arrangement/ Internal Connections (Top View)





Mounting Holes




Note: Can also be mounted to a DIN track.

Note: A finger-protection model (P2CF-08-E) is also available.

P3G-08 Back Connecting Socket (for Flush Mounting)



Terminal Arrangement/ Internal Connections (Bottom View)



Note: A Protective Cover for finger protection (Y92A-48G) is also available.

Protective Cover Y92A-48

The protective cover protects the front panel, particularly the setting section, against dust, dirt, and water drip. It also prevents the set values from being altered due to accidental contact with the setting keys.


| | |
|------------|----------|
| Appearance | |
| Model | Y92A-48B |

Installation

Connections

Input

Connect a thermocouple, the E52-THE□ Thermistor or platinum resistance thermometer to the E5C2 as shown in the following illustration.



Output

If the load circuit is a heating control system, be sure to connect the load to terminals 4 and 5. If the load circuit is a cooling control system, be sure to connect the load to terminals 4 and 6. If the heating control system is connected to terminals 4 and 5, the temperature of the heating control system or cooling control system will be abnormal and a serious accident may result.

If the E5C2 is in frequent operation, such as proportional operation, add an appropriate external relay to the E5C2 by considering the capacity of the load and the life of the relay.

Power Supply

If a single power supply is used for the E5C2 and the load, the supply voltage of the power supply may vary greatly when the load is open or closed if the capacity of the power supply is not large enough. Make sure that the capacity of the power supply is large enough so that the supply voltage range will be always from 90% to 110% of the rated supply voltage.


The E5C2 operates at either 50 or 60 Hz.

Precautions

Mounting


Track Mounting (E5C2 with P2CF-08)

When mounting two or more E5C2 models with track-mounting sockets, leave a space of approximately 20 mm on both sides of the sockets where hooks are located.




Flush Mounting

Insert E5C2 into the square hole of the panel and insert an adapter from the back so that there will be no space between E5C2 and the panel. Then, secure the E5C2 with a screw.




The P3G-08 can be wired in the same way as the P2CF-08.



Dismounting

If flush mounted, loosen the screw of the adapter and disengage the hooks for dismounting.



Temperature Setting

Do not turn the temperature setting knob of the E5C2 with excessive force, otherwise the stopper of the knob may break.

Others

Do not remove the housing of the E5C2, otherwise the housing may break.

To clean the surface of the E5C2, use a soft cloth wet with neutral detergent or alcohol. Do not use any organic solvent, such as paint thinner or benzine, strong acid or strong alkali to clean the surface of the E5C2, otherwise the surface of the E5C2 will become damaged.

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.