

FR-E 500

Frequency Inverter

Instruction Manual

FR-E 520 EC

FR-E 540 EC

Thank you for choosing the Mitsubishi Transistorized inverter.

This instruction manual gives handling information and precautions for use of this equipment.

Incorrect handling might cause an unexpected fault. Before using the inverter, please read this manual carefully to use the equipment to its optimum.

Please forward this manual to the end user.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through this instruction manual and appended documents carefully and can use the equipment correctly.

Do not use the inverter until you have a full knowledge of the equipment, safety information and instructions.

In this manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the CAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

SAFETY INSTRUCTIONS

1. Electric Shock Prevention

 **WARNING**

- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover removed. Otherwise, you may access the exposed high-voltage terminals or the charging part of the circuitry and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for residual voltage with a meter (refer to chapter 2 for further details) etc.
- Earth the Inverter.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.
- Operate the switches and potentiometers with dry hands to prevent an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise, you may get an electric shock.
- Do not change the cooling fan while power is on.
It is dangerous to change the cooling fan while power is on.

2. Fire Prevention

 **CAUTION**

- Mount the inverter and brake resistor on an incombustible surface. Installing the inverter directly on or near a combustible surface could lead to a fire.
- If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire.
- When a brake resistor is used, use an alarm signal to switch power off. Otherwise, the brake resistor will overheat abnormally due a brake transistor or other fault, resulting in a fire.
- Do not connect a resistor directly to the DC terminals +, -. This could cause a fire.

3. Injury Prevention

 **CAUTION**

- Apply only the voltage specified in the instruction manual to each terminal to prevent damage etc.
- Ensure that the cables are connected to the correct terminals. Otherwise, damage etc. may occur.
- Always make sure that polarity is correct to prevent damage etc.
- While power is on and for some time after power-off, do not touch the inverter or brake resistor as they are hot and you may get burnt.

4. Additional instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and installation

 **CAUTION**

- When carrying products, use correct lifting gear to prevent injury.
- Do not stack the inverter boxes higher than the number recommended.
- Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the Instruction Manual.
- Do not operate if the inverter is damaged or has parts missing.
- Do not hold the inverter by the front cover or operation panel; it may fall off.
- Do not stand or rest heavy objects on the inverter.
- Check the inverter mounting orientation is correct.
- Prevent screws, wire fragments or other conductive bodies or oil or other flammable substance from entering the inverter.
- Do not drop the inverter, or subject it to impact.
- Use the inverter under the following environmental conditions:

| | | |
|-------------|---------------------|---|
| Environment | Ambient temperature | Constant torque : -10°C to +50°C (non-freezing) |
| | Ambient humidity | 90%RH or less (non-condensing) |
| | Storage temperature | -20°C to +65°C * |
| | Ambience | Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt) |
| | Altitude, vibration | Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (91%). 5.9m/s ² or less (conforming to JIS C 0911) |

*Temperatures applicable for a short time, e.g. in transit.

(2) Wiring

CAUTION

- Do not fit capacitive equipment such as power factor correction capacitor, radio noise filter or surge suppressor to the output of the inverter.
- The connection orientation of the output cables U, V, W to the motor will affect the direction of rotation of the motor.

(3) Trial run

CAUTION

- Check all parameters, and ensure that the machine will not be damaged by a sudden start-up.

(4) Operation

WARNING

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after an alarm stop.
- The [STOP] key is valid only when the appropriate function setting has been made. Prepare an emergency stop switch separately.
- Make sure that the start signal is off before resetting the inverter alarm. A failure to do so may restart the motor suddenly.
- The load used should be a three-phase induction motor only. Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.

 **CAUTION**

- The electronic overcurrent protection does not guarantee protection of the motor from overheating.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter.
- Use a noise filter to reduce the effect of electromagnetic interference. Otherwise nearby electronic equipment may be affected.
- Take measures to suppress harmonics. Otherwise power harmonics from the inverter may heat/damage the power capacitor and generator.
- When a 400V class motor is inverter-driven, it should be insulation-enhanced or surge voltages suppressed. Surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all clear is performed, each parameter returns to the factory setting. Re-set the required parameters before starting operation.
- The inverter can be easily set for high-speed operation. Before changing its setting, fully examine the performances of the motor and machine.
- In addition to the inverter's holding function, install a holding device to ensure safety.
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.

(5) Emergency stop

 **CAUTION**

- Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.

(6) Maintenance, inspection and parts replacement

 **CAUTION**

- Do not carry out a megger (insulation resistance) test on the control circuit of the inverter.

(7) Disposing of the inverter

 **CAUTION**

- Treat as industrial waste.

(8) General instructions

Many of the diagrams and drawings in this instruction manual show the inverter without a cover, or partially open. Never operate the inverter like this. Always replace the cover and follow this instruction manual when operating the inverter.

CONTENTS

| | |
|------------------|----------|
| 1 OUTLINE | 1 |
|------------------|----------|

| | |
|--|----|
| 1.1 Pre-Operation Information | 1 |
| 1.1.1 Precautions for operation | 1 |
| 1.2 Basic Configuration | 3 |
| 1.2.1 Basic configuration | 3 |
| 1.3 Structure | 4 |
| 1.3.1 Appearance and structure | 4 |
| 1.3.2 Removal and reinstallation of the front cover | 5 |
| 1.3.3 Removal and reinstallation of the wiring cover | 6 |
| 1.3.4 Removal and reinstallation of the accessory cover | 7 |
| 1.3.5 Reinstallation and removal of the control panel..... | 8 |
| 1.3.6 Removal of the operation panel (FR-PA02-02) front cover..... | 10 |
| 1.3.7 Exploded view | 10 |

| | |
|----------------------------------|-----------|
| 2 INSTALLATION AND WIRING | 11 |
|----------------------------------|-----------|

| | |
|---|----|
| 2.1 Installation..... | 11 |
| 2.1.1 Instructions for installation..... | 11 |
| 2.2 Wiring..... | 13 |
| 2.2.1 Terminal connection diagram (when source logic is selected) | 13 |
| 2.2.2 Wiring of the Main Circuit | 17 |
| 2.2.3 Wiring of the control circuit..... | 22 |
| 2.2.4 Connection to the PU connector | 26 |
| 2.2.5 Connection of stand-alone option units | 29 |
| 2.2.6 Design information | 31 |
| 2.3 Other Wiring..... | 32 |
| 2.3.1 Power supply harmonics | 32 |
| 2.3.2 Inverter-generated noise and reduction techniques | 33 |
| 2.3.3 Leakage currents and countermeasures | 37 |
| 2.3.4 Inverter-driven 400V class motor..... | 38 |
| 2.3.5 Peripheral devices | 39 |
| 2.3.6 Instructions for compliance with U.S. and Canadian Electrical Codes | 43 |
| 2.3.7 Instructions for compliance with the European standards..... | 44 |

| | |
|----------------------------|-----------|
| 3 OPERATION/CONTROL | 46 |
|----------------------------|-----------|

| | |
|---|----|
| 3.1 Pre-Operation Information | 46 |
| 3.1.1 Types of operation modes | 46 |
| 3.1.2 Power on | 48 |
| 3.2 About the Control Panel..... | 49 |
| 3.2.1 Names and functions of the control panel (FR-PA02-02) | 49 |
| 3.2.2 Control panel mode is changed by pressing the MODE key | 50 |
| 3.2.3 Monitoring..... | 50 |
| 3.2.4 Frequency setting..... | 51 |
| 3.2.5 Parameter setting method | 51 |
| 3.2.6 Operation mode..... | 53 |
| 3.2.7 Help mode | 53 |
| 3.3 Operation | 55 |
| 3.3.1 Pre-operation checks | 55 |
| 3.3.2 External operation mode (Operation using the external frequency setting potentiometer and external start signal) | 56 |
| 3.3.3 PU operation mode (Operation using the control panel) | 57 |
| 3.3.4 Combined operation mode 1 (Operation using both external start signal and control panel)..... | 58 |
| 3.3.5 Combined operation mode 2..... | 59 |

| | |
|---------------------|-----------|
| 4 PARAMETERS | 60 |
|---------------------|-----------|

| | |
|---|----|
| 4.1 Parameter List..... | 60 |
| 4.1.1 Parameter list | 60 |
| 4.1.2 List of Parameters Classified by Purpose of Use | 66 |
| 4.1.3 Parameters recommended to be set by the user | 68 |
| 4.2 Parameter Function Details | 69 |
| 4.2.1 Torque boost (Pr. 0, Pr. 46)..... | 69 |
| 4.2.2 Output frequency range (Pr. 1, Pr. 2, Pr. 18)..... | 70 |
| 4.2.3 Base frequency, base frequency voltage (Pr. 3, Pr. 19, Pr. 47) | 71 |
| 4.2.4 Multi-speed operation (Pr. 4, Pr. 5, Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)..... | 72 |
| 4.2.5 Acceleration/deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45) | 73 |
| 4.2.6 Electronic overcurrent protection (Pr. 9, Pr. 48) | 75 |

| | |
|---|-----|
| 4.2.7 DC injection brake (Pr. 10 to Pr. 12)..... | 76 |
| 4.2.8 Starting frequency (Pr. 13) | 77 |
| 4.2.9 Load pattern selection (Pr. 14) | 78 |
| 4.2.10 Jog operation (Pr. 15, Pr. 16) | 79 |
| 4.2.11 Stall prevention (Pr. 22, Pr. 23, Pr. 66)..... | 80 |
| 4.2.12 Acceleration/deceleration pattern (Pr. 29)..... | 82 |
| 4.2.13 Regenerative brake duty (Pr. 30, Pr. 70)..... | 83 |
| 4.2.14 Frequency jump (Pr. 31 to Pr. 36) | 84 |
| 4.2.15 Speed display (Pr. 37)..... | 85 |
| 4.2.16 Frequency at 5V (10V) input (Pr. 38)..... | 86 |
| 4.2.17 Frequency at 20mA input (Pr. 39) | 86 |
| 4.2.18 Up-to-frequency sensitivity (Pr. 41) | 87 |
| 4.2.19 Output frequency detection (Pr. 42, Pr. 43)..... | 88 |
| 4.2.20 Monitor display (Pr. 52, Pr. 158)..... | 89 |
| 4.2.21 Monitoring reference (Pr. 55, Pr. 56)..... | 91 |
| 4.2.22 Automatic restart after instantaneous power failure (Pr. 57, Pr. 58)..... | 92 |
| 4.2.23 Remote setting function selection (Pr. 59)..... | 93 |
| 4.2.24 Shortest acceleration/deceleration mode (Pr. 60 to Pr. 63)..... | 95 |
| 4.2.25 Retry function (Pr. 65, Pr. 67 to Pr. 69) | 96 |
| 4.2.26 Applied motor (Pr. 71) | 98 |
| 4.2.27 PWM carrier frequency (Pr. 72, Pr. 240) | 99 |
| 4.2.28 Voltage input (Pr. 73) | 100 |
| 4.2.29 Input filter time constant (Pr. 74) | 101 |
| 4.2.30 Reset selection/disconnected PU detection/PU stop selection (Pr. 75) | 101 |
| 4.2.31 Parameter write inhibit selection (Pr. 77)..... | 103 |
| 4.2.32 Reverse rotation prevention selection (Pr. 78) | 104 |
| 4.2.33 Operation mode selection (Pr. 79) | 105 |
| 4.2.34 General-purpose magnetic flux vector control selection (Pr. 80)..... | 109 |
| 4.2.35 Offline auto tuning function (Pr. 82 to Pr. 84, Pr. 90, Pr. 96)..... | 110 |
| 4.2.36 Computer link operation (Pr. 117 to Pr. 124, Pr. 342) | 116 |
| 4.2.37 PID control (Pr. 128 to Pr. 134) | 128 |
| 4.2.38 Output current detection function (Pr. 150, Pr. 151)..... | 136 |
| 4.2.39 Zero current detection (Pr. 152, Pr. 153)..... | 137 |
| 4.2.40 Stall prevention function and current limit function (Pr. 156) | 138 |
| 4.2.41 User group selection (Pr. 160, Pr. 173 to Pr. 176) | 140 |

| | |
|---|-----|
| 4.2.42 Actual operation hour meter clear (Pr. 171) | 142 |
| 4.2.43 Input terminal function selection (Pr. 180 to Pr. 183) | 142 |
| 4.2.44 Output terminal function selection (Pr. 190 to Pr. 192)..... | 144 |
| 4.2.45 Cooling fan operation selection (Pr. 244) | 145 |
| 4.2.46 Slip compensation (Pr. 245 to Pr. 247) | 146 |
| 4.2.47 Stop selection (Pr. 250) | 147 |
| 4.2.48 Output phase failure protection selection (Pr. 251) | 148 |
| 4.2.49 Meter (frequency meter) calibration (Pr. 901)..... | 149 |
| 4.2.50 Biases and gains of the frequency setting voltage (current) (Pr. 902 to Pr. 905)..... | 151 |

| | |
|-------------------------------|------------|
| 5 PROTECTIVE FUNCTIONS | 157 |
|-------------------------------|------------|

| | |
|--|-----|
| 5.1 Errors (Alarms)..... | 157 |
| 5.1.1 Error (alarm) definitions | 157 |
| 5.1.2 To know the operating status at the occurrence of alarm..... | 165 |
| 5.1.3 Correspondence between digital and actual characters..... | 165 |
| 5.1.4 Resetting the inverter | 165 |
| 5.2 Troubleshooting | 166 |
| 5.2.1 Motor remains stopped..... | 166 |
| 5.2.2 Motor rotates in opposite direction | 166 |
| 5.2.3 Speed greatly differs from the setting..... | 167 |
| 5.2.4 Acceleration/deceleration is not smooth..... | 167 |
| 5.2.5 Motor current is large..... | 167 |
| 5.2.6 Speed does not increase..... | 167 |
| 5.2.7 Speed varies during operation..... | 167 |
| 5.2.8 Operation mode is not changed properly | 168 |
| 5.2.9 Control panel display is not operating | 168 |
| 5.2.10 POWER lamp is not lit..... | 168 |
| 5.2.11 Parameter write cannot be performed | 168 |
| 5.3 Precautions for Maintenance and Inspection..... | 169 |
| 5.3.1 Precautions for maintenance and inspection | 169 |
| 5.3.2 Check items..... | 169 |
| 5.3.3 Periodic inspection | 169 |
| 5.3.4 Insulation resistance test using megger | 170 |
| 5.3.5 Pressure test | 170 |

5.3.6 Daily and Periodic Inspection 171
5.3.7 Replacement of parts 174
5.3.8 Measurement of main circuit voltages, currents and powers..... 178

6 SPECIFICATIONS 180

6.1 Standard Specifications 180
6.1.1 Model specifications 180
6.1.2 Common specifications 182
6.1.3 Outline drawings..... 184

APPENDIX 186

Appendix 1 Data Code List 186

CHAPTER 1

OUTLINE

This chapter gives information on the basic "outline" of this product.

Always read the instructions before using the equipment.

| | |
|-------------------------------------|---|
| 1.1 Pre-Operation Information | 1 |
| 1.2 Basic Configuration..... | 3 |
| 1.3 Structure | 4 |

<Abbreviations>

- PU
Control panel and parameter unit (FR-PU04)
- Inverter
Mitsubishi transistorized inverter FR-E500 series
- Pr.
Parameter number

Chapter 1

Chapter 2

Chapter 3

Chapter 4

Chapter 5

Chapter 6

1.1.1 Precautions for operation

This manual is written for the FR-E500 series transistorized inverters.


Incorrect handling may cause the inverter to operate incorrectly, causing its life to be reduced considerably, or at the worst, the inverter to be damaged. Handle the inverter properly in accordance with the information in each section as well as the precautions and instructions of this manual to use it correctly.

For handling information on the parameter unit (FR-PU04), stand-alone options, etc., refer to the corresponding manuals.

(1) Unpacking and product check

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.

1) Inverter type



● Inverter type

FR - E540 - 0.4 K - EC

| Symbol | Voltage Class |
|--------|----------------------------|
| E540 | Three-phase 400V class |
| E520S | Single-phase 200V class |

Represents the inverter capacity "kW".

2) Accessory

Instruction manual

If you have found any discrepancy, damage, etc., please contact your sales representative.

(2) Preparation of instruments and parts required for operation

Instruments and parts to be prepared depend on how the inverter is operated. Prepare equipment and parts as necessary. (Refer to page 46.)

(3) Installation

To operate the inverter with high performance for a long time, install the inverter in a proper place, in the correct direction, with proper clearances. (Refer to page 11.)


(4) Wiring

Connect the power supply, motor and operation signals (control signals) to the terminal block. Note that incorrect connection may damage the inverter and peripheral devices. (See page 13.)

1.2 Basic Configuration


1.2.1 Basic configuration

The following devices are required to operate the inverter. Proper peripheral devices must be selected and correct connections made to ensure proper operation. Incorrect system configuration and connections can cause the inverter to operate improperly, its life to be reduced considerably, and in the worst case, the inverter to be damaged. Please handle the inverter properly in accordance with the information in each section as well as the precautions and instructions of this manual. (For connections of the peripheral devices, refer to the corresponding manuals.)




1.3.1 Appearance and structure

(1) Front view



(2) Without front cover and accessory cover



1


*The PU connector is used for connection of the FR-PA02-02 or FR-PU04 option or to make RS-485 communication.

1.3.2 Removal and reinstallation of the front cover

● **Removal**

The front cover is fixed with catches in positions A, B and C.

Push A and B in the directions of arrows at the same time and remove the cover using C as supporting points.



● **Reinstallation**

When reinstalling the front cover after wiring, fix the catches securely.

With the front cover removed, do not switch power on.


Note: 1. Make sure that the front cover has been reinstalled securely.

2. The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Before reinstalling the front cover, check the serial numbers to ensure that the cover removed is reinstalled to the inverter from where it was removed.

1.3.3 Removal and reinstallation of the wiring cover

● Removal

Remove the wiring cover by pulling it in the direction of arrow A.




● Reinstallation

Pass the cables through the wiring hole and reinstall the cover in the original position.

1.3.4 Removal and reinstallation of the accessory cover


● **Removal**

Hold down the portion A indicated by the arrow and lift the right hand side using the portion B indicated by the arrow as a support, and pull out the accessory cover to the right.



● **Reinstallation**

Insert the mounting catch (left hand side) of the accessory cover into the mounting position of the inverter and push in the right hand side mounting catch to install the accessory cover.




1.3.5 Reinstallation and removal of the control panel

To ensure safety, reinstall and remove the optional control panel (FR-PA02-02) after switching power off.

The charging area and control printed board are exposed on the rear surface of the control panel. When removing the control panel, always fit the rear cover option FR-E5P. Never touch the control printed board because touching it can cause the inverter to fail.


● **Reinstallation**

Insert the mounting catch (left hand side) of the accessory cover into the mounting position of the inverter and push in the right hand side mounting catch to install the accessory cover.



● **Removal of the control panel**


Hold down the portion A indicated by the arrow and lift the right hand side using the portion B indicated by the arrow as a support, and pull out the accessory cover to the right.



(If the above procedure is not used for removal, the internal connector may be damaged by the force applied.)

- **Using the connection cable for operation**

- 1) Fit the rear cover option FR-E5P to the back surface of the control panel.
- 2) Securely plug one end of the connection cable into the PU connector of the inverter and the other end into the adaptor of the FR-E5P option to connect it to the control panel. (For the connection cable of the FR-E5P, refer to page 26.)




- **Mounting the control panel on an enclosure**


When you open the control panel front cover, the screw mounting guides for fixing the control panel to an enclosure appear on the top left and bottom right. Fit the rear cover of the FR-E5P option, drill holes in the control panel mounting guides, and securely mount the control panel on the enclosure with screws.

1.3.6 Removal of the operation panel (FR-PA02-02) front cover

- 1) Open the control panel front cover to 90 degrees.
- 2) Pull out the control panel front cover to the left to remove it.



1.3.7 Exploded view



1

CHAPTER 2

INSTALLATION AND WIRING

This chapter gives information on the basic "installation and wiring" for use of this product.

Always read the instructions in this chapter before using the equipment.

| | |
|------------------------|----|
| 2.1 Installation | 11 |
| 2.2 Wiring | 13 |
| 2.3 Other Wiring | 32 |

Chapter 1

Chapter 2

Chapter 3

Chapter 4

Chapter 5

Chapter 6

2.1 Installation

2.1.1 Instructions for installation

1) Handle the unit carefully.

The inverter uses plastic parts. Handle it gently to protect it from damage. Also, hold the unit with even strength and do not apply too much strength to the front cover alone.

2) Install the inverter in a place where it is not affected by vibration easily (5.9m/s^2 maximum).

Note the vibration of a cart, press, etc.

3) Note on ambient temperature.

The inverter life is under great influence of ambient temperature. In the place of installation, ambient temperature must be within the permissible range $-10\text{ }^{\circ}\text{C}$ to $+50\text{ }^{\circ}\text{C}$. Check that the ambient temperature is within that range in the positions shown in figure 3).

4) Install the inverter on a non-combustible surface.

The inverter will be very hot (maximum about $150\text{ }^{\circ}\text{C}$). Install it on a non-combustible surface (e.g. metal). Also leave sufficient clearances around the inverter.

5) Avoid high temperature and high humidity.

Avoid direct sunlight and places of high temperature and high humidity.

6) Avoid places where the inverter is exposed to oil mist, flammable gases, fluff, dust, dirt etc.


Install the inverter in a clean place or inside a "totally enclosed" panel which does not accept any suspended matter.

7) Note the cooling method when the inverter is installed in an enclosure.


When two or more inverters are installed or a ventilation fan is mounted in an enclosure, the inverters and ventilation fan must be installed in proper positions with extreme care taken to keep the ambient temperatures of the inverters within the permissible values. If they are installed in improper positions, the ambient temperatures of the inverters will rise and ventilation effect will be reduced.

8) Install the inverter securely in the vertical direction with screws or bolts.

3) Note on ambient temperatures





4) Clearances around the inverter




*5cm or more for 5.5K and 7.5K

These clearances are also necessary for changing the cooling fan.

7) For installation in an enclosure






(Correct example)



(Incorrect example)

When more than one inverter is contained


8) Vertical mounting



2.2 Wiring


2.2.1 Terminal connection diagram (when source logic is selected)

● 3-phase 400V power input



- Note: 1. If the potentiometer is to be operated often, use a 2W1kΩ potentiometer.
2. Terminals 5, SD and SE are isolated.
3. Terminals SD and 5 are common terminals. Do not earth them to the ground.
4. When terminals PC-SD are used as a 24VDC power supply, be careful not to short these terminals. If they are shorted, the inverter will be damaged.

● **Single-phase 200V power input**



Note: 1. To ensure safety, connect the power input to the inverter via a magnetic contactor and earth leakage circuit breaker or no-fuse breaker, and use the magnetic contactor to switch power on-off.
 2. The output is three-phase 200V.

(1) Description of the main circuit terminals

| Symbol | Terminal Name | Description |
|----------------------|--|---|
| L1, L2, L3 (Note) | AC power input | Connect to the commercial power supply. Keep these terminals unconnected when using the high power factor converter. |
| U, V, W | Inverter output | Connect a three-phase squirrel-cage motor. |
| +, PR | Brake resistor connection | Connect the optional brake resistor across terminals + - PR. |
| +, - | Brake unit connection | Connect the optional brake unit or high power factor converter. |
| +, P1 | Power factor improving DC reactor connection | Disconnect the jumper from terminals + - P1 and connect the optional power factor improving DC reactor. |
| | Earth (Ground) | For earthing the inverter chassis. Must be earthed. |

Note: L1, N terminals for single-phase power input.

(2) Description of the control circuit terminals

| Type | Symbol | Terminal Name | Description | | | | |
|---------------|---|---------------|--------------------------------|---|---|--|--|
| Input signals | Contacts, e.g. start (STF), stop (STOP) etc | STF | Forward rotation start | Turn on the STF signal to start forward rotation and turn it off to stop. | When the STF and STR signals are turned on simultaneously, the stop command is given. | | |
| | | STR | Reverse rotation start | Turn on the STR signal to start reverse rotation and turn it off to stop. | | | |
| | | RH, RM, RL | Multi-speed selection | Combine the RH, RM and RL signals as appropriate to select multiple speeds. | Input terminal function choices (Pr. 180 to Pr. 183) change terminal functions. | | |
| | | MRS | Output stop | Turn on the MRS signal (20ms or longer) to stop the inverter output. Used to shut off the inverter output to bring the motor to a stop by the electromagnetic brake. | | | |
| | | RES | Reset | Used to reset the protective circuit activated. Turn on the RES signal for more than 0.1 second then turn it off. | | | |
| | | | | SD | Contact input common and external transistor common (sink*) | When transistor output (open collector output), such as a programmable controller (PLC), is connected, connect the external power supply common for transistor output to this terminal to prevent a fault caused by undesirable current. Common to the contact input terminals. Common output terminal for 24VDC 0.1A power output (PC terminal). This terminal becomes common to the contact input terminals when sink logic is selected. Please see page 23 for the logic changing method. | |
| | | | | PC | Power output Contact input common (source*) | This terminal can be used as a 24VDC, 0.1A power output. This terminal becomes external transistor common when sink logic is selected. Please see page 23 for the logic changing method. | |
| Analog | Frequency setting | 10 | Frequency setting power supply | 5VDC, permissible load current 10mA | | | |
| | | 2 | Frequency setting (voltage) | By entering 0 to 5VDC (0 to 10VDC), the maximum output frequency is reached at 5V (or 10V) and I/O are proportional. Use Pr. 73 to switch between input 0 to 5VDC (factory setting) and 0 to 10VDC. Input resistance 10kΩ. Maximum permissible voltage 20V. | | | |
| | | 4 | Frequency setting (current) | By entering 4 to 20mADC, the maximum output frequency is reached at 20mA and I/O are proportional. This input signal is valid only when the AU signal (Note) is on. Input resistance 250Ω. Maximum permissible current 30mA. | | | |
| | | 5 | Frequency setting input common | Common terminal for the frequency setting signal (terminal 2, 1 or 4) and analog output terminal AM. Do not connect to the earth (ground). | | | |

Note: Assign the AU signal to any of the terminals using the input terminal function selection (Pr. 180 to Pr. 183).

* Used as a contact input signal common terminal by switching between sink logic and source logic. (Refer to page 23.)

| Type | Symbol | Terminal Name | Description | | |
|----------------|----------------|---------------|------------------------------|--|--|
| Output signals | Contact | A, B, C | Alarm output | Change-over contact output indicating that the output has been stopped by the inverter protective function activated. 230VAC 0.3A, 30VDC 0.3A. Alarm: discontinuity across B-C (continuity across A-C), normal: continuity across B-C (discontinuity across A-C). | Output terminal function choices (Pr. 190 to Pr. 192) change terminal functions. |
| | | RUN | Inverter running | Switched low when the inverter output frequency is equal to or higher than the starting frequency (factory set to 0.5Hz, variable). Switched high during stop or DC injection brake operation (*1). Permissible load 24VDC 0.1A. | |
| | Open collector | FU | Frequency detection | Switched low when the output frequency has reached or exceeded the detection frequency set as appropriate. Switched high when below the detection frequency (*1). Permissible load 24VDC 0.1A | |
| | | SE | Open collector output common | Common to the RUN and FU terminals. | |
| Communication | RS-485 | — | PU connector | One selected from output frequency, motor current and output voltage is output (*2). The output signal is proportional to the magnitude of each monitoring item. | Factory setting of output item: Frequency Permissible load current 1mA Output signal 0 to 10VDC |
| | | | | With the control panel connector, communication can be made using the RS-485 protocol. <ul style="list-style-type: none"> • Conforming Standard : EIA Standard RS-485 • Transmission format : Multi-drop link • Communication speed : Maximum 19200bps • Overall length : 500m | |

*1: Low indicates that the open collector output transistor is on (conducts). High indicates that the transistor is off (does not conduct).


*2: Not output during inverter resetting.

2.2.2 Wiring of the Main Circuit

(1) Wiring instructions

- 1) It is recommended to use insulation-sleeved solderless terminals for power supply and motor wiring.
- 2) Power must not be applied to the output terminals (U, V, W) of the inverter. Otherwise the inverter will be damaged.
- 3) After wiring, wire off-cuts must not be left in the inverter.
Wire off-cuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in a control box etc., be careful so that chips and others do not enter the inverter.
- 4) Use thick cables to make the voltage drop 2% or less.
If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease, especially at the output of a low frequency. (A selection example for the wiring length of 20m is shown on page 19.)
- 5) For long distance wiring, the overcurrent protection may be activated improperly or the devices connected to the output side may misoperate or become faulty under the influence of a charging current due to the stray capacitance of the wiring. Therefore, the maximum overall wiring length should be as indicated in the following table. If the wiring length exceeds the value, it is recommended to set "1" in Pr. 156 to make the fast-response current limit function invalid. (When two or more motors are connected to the inverter, the total wiring length should be within the indicated value.)

| Inverter Capacity | | 0.4K | 0.75K | 1.5K | 2.2K | 3.7K or more |
|-----------------------------|------------|------|-------|------|------|--------------|
| Non-low acoustic noise mode | 200V class | 300m | 500m | 500m | 500m | 500m |
| | 400V class | 200m | 200m | 300m | 500m | 500m |
| Low acoustic noise mode | 200V class | 200m | 300m | 500m | 500m | 500m |
| | 400V class | 30m | 100m | 200m | 300m | 500m |



6) Connect only the recommended optional brake resistor between the + - PR.

These terminals must not be shorted.

7) Electromagnetic wave interference

The input/output (main circuit) of the inverter includes harmonic components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional radio noise filter (for use in the input side only) or FR-BSF01 or FR-BLF line noise filter to minimize interference.

8) Do not install a power capacitor, surge suppressor or radio noise filter (FR-BIF option) in the output side of the inverter.

This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are installed, immediately remove them. (When using the FR-BIF radio noise filter with a single-phase power supply, connect it to the input side of the inverter after isolating the T phase securely.)

9) When rewiring after operation, make sure that the POWER lamp has gone off, and when more than 10 minutes has elapsed after power-off, check with a meter etc. that the voltage is zero. After that, start rewiring work. For some time after power-off, there is a dangerous voltage in the capacitor.

Notes on Earthing (Grounding)

- Leakage currents flow in the inverter. To prevent an electric shock, the inverter and motor must be earthed (grounded).
- Use the dedicated earth (ground) terminal to earth (ground) the inverter. (Do not use the screw in the case, chassis, etc.) For the earth connection avoid direct contact between aluminium and copper. Tin-plated cable lugs can be used if the plating does not contain zinc. When tightening the screws take care not to damage the thread in the aluminium frame.
- The earth (ground) cable should be as thick as possible. Use the cable whose gauge is equal to or larger than those indicated in the following table, and make its length as short as possible. The earthing (grounding) point should be as near as possible to the inverter to minimize the earth (ground) cable length.



(Unit: mm²)

| Motor Capacity | Earth Cable Gauge | |
|----------------|-------------------|------------|
| | 200V class | 400V class |
| 2.2kW or less | 2 (2.5) | 2 (2.5) |
| 3.7kW | — | 2 (4) |
| 5.5kW, 7.5kW | — | 3.5 (6) |

To meet the Low Voltage Directive, use PVC insulated cables larger than specified size in brackets ().

- Earth (Ground) the motor on the inverter side using one wire of the 4-core cable.

(2) Terminal block layout of the power circuit



(3) Cables, crimping terminals, etc.

The following table lists the cables and crimping terminals used with the inputs (L1, L2, L3) and outputs (U, V, W) of the inverter and the torques for tightening the screws:

1) FR-E540-0.4K to 7.5K-EC

| Applicable Inverter Type | Terminal Screw Size | Tightening Torque N·m | Crimping Terminals | | Cables | | | | PVC Insulated Cables | |
|--------------------------|---------------------|-----------------------|--------------------|---------|-----------------|---------|------------|---------|----------------------|---------|
| | | | | | mm ² | | AWG | | mm ² | |
| | | | L1, L2, L3 | U, V, W | L1, L2, L3 | U, V, W | L1, L2, L3 | U, V, W | L1, L2, L3 | U, V, W |
| FR-E540-0.4K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E540-0.75K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E540-1.5K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E540-2.2K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E540-3.7K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E540-5.5K-EC | M4 | 1.5 | 5.5-4 | 2-4 | 3.5 | 2 | 12 | 14 | 4 | 2.5 |
| FR-E540-7.5K-EC | M4 | 1.5 | 5.5-4 | 5.5-4 | 3.5 | 3.5 | 12 | 12 | 4 | 4 |


2) FR-E520S-0.4K to 2.2K-EC

| Applicable Inverter Type | Terminal Screw Size | Tightening Torque N·m | Crimping Terminals | | Cables | | | | PVC Insulated Cables | |
|--------------------------|---------------------|-----------------------|--------------------|---------|-----------------|---------|-------|---------|----------------------|---------|
| | | | | | mm ² | | AWG | | mm ² | |
| | | | L1, N | U, V, W | L1, N | U, V, W | L1, N | U, V, W | L1, N | U, V, W |
| FR-E520S-0.4K-EC | M4 | 1.5 | 2-3.5 | 2-3.5 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E520S-0.75K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E520S-1.5K-EC | M4 | 1.5 | 2-4 | 2-4 | 2 | 2 | 14 | 14 | 2.5 | 2.5 |
| FR-E520S-2.2K-EC | M4 | 1.5 | 5.5-4 | 2-4 | 3.5 | 2 | 12 | 14 | 4 | 2.5 |

Note: 1. The cables used should be 75°C copper cables.
 2. Tighten the terminal screws to the specified torques.
 Undertightening can cause a short or misoperation.
 Overtightening can cause the screws and unit to be damaged, resulting in a short or misoperation.

(4) Connection of the power supply and motor


● **Three-phase power input**



The power supply cables must be connected to L1, L2, L3. If they are connected to U, V, W, the inverter will be damaged.
(Phase sequence need not be matched.)

Connect the motor to U, V, W. In the above connection, turning on the forward rotation switch (signal) rotates the motor in the counterclockwise (arrow) direction when viewed from the load shaft.

● **Single-phase power input**



Note: 1. To ensure safety, connect the power input to the inverter via a magnetic contactor and earth leakage circuit breaker or no-fuse breaker, and use the magnetic contactor to switch power on-off.
2. The output is three-phase 200V.

2.2.3 Wiring of the control circuit

(1) Wiring instructions


- 1) Terminals PC, SE and 5 (and SD when sink logic is selected) are common to the I/O signals. These common terminals must not be earthed to the ground.
- 2) Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).
- 3) The frequency input signals to the control circuit are micro currents. When contacts are required, use two or more parallel micro signal contacts or a twin contact to prevent a contact fault.
- 4) It is recommended to use the cables of 0.3mm² to 0.75mm² gauge for connection to the control circuit terminals.
- 5) When bar terminals and solid wires are used for wiring, their diameters should be 0.9mm maximum. If they are larger, screw threads may be damaged during tightening.

(2) Terminal block layout

In the control circuit of the inverter, the terminals are arranged as shown below:


Terminal screw size: M2.5

Terminal layout of control circuit



(3) Wiring method

- 1) For wiring the control circuit, use cables after stripping their sheaths. Refer to the gauge printed on the inverter and strip the sheaths to the following dimensions. If the sheath is stripped too much, its cable may be shorted with the adjoining cable. If the sheath is stripped too little, the cable may come off.



- 2) When using bar terminals and solid wires for wiring, their diameters should be 0.9mm maximum. If they are larger, the threads may be damaged during tightening.
- 3) Loosen the terminal screw and insert the cable into the terminal.
- 4) Tighten the screw to the specified torque.

Undertightening can cause cable disconnection or misoperation. Overtightening can cause damage to the screw or unit, leading to short circuit or misoperation.

Tightening torque: 0.25 N·m to 0.49 N·m

* Use a size 0 screwdriver.

Note: When routing the stripped cables, twist them so that they do not become loose. In addition, do not solder them.


(4) Control logic changing

The input signal logic is factory-set to the source mode.

To change the control logic, the position of the connector beside the control circuit terminal block must be changed.

- 1) Use tweezers etc. to remove the connector in the source logic position and fit it in the sink logic position.

Do this position changing before switching power on.




- Note:
1. Make sure that the front cover has been installed securely.
 2. The front cover has a capacity plate and the inverter a rating plate on it. Since these plates have the same serial numbers, always reinstall the removed cover to the inverter from where it was removed.
 3. Always install the sink-source logic changing connector in either of the positions. If two connectors are installed in these positions at the same time, the inverter may be damaged.


2) Source logic type

- In this logic, a signal switches on when a current flows into the corresponding signal input terminal.

Terminal PC is common to the contact input signals. Terminal SE common to the open collector output signals.




- When using an external power supply for transistor output, use terminal SD as a common to prevent misoperation caused by undesirable current.




3) Sink logic type

- In this logic, a signal switches on when a current flows out of the corresponding signal input terminal.

Terminal SD is common to the contact input signals. Terminal SE common to the open collector output signals.




- When using an external power supply for transistor output, use terminal PC as a common to prevent misoperation caused by undesirable current.
 (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install the power supply in parallel outside the inverter. Doing so may cause misoperation due to undesirable current.)



(5) How to use the STOP signal

The following connection example shows how to self-hold the start signals (forward rotation, reverse rotation).

Use Pr. 180 to Pr. 183 (input terminal function selection) to assign the STOP signal.



2.2.4 Connection to the PU connector

(1) When connecting the control panel or parameter unit using a cable

Use the option FR-CB2□ or the following connector and commercially available cable:

<Connection cable>

- Connector : RJ45 connector
Example: 5-554720-3, Tyco Electronics Corporation
- Cable : Cable conforming to EIA568 (e.g. 10BASE-T cable)
Example: SGLPEV 0.5mm×4P (Twisted pair cable, 4 pairs), MITSUBISHI CABLE INDUSTRIES, LTD.

<When using the control panel>

Note: The rear cover and junction adaptor are required since the circuit board is exposed in the back of the control panel.

Use the FR-E5P option (cover and adaptor available as a set).


<Maximum wiring length>

- Control panel (FR-PA02-02): 20m
- Parameter unit (FR-PU04): 20m

(2) For RS-485 communication

The PU connector can be used for communication operation from a personal computer etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program allows the inverter to be run and monitored and the parameter values to be read and written.



- | | |
|--------|--------|
| 1) SG | 5) SDA |
| 2) P5S | 6) RDB |
| 3) RDA | 7) SG |
| 4) SDB | 8) P5S |

8) to 1)


<PU connector pin-outs>

Viewed from the inverter (receptacle side) front

- Note: 1. Do not connect the PU connector to a computer's LAN board, FAX modem socket or telephone modular connector. Otherwise, the product may be damaged due to electrical specification differences.
2. Pins 2) and 8) (P5S) provide power to the control panel or parameter unit. Do not use these pins for RS-485 communication.

<System configuration examples>

1) When a computer having a RS-485 interface is used with several inverters



Use the connectors and cables which are available on the market.


Note: 1. Connector: RJ45 connector

Example: 5-554720-3, Tyco Electronics Corporation

2. Cable : Cable conforming to EIA568 (such as 10BASE-T cable)

Example: SGLPEV 0.5mm × 4P (Twisted pair cable, 4 pairs),
Mitsubishi Cable Industries, Ltd.

2) When a computer having a RS-232C interface is used with inverters



*Commercially available converter is required. (Note 3)

Use the connectors, cables and converter which are available on the market.

Note: 1. Connector: RJ45 connector

Example: 5-554720-3, Tyco Electronics Corporation

2. Cable : Cable conforming to EIA568 (such as 10BASE-T cable)

Example: SGLPEV 0.5mm × 4P (Twisted pair cable, 4 pairs),
Mitsubishi Cable Industries, Ltd.

3.*Commercially available converter examples


Model: FA-T-RS40

Converter


Nagoya Sales Office, Mitsubishi Electric Engineering Co., Ltd.

<Wiring methods>

1) Wiring of one RS-485 computer and one inverter



2) Wiring of one RS-485 computer and "n" inverters (several inverters)



2

Note:1. Make connections in accordance with the instruction manual of the computer used.
Fully check the terminal numbers of the computer as they differ between models.

2. There may be the influence of reflection depending on the transmission speed and/or transmission distance. If this reflection hinders communication, provide a termination resistor. If the PU connector is used to make a connection, use the distributor as a termination resistor cannot be fitted.
Connect the termination resistor to only the inverter remotest from the computer. (Termination resistor: 100Ω)


2.2.5 Connection of stand-alone option units

The inverter accepts a variety of stand-alone option units as required. Incorrect connection will cause inverter damage or an accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

(1) Connection of the dedicated external brake resistor (option)


Connect a brake resistor across terminals + and PR. Connect a dedicated brake resistor only.

(For the positions of terminals + and PR, refer to the terminal block layout (page 19).)



(2) Connection of the BU brake unit (option)

Connect the BU brake unit correctly as shown on the right. Incorrect connection will damage the inverter.




- Note: 1. The wiring distance between the inverter, brake unit and discharge resistor should be within 2m. If twisted wires are used, the distance should be within 5m.
2. If the transistors in the brake unit should fail, the resistor will be extremely hot, causing a fire. Therefore, install a magnetic contactor on the inverter's power supply side to shut off current in case of failure.
3. When the power supply is 400V class, install a step-down transformer.

(3) Connection of the FR-HC high power factor converter (option unit)

(In the case of single-phase power input, the FR-HC cannot be connected.)

When connecting the high power factor converter (FR-HC) to suppress power harmonics, wire as shown below. Wrong connection will damage the high power factor converter and inverter.




- Note: 1. The power input terminals L₁, L₂, L₃ must be open. Incorrect connection will damage the inverter. Reverse polarity of terminals -, + will damage the inverter.
2. The voltage phases of terminals L₁, L₂, L₃ and terminals R₄, S₄, T₄ must be matched before connection.
3. If the load capacity is less than half of the high power factor converter capacity, satisfactory harmonic suppression effects cannot be produced.

(4) Connection of the power factor improving DC reactor (option)

Connect the FR-BEL power factor improving DC reactor between terminals P1-+. In this case, the jumper connected across terminals P1-+ must be removed. Otherwise, the reactor will not function.


<Connection method>



- Note: 1. The wiring distance should be within 5m.
2. The size of the cables used should be equal to or larger than that of the power supply cables (L₁, L₂, L₃).

2.2.6 Design information

- 1) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for commercial power supply-inverter switch-over.
When there is a commercial power supply-inverter switch-over circuit as shown below, the inverter will be damaged by leakage current from the power supply due to arcs generated at the time of switch-over or chattering caused by a sequence error.
- 2) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's primary circuit and also make up a sequence which will not switch on the start signal.
If the start signal (start switch) remains on after a power failure, the inverter will automatically restart as soon as the power is restored.
- 3) Since the input signals to the control circuit are on a low level, use two or more parallel micro signal contacts or a twin contact for contact inputs to prevent a contact fault.
- 4) Do not apply a large voltage to the contact input terminals (e.g. STF) of the control circuit.
- 5) Always apply a voltage to the alarm output terminals (A, B, C) via a relay coil, lamp etc.
- 6) Make sure that the specifications and rating match the system requirements.



2.3 Other Wiring

2.3.1 Power supply harmonics


Power supply harmonics may be generated from the converter section of the inverter, affecting the power supply equipment, power capacitor, etc. Power supply harmonics are different in generation source, frequency band and transmission path from radio frequency (RF) noise and leakage currents. Take the following counter measures.

- The differences between harmonics and RF noises are indicated below:

| Item | Harmonics | RF Noise |
|-----------------------------|---|--|
| Frequency | Normally 40th to 50th degrees, (up to 3kHz) or less | High frequency (several 10kHz to MHz order) |
| Environment | To wire paths, power impedance | Across spaces, distance, laying paths |
| Quantitative understanding | Logical computation is possible | Occurs randomly, quantitative understanding is difficult. |
| Generated amount | Approximately proportional to load capacity | According to current fluctuation rate (larger with faster switching) |
| Immunity of affected device | Specified in standards for each device. | Differs according to maker's device specifications. |
| Examples of safeguard | Install a reactor. | Increase the distance. |

- Countermeasures

The harmonic current generated from the inverter to the power supply differs according to various conditions such as the wiring impedance, whether a power factor improving reactor is used or not, and output frequency and output current on load side. For the output frequency and output current, the adequate method is to obtain them under rated load at the maximum operating frequency.



Note: A power factor improving capacitor and surge suppressor on the inverter's output side may overheat or be damaged due to the harmonics of the inverter output. Also, when an overcurrent flows in the inverter, the overcurrent protection is activated. Hence, when the motor is driven by the inverter, do not install a capacitor or surge suppressor on the inverter's output side. To improve the power factor, insert a power factor improving reactor in the inverter's input or DC circuit. For details, refer to the FR-A500/E500 series technical information.

2.3.2 Inverter-generated noise and reduction techniques

Some noises enter the inverter causing it to incorrectly operate, and others are radiated by the inverter causing misoperation of peripheral devices. Though the inverter is designed to be insusceptible to noise, it handles low-level signals, so it requires the following basic measures to be taken. Also, since the inverter chops the output at high carrier frequencies, it could generate noise. If these noises cause peripheral devices to misoperate, measures should be taken to suppress noise. The measures differ slightly depending on noise propagation paths.

1) Basic measures

- Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle them.
- Use twisted shield cables for the detector connecting and control signal cables and connect the sheathes of the shield cables to terminal SD.
- Earth (Ground) the inverter, motor, etc. at one point.



2) Measures against noise which enters and causes misoperation of the inverter

When devices which generate noise (devices which use magnetic contactors, magnetic brakes, many relays, for example) are installed near the inverter, the inverter may misoperate due to noise. The following measures must be taken:

- Provide surge suppressors for devices that generate noise to suppress noise.
- Fit data line filters (Refer to page 36) to signal cables.
- Ground the shields of the detector connection and control signal cables with cable clamp metal.

3) Measures against noises which are radiated by the inverter causing misoperation of peripheral devices.

Inverter-generated noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuit (I/O), those electromagnetically and electrostatically inducted to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.




| Noise Path | Measures |
|-------------------|---|
| 1), 2), 3) | <p>When devices which handle low-level signals and are susceptible to misoperation due to noise (such as instruments, receivers and sensors) are installed near the inverter and their signal cables are contained in the same panel as the inverter or are run near the inverter, the devices may be misoperated by air-propagated noise and the following measures must be taken:</p> <ol style="list-style-type: none"> (1) Install easily affected devices as far away as possible from the inverter. (2) Run easily affected signal cables as far away as possible from the inverter. (3) Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them. (4) Insert line noise filters onto I/O and radio noise filters into inputs to suppress cable-radiated noises. (5) Use shielded cables for signal cables and power cables and run them in individual metal conduits to further reduce effects. |
| 4), 5), 6) | <p>When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises may be propagated to the signal cables causing misoperation of the devices and the following measures must be taken:</p> <ol style="list-style-type: none"> (1) Install easily affected devices as far away as possible from the inverter. (2) Run easily affected signal cables as far away as possible from the inverter. (3) Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them. (4) Use shielded cables for signal cables and power cables and run them in individual metal conduits to further reduce effects. |
| 7) | <p>When the power supplies of the peripheral devices are connected to the power supply of the inverter within the same line, inverter-generated noise may flow back through the power supply cables causing misoperation of the devices and the following measures must be taken:</p> <ol style="list-style-type: none"> (1) Install the radio noise filter (FR-BIF) to the power cables (input cables) of the inverter. (2) Install the line noise filter (FR-BLF, FR-BSF01) to the power cables (I/O cables) of the inverter. |
| 8) | <p>When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage current may flow through the ground cable of the inverter causing misoperation of the device. In such a case, disconnection of the ground cable of the device may cause the device to operate properly.</p> |

● Data line filter

Noise entry can be prevented by providing a data line filter for the detector or other cable.

● Example of counter measures against noise



- By decreasing the carrier frequency, the noise terminal voltage* can be reduced. Use Pr. 72 to set the carrier frequency to a low value (1kHz). Though motor noise increases at a low carrier frequency, selection of Soft-PWM will make it unoffending.
 - By using shielded cables as signal cables, induction noise can be reduced greatly (1/10 to 1/100).
- * Noise terminal voltage: Represents the magnitude of noise propagated from the inverter to the power supply.

2.3.3 Leakage currents and countermeasures

Due to the static capacitance existing in the inverter I/O wiring and motor, leakage currents flow through them. Since their values depend on the static capacitance, carrier frequency, etc., take the following measures.

(1) To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earth (ground) cable, etc. These leakage currents may operate earth leakage circuit breakers and earth leakage relays unnecessarily.

● Countermeasures


- If the carrier frequency setting is high, decrease the carrier frequency (Pr. 72) of the inverter.
Note that motor noise increases. Selection of Soft-PWM (Pr. 240) will make it unoffending.
- By using earth leakage circuit breakers designed for harmonic and surge suppression (e.g. Mitsubishi's Progressive Super Series) in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).

● To-earth (ground) leakage current

- Note that a long wiring length will increase leakage currents. Decrease the carrier frequency of the inverter to reduce leakage currents.
- Higher motor capacity leads to larger leakage currents. The leakage currents of the 400V class are higher than those of the 200V class.

(2) Line-to-line leakage currents

Harmonics of leakage currents flowing in static capacities between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50m or more) for the 400V class, the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.



● **Countermeasures**

- Use the electronic overcurrent protection of the inverter.
- Decrease the carrier frequency. Note that motor noise increases. Selection of Soft-PWM will make it unoffending.

To ensure that the motor is protected not to be influenced by line-to-line leakage currents, we recommend the protection method which uses a temperature sensor to directly detect motor temperature.

2.3.4 Inverter-driven 400V class motor

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially for a 400V class motor, the surge voltage may deteriorate the insulation. When the 400V class motor is driven by the inverter, consider the following measures:

● **Measures**

It is recommended to take either of the following measures:

(1) Rectifying the motor insulation

For the 400V class motor, use an insulation-rectified motor. Specifically

- 1) Specify the "400V class inverter-driven, insulation-rectified motor".
- 2) For the dedicated motor such as the constant-torque motor and low-vibration motor, use the "inverter-driven, dedicated motor".

(2) Suppressing the surge voltage on the inverter side

On the secondary side of the inverter, connect the optional surge voltage suppression filter (FR-ASF-H).

2.3.5 Peripheral devices


(1) Selection of peripheral devices

Check the capacity of the motor to be used with the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity.

Refer to the following list and prepare appropriate peripheral devices:

| | Inverter Type | Motor Output (kW) | Power Supply Capacity (kVA) | Rated current of Circuit Breaker (Note 5) | | Magnetic Contactor (MC) | | |
|-------------------|-------------------|-------------------|-----------------------------|---|-------------------------------------|-------------------------|---|---|
| | | | | Standard | With power factor improving reactor | A | B | C |
| Three-phase 400V | FR-E540-0.4K-EC | 0.4 | 1.5 | 30AF 5A | 30AF 5A | S-N10 | | |
| | FR-E540-0.75K-EC | 0.75 | 2.5 | 30AF 5A | 30AF 5A | S-N10 | | |
| | FR-E540-1.5K-EC | 1.5 | 4.5 | 30AF 10A | 30AF 10A | S-N10 | | |
| | FR-E540-2.2K-EC | 2.2 | 5.5 | 30AF 15A | 30AF 10A | S-N20 | | |
| | FR-E540-3.7K-EC | 3.7 | 9 | 30AF 20A | 30AF 15A | S-N20 | | |
| | FR-E540-5.5K-EC | 5.5 | 12 | 30AF 30A | 30AF 20A | S-N20 | | |
| | FR-E540-7.5K-EC | 7.5 | 17 | 30AF 30A | 30AF 30A | S-N20 | | |
| Single-phase 200V | FR-E520S-0.4K-EC | 0.4 | 1.5 | 30AF 10A | 30AF 10A | S-N10 | | |
| | FR-E520S-0.75K-EC | 0.75 | 2.5 | 30AF 15A | 30AF 15A | S-N10 | | |
| | FR-E520S-1.5K-EC | 1.5 | 4.5 | 30AF 20A | 30AF 20A | S-N21 | | |
| | FR-E520S-2.2K-EC | 2.2 | 5.5 | 30AF 30A | 30AF 30A | S-N25 | | |

- Note: 1. Select the type of the no-fuse breaker (NFB) in response to the power supply capacity.
2. The power supply cable size of the motor indicated assumes that its length is 20m.
3. The inverter input side magnetic contactor to be chosen differs between the applicable ranges A, B and C shown on the right, depending on the power supply capacity and wiring length.
4. When the inverter capacity is greater than the motor capacity, choose the breaker and magnetic contactor in accordance with the inverter type and choose the cables and power factor improving reactor in accordance with the motor output.
5. For installations in the United States or Canada, the circuit breaker must be inverse time or instantaneous trip type.



● **Installation and selection of no-fuse breaker**


Install a no-fuse breaker (NFB) in the power supply side for protection of the inverter's primary wiring. Refer to the previous table and choose the NFB according to the inverter's power supply side power factor (which changes with the power supply voltage, output frequency and load). Especially for a completely electromagnetic type NFB, the one with a larger capacity must be selected since its operational characteristics change with harmonic currents. (Check the data of the corresponding breaker for confirmation.) Also the earth leakage circuit breaker used should be our product durable against harmonics/surges (such as the Progressive Super Series).

● **Power factor improving reactor**

| | Inverter Model | Power Factor Improving AC Reactor | Power Factor Improving DC Reactor |
|-------------------|-------------------|-----------------------------------|-----------------------------------|
| Three-phase 400V | FR-E540-0.4K-EC | FR-BAL-H0.4K | FR-BEL-H0.4K |
| | FR-E540-0.75K-EC | FR-BAL-H0.75K | FR-BEL-H0.75K |
| | FR-E540-1.5K-EC | FR-BAL-H1.5K | FR-BEL-H1.5K |
| | FR-E540-2.2K-EC | FR-BAL-H2.2K | FR-BEL-H2.2K |
| | FR-E540-3.7K-EC | FR-BAL-H3.7K | FR-BEL-H3.7K |
| | FR-E540-5.5K-EC | FR-BAL-H5.5K | FR-BEL-H5.5K |
| | FR-E540-7.5K-EC | FR-BAL-H7.5K | FR-BEL-H7.5K |
| Single-phase 200V | FR-E520S-0.4K-EC | FR-BAL-0.75K (Note) | FR-BEL-0.75K (Note) |
| | FR-E520S-0.75K-EC | FR-BAL-1.5K (Note) | FR-BEL-1.5K (Note) |
| | FR-E520S-1.5K-EC | FR-BAL-2.2K (Note) | FR-BEL-2.2K (Note) |
| | FR-E520S-2.2K-EC | FR-BAL-3.7K (Note) | FR-BEL-3.7K (Note) |

Note: The power factor may be slightly lower.


When the inverter is connected near a large-capacity power supply transformer (500kVA or more, wiring length 10m maximum) or there is power capacitor switch-over, excessive peak currents may flow into the power input circuit and damage the converter circuit. In such a case, the power supply improving reactor (FR-BEL or FR-BAL) must be installed.



(2) Selecting the rated sensitivity current for the earth leakage circuit breaker


When using the earth leakage circuit breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency:

Example of leakage current per 1km in cable path during commercial power supply operation when the CV cable is routed in metal conduit (200V 60Hz)



Cable size (mm²)

Leakage current example of 3-phase induction motor during commercial power supply operation (200V 60Hz)




Motor capacity (kW)

- Progressive Super Series (Type SP, CF, SF, CP)
Rated sensitivity current: $\Delta n \geq 10 \times (I_{g1} + I_{gn} + I_{g2} + I_{gm})$
- Conventional NV series (Type CA, CS, SS produced prior to '91)
Rated sensitivity current: $\Delta n \geq 10 \times \{I_{g1} + I_{gn} + 3 \times (I_{g2} + I_{gm})\}$

I_{g1}, I_{g2} : Leakage currents of cable path during commercial power supply operation
 I_{gn}^* : Leakage current of noise filter on inverter input side
 I_{gm} : Leakage current of motor during commercial power supply operation

<Example>



- Note: 1. The earth leakage circuit breaker should be installed to the primary (power supply) side of the inverter.
2. Ground fault in the secondary side of the inverter can be detected at the running frequency of 120Hz or lower.
3. In the Δ connection neutral point grounded system, the sensitivity current becomes worse for ground faults in the inverter secondary side. Hence, the protective grounding of the load equipment should be 10Ω or less.
4. When the breaker is installed in the secondary side of the inverter, it may be unnecessarily operated by harmonics if the effective value is less than the rating. In this case, do not install the breaker since the eddy current and hysteresis loss increase and the temperature rises.
- * Note the leakage current value of the noise filter installed on the inverter input side.

| | Progressive Super Series (Type SP, CF, SF,CP) | Conventional NV (Type CA, CS, SS) |
|---|--|--|
| Leakage current (I _{g1}) (mA) | $33 \times \frac{5m}{1000m} = 0.17$ | |
| Leakage current (I _{gn}) (mA) | 0 (without noise filter) | |
| Leakage current (I _{g2}) (mA) | $33 \times \frac{70m}{1000m} = 2.31$ | |
| Motor leakage current (I _{gm}) (mA) | 0.18 | |
| Total leakage current (mA) | 2.66 | 7.64 |
| Rated sensitivity current (mA) ($\geq I_g \times 10$) | 30 | 100 |

2.3.6 Instructions for compliance with U.S. and Canadian Electrical Codes



(Standard to comply with: UL 508C)

(1) Short circuit ratings

Suitable For Use In A Circuit Capable Of Delivering Not More Than 5 kA rms Symmetrical Amperes.

(2) Branch circuit protection

For installation in United States, branch circuit protection must be provided, in accordance with the National Electrical Code and any applicable local codes.

For installation in Canada, branch circuit protection must be provided in accordance with the Canada Electrical Code and any applicable provincial codes.

(3) Wiring of the power supply and motor


Use the UL-listed cables (rated at 75°C) and round crimping terminals to wire the input (L1, L2, L3) and output (U, V, W) terminals of the inverter. Crimp the terminals with the crimping tool recommended by the terminal manufacturer.

(4) Motor overload protection

When using the electronic overcurrent protection function as motor overload protection, set the rated motor current in Pr. 9 "electronic thermal O/L relay.

When connecting two or more motors to the inverter, install external thermal relays for individual motors.

Reference: Motor overload protection characteristics



- Protection activating range
Range on the right of characteristic curve
- Normal operating range
Range on the left of characteristic curve

(Note 1) When you set the 50% value (current value) of the rated inverter output current.

(Note 2) The % value denotes the percentage of the current value to the rated inverter output current, not to the rated motor current.

(Note 3) This characteristic curve will be described even under operation of 6Hz or higher when you set the electronic overcurrent protection dedicated to the Mitsubishi constant-torque motor.

2.3.7 Instructions for compliance with the European standards

(The products conforming to the Low Voltage Directive carry the CE mark.)

(1) EMC Directive

1) Our view of transistorized inverters for the EMC Directive

A transistorized inverter is a component designed for installation in a control box and for use with the other equipment to control the equipment/device. Therefore, we understand that the EMC Directive does not apply directly to transistorized inverters. For this reason, we do not place the CE mark on the transistorized inverters. (The CE mark is placed on inverters in accordance with the Low Voltage Directive.) The European power drive manufacturers' organization (CEMEP) also holds this point of view.

2) Compliance

We understand that the transistorized inverters are not covered directly by the EMC Directive. However, the EMC Directive applies to machines/equipment into which transistorized inverters have been incorporated, and these machines and equipment must carry the CE marks. Hence, we prepared the technical information "EMC Installation Guidelines" (information number BCN-A21041-202) so that machines and equipment incorporating transistorized inverters may conform to the EMC Directive more easily.

3) Outline of installation method

Install an inverter using the following methods:

- * Use the inverter with an European Standard-compliant noise filter.
- * For wiring between the inverter and motor, use shielded cables or run them in a metal piping and ground the cables on the inverter and motor sides with the shortest possible distance.
- * Insert a line noise filter and ferrite core into the power and control lines as required.

Full information including the European Standard-compliant noise filter specifications are written in the technical information "EMC Installation Guidelines" (BCN-A21041-202). Please contact your sales representative.

(2) Low Voltage Directive

- 1) Our view of transistorized inverters for the Low Voltage Directive
 Transistorized inverters are covered by the Low Voltage Directive (Standard to comply with: EN50178).
- 2) Compliance
 We have self-confirmed our inverters as products compliant to the Low Voltage Directive and place the CE mark on the inverters.
- 3) Outline of instructions
 - * In the 400V class inverters, the rated input voltage range is three-phase, 380V to 415V, 50Hz/60Hz.
 - * Connect the equipment to the earth (ground) securely. Do not use an earth leakage circuit breaker as an electric shock protector without connecting the equipment to the earth (ground).
 - * Wire the earth terminal independently. (Do not connect two or more cables to one terminal.)
 - * The wire size on pages 18 and 19 are shown for following conditions.
 - Ambient Temp: 40°C maximum
 - Wire installation: On wall without duct or conduits
 If conditions are different from above, select appropriate wire according to EN60204 ANNEX C TABLE 5.
 - * Use the no-fuse breaker and magnetic contactor which conform to the EN or IEC Standard.
 Design notice: Where residual-current-operated protective device (RCD) is used for protection in case of direct or indirect contact, only RCD of Type B is allowed on the supply side of this Electronic Equipment (EE). Otherwise another protective measure shall be applied such as separation of the EE from the environment by double or reinforced insulation or isolation of EE and supply system by a transformer. (Extract from EN51078)
 - * Use the inverter under the conditions of overvoltage category II and contamination level 2 or higher specified in IEC664.
 - * On the input and output of the inverter, use cables of the type and size set forth in EN60204 Appendix C.
 - * The operating capacity of the relay outputs (terminal symbols A, B, C) should be 30VDC, 0.3A.
 - * The terminals indicated as the input and output terminals for control circuit on page 13 are isolated safely from the main circuit.

Environment

| \ | During operation | In storage | During transportation |
|---------------------|-------------------------|-------------------|------------------------------|
| Ambient Temperature | -10°C to +50°C | -20°C to +65°C | -20°C to +65°C |
| Ambient Humidity | 90% RH or less | 90% RH or less | 90% RH or less |
| Maximum Altitude | 1,000 m | 1,000 m | 10,000 m |

Details are given in the technical information "Low Voltage Directive Conformance Guide" (BCN-A21041-203). Please contact your sales representative.

CHAPTER 3

OPERATION/CONTROL

This chapter provides the basic "operation/control" for use of this product.

Always read this chapter before using the equipment.

| | |
|-------------------------------------|----|
| 3.1 Pre-Operation Information | 46 |
| 3.2 About the Control Panel..... | 49 |
| 3.3 Operation..... | 55 |

Chapter 1

Chapter 2

Chapter 3

Chapter 4

Chapter 5

Chapter 6

3.1 Pre-Operation Information

3.1.1 Types of operation modes


The inverter can be operated in any of "PU operation mode", "external operation mode", "combined operation mode" and "communication operation mode". Prepare required instruments and parts according to the operation mode. For the way of changing the operation mode, refer to page 52.

(1) External operation mode

(factory setting, Pr. 79 "operation mode selection" = 0)

Pr. 79 "operation mode selection" is factory-set to 0 and the external operation mode is selected at power-on.

The inverter is operated using an external start signal and an external frequency setting signal.




Preparation

- Start signal..... Switch, relay, etc.
- Frequency setting signal... 0 to 5V, 0 to 10V or 4 to 20mA
DC signals or multiple speeds
from a potentiometer or outside
the inverter

Note: 1. Operation cannot be started by the start signal alone. Both the start signal and frequency setting signal are required to run the inverter.

(2) PU operation mode (Pr. 79 "operation mode selection" = 1)

How to perform operation using the optional control panel or parameter unit.



Preparation

- Operation unitControl panel (FR-PA02-02) or parameter unit (FR-PU04)
- Connection cableTo be prepared for use of the control panel (FR-PA02-02) away from the inverter or for use of the parameter unit (FR-PU04).
FR-CB2□□ (option)
- FR-E5P (option)To be prepared for use of the control panel away from the inverter. It is available as a set of control panel cover and connection cable junction adapter.


(3) Combined operation mode 1 (Pr. 79 "operation mode selection" = 3)

The start signal is an external signal.

The frequency setting signal is made setting using the optional control panel or parameter unit.

Preparation

- Start signal Switch, relay, etc.
- Operation unit Control panel (FR-PA02-02) or parameter unit (FR-PU04)
- Connection cable Refer to (1) PU operation mode.
- FR-E5P (option) Refer to (1) PU operation mode.


**(4) Combined operation mode 2 (Pr. 79 "operation mode selection" = 4)**

The start signal is entered from the operation command key of the optional control panel.

The frequency setting signal is set using the external frequency setting signal.

Preparation

- Frequency 0 to 5V, 0 to 10V or 4 to 20mA DC setting signal signals from an external potentiometer or from outside the inverter
- Operation unit Control panel (FR-PA02-02) or parameter unit (FR-PU04)
- Connection cable Refer to (1) PU operation mode.
- FR-E5P (option) Refer to (1) PU operation mode.



(5) Communication operation mode


(Pr. 79 "operation mode selection" = 0 or 1)

Communication operation can be performed by connecting a personal computer and the PU connector with the RS-485 communication cable.

The inverter setup software is available as an FR-E500 inverter start-up support software package.

Preparation

- Connection cable Connector: RJ45 connector
Cable: Cable conforming to EIA568
(e.g. 10BASE-T cable)
- Personal computer
- RS-485, RS-232C converter To be prepared when the communication port of the personal computer has RS-232C specifications.



3.1.2 Power on

Before switching power on, check the following.

● **Installation check**

Make sure that the inverter is installed correctly in a proper location. (Refer to page 11.)

- **Wiring check**

Make sure that the main and control circuits are wired correctly.

Make sure that the options and peripheral devices are selected and connected correctly. (Refer to page 13.)


● **Switch power on**

Power-on is complete if the POWER lamp is lit and the ALARM lamp is off.

3.2 About the Control Panel

With the optional control panel (FR-PA02-02), you can run the inverter, set the frequency, monitor the operation command display, set parameters, and display an error.

3.2.1 Names and functions of the control panel (FR-PA02-02)




● Key indication

| Key | Description |
|-----|--|
| key | Used to give a start rotation command. |
| key | You can select the operation mode or setting mode. |
| key | You can determine the frequency and parameter setting. |
| key | <ul style="list-style-type: none"> Used to increase or decrease the running frequency consecutively. Hold down this key to change the frequency. Press this key in the setting mode to change the parameter setting consecutively. |
| key | Used to give a forward rotation command. |
| key | Used to give a reverse rotation command. |
| key | <ul style="list-style-type: none"> Used to stop operation. Used to reset the inverter when its output is stopped by the activated protective function. |

● Unit indications, operating status indications

| Indication | Description |
|------------|---|
| Hz | Lit to indicate the frequency. |
| A | Lit to indicate the current. |
| RUN | Lit while the inverter is operating. Lit to indicate forward rotation, and flickers to indicate reverse rotation. |
| MON | Lit in the monitor display mode. |
| PU | Lit in the PU operation mode. |
| EXT | Lit in the external operation mode. |

3.2.2 Control panel mode is changed by pressing the **MODE** key




(Note) The frequency setting mode is displayed only in the PU operation mode.

3.2.3 Monitoring

- Operation command indications given while a monitor display is being provided
EXT is lit to indicate external operation.
PU is lit to indicate PU operation.
Both EXT and PU are lit to indicate combined operation.
- The monitor display can also be changed during operation.

•Frequency monitor




To 3.2.4 Frequency setting mode (Note3)

Note: 1. Hold down the **SET** key marked *1 for more than 1.5 seconds to change the current monitor to the power-on monitor.
2. Hold down the **SET** key marked *2 for more than 1.5 seconds to display four errors including the most recent one.
3. To the parameter setting mode when in the external operation mode.

3.2.4 Frequency setting

Set the frequency value used for operation performed under the operation command given by the **RUN** key (**FWD** or **REV** key) in the PU operation mode. This mode is displayed only in PU operation.



3.2.5 Parameter setting method

With the exception of some parameters, parameter setting can be made only when the PU operation mode is selected by the Pr. 79 setting.

- A parameter value may either be set by updating its parameter number or setting the value digit-by-digit using the **▲**/**▼** key.
- To write the setting, change it and press the **SET** key for about 1.5 seconds.



Note: If parameter write cannot be performed, refer to page 168.

(1) Example: To change the Pr. 79 "operation mode selection" setting from "2" (external operation mode) to "1" (PU operation mode)

(For details of Pr. 79, refer to page 105.)

Press the **MODE** key, to choose the parameter setting mode.


●Parameter setting mode



3.2.6 Operation mode


The operation mode change method which is shown below is only allowed when Pr. 79 "operation mode selection" is "0".

●PU operation



Note: If the operation mode cannot be changed, refer to page 168.


3.2.7 Help mode



(1) Alarm history


Four past alarms can be displayed with the \uparrow/\downarrow key.
 ("." is appended to the most recent alarm.)
 When no alarm exists, E.__0 is displayed.

● Most recent alarm




(2) Alarm history clear

Clears all alarm history.



(3) Parameter clear


Initializes the parameter values to the factory settings. The calibration values are not initialized.
 (Parameter values are not cleared by setting "1" in Pr. 77 "parameter write disable selection")



Note: The Pr. 75, Pr. 180 to Pr. 183, Pr. 190 to Pr. 192, and Pr. 901 to Pr. 905 values are not initialized.

(4) All clear

Initializes the parameter values and calibration values to the factory settings.



Note: The Pr. 75 value is not initialized.

3.3 Operation

3.3.1 Pre-operation checks

Before starting operation, check the following:






- Safety
Perform test operation after making sure that safety is ensured if the machine should become out of control.
- Machine
Make sure that the machine is free of damage.
- Parameters
Set the parameter values to match the operating machine (system) environment.
- Test operation
Perform test operation and make sure that the machine operates safely under light load at a low frequency. After that, start operation.
Since the Pr. 240 "Soft-PWM setting" value is factory-set to select Soft-PWM control, the tone is different from that in the conventional non-low acoustic noise mode, this is not a fault.

3.3.2 External operation mode (Operation using the external frequency setting potentiometer and external start signal)

(1) Operation at 50Hz

Operation command: Externally connected start signal

Frequency setting: Externally connected frequency setting potentiometer

| Step | Description | Image |
|------|---|---|
| 1 | Power on → Operation mode check With the factory setting, the external operation mode is selected and the [EXT] indication is lit when power is switched on. If the [EXT] indication is not lit, refer to page 51 and set "2" in Pr. 79. |  |
| 2 | Start Set the start switch (STF or STR) to ON. The [RUN] indication is lit to indicate forward rotation, or flickers to indicate reverse rotation. <div style="border: 1px solid black; padding: 5px; width: fit-content;">Note: The motor does not start if both the forward and reverse rotation switches are turned on. If both switches are turned on during operation, the motor decelerates to a stop.</div> |  |
| 3 | Acceleration → Constant speed Slowly turn the potentiometer connected across terminals 2-5 (frequency setting potentiometer) fully clockwise. The frequency shown on the display increases gradually to 50.00Hz. |  |
| 4 | Deceleration Slowly turn the potentiometer connected across terminals 2-5 (frequency setting potentiometer) fully counterclockwise. The frequency shown on the display decreases gradually to 0.00Hz. The motor stops running. |  |
| 5 | Stop Turn off the start switch (STF or STR). |  |

<Reference> If other frequency is required at fully clockwise position, change Pr. 38 "Frequency at 5V (10V)" setting.
(Refer to page 151)

3.3.3 PU operation mode (Operation using the control panel)

(1) Using the control panel (FR-PA02-02) for operation at 50Hz with digital frequency setting

Operation command: key or control panel (FR-PA02-02) / key

Frequency setting: / key

Related parameters: Pr. 79 "operation mode selection"

By repeating step 2 below during motor run, speed can be varied.

| Step | Description | Image |
|------|---|-------|
| 1 | Power on → Operation mode check Switch power on, refer to page 51, and set "1" in Pr. 79 "operation mode selection". The [PU] indication is lit. | |
| 2 | Running frequency setting Set the running frequency to 50Hz. 1) Refer to page 50 and select the frequency setting mode with the key. 2) Refer to page 51, change the setting with the / key, and write the new setting with the key. | |
| 3 | Start Press the key (or / key). The monitoring mode is automatically selected and the output frequency is displayed. The [RUN] indication is lit to indicate forward rotation, or flickers to indicate reverse rotation. | |
| 4 | Stop Press the key. The motor is decelerated to a stop. The [RUN] indication goes off. | |

(2) PU jog operation

Hold down the (or or) key to perform operation, and release it to stop.

1) Set Pr. 15 "jog frequency" and Pr. 16 "jog acceleration/deceleration time".


2) Select the PU jog operation mode. (Refer to page 53.)

3) Hold down the (or or) key to perform operation.



(If the motor remains stopped, check Pr. 13 "starting frequency". The motor will not start if its setting is lower than the starting frequency.)








3.3.4 Combined operation mode 1 (Operation using both external start signal and control panel)


When the start signal is provided externally (switch etc.) and the running frequency is set from the control panel (Pr. 79 = 3).

The external frequency setting signal and PU's forward rotation, reverse rotation and  keys are not accepted. (Note)




Operation command: externally connected start signal




Frequency setting:  /  key of the control panel (FR-PA02-02) or multi-speed command (multi-speed command has priority) Refer to page 72.

| Step | Description | Image |
|------|---|---|
| 1 | Power on Switch power on. |  |
| 2 | Operation mode selection Refer to page 52 and set "3" in Pr. 79 "operation mode selection". The [PU] and [EXT] indications are lit. |  |
| 3 | Start Turn on the start switch (STF or STR). Note: The motor does not start if both the forward and reverse rotation switches are turned on. If both switches are turned on during operation, the motor decelerates to a stop. The [RUN] indication is lit to indicate forward rotation, or flickers to indicate reverse rotation. |  |
| 4 | Running frequency setting Set the running frequency to 60.00Hz with the  /  key. |  |
| 5 | Stop Turn off the start switch (STF or STR). The motor stops. The [RUN] indication goes off. |  |











Note: The  key is made valid if any of "14" to "17" is set in Pr. 75 "PU stop selection".

3.3.5 Combined operation mode 2

When the running frequency is set from a potentiometer connected across terminals 2-5 (frequency setting potentiometer) and the start signal is provided by the  key or  /  key of the control panel (FR-PA02-02). (Pr.79 = 4)

Operation command:  key (or  /  key) of the control panel (FR-PA02-02)

Frequency setting: Externally connected frequency setting potentiometer or multi-speed command (multi-speed command has priority) Refer to page 72.

| Step | Description | Image |
|------|--|---|
| 1 | Power on Switch power on. |  |
| 2 | Operation mode selection Refer to page 51 and set "4" in Pr. 79 "operation mode selection". The [PU] and [EXT] indications are lit. |  |
| 3 | Start Press the  key (or  /  key) of the control panel. The [RUN] indication is lit to indicate forward rotation, or flickers to indicate reverse rotation. |  |
| 4 | Acceleration → Constant speed Slowly turn the potentiometer connected across terminals 2-5 (frequency setting potentiometer) fully clockwise. The frequency shown on the display increases gradually to 50.00Hz. |  |
| 5 | Deceleration Slowly turn the potentiometer connected across terminals 2-5 (frequency setting potentiometer) fully counterclockwise. The frequency shown on the display decreases gradually to 0.00Hz. The motor stops running. |  |
| 6 | Stop Press the  key. The operation command indication RUN goes off. |  |

<Reference> If other frequency is required at fully clockwise position, change Pr. 38 "Frequency at 5V (10V) " setting. (Refer to page 151)

CHAPTER 4

PARAMETERS

This chapter explains the "parameters" of this product. With the factory settings, the inverter is designed to perform simple variable-speed operation. Set necessary parameter values according to the load and operating specifications. Always read the instructions before using the equipment.

| | |
|--------------------------------------|----|
| 4.1 Parameter List | 60 |
| 4.2 Parameter Function Details | 69 |

Note: By making parameter setting, you can change the functions of contact input terminals RL, RM, RH, MRS, open collector output terminals RUN, FU, and contact output terminals A, B, C. Therefore, signal names corresponding to the functions are used in the description of this chapter (except in the wiring examples). Note that they are not terminal names.

Chapter 1

Chapter 2

Chapter 3

Chapter 4

Chapter 5

Chapter 6

4.1 Parameter List

PARAMETERS

4.1.1 Parameter list

| Function | Parameter Number | Name | Setting Range | Minimum Setting Increments | Factory Setting | Refer To: | Customer Setting |
|------------------------------|------------------|---|----------------------------|----------------------------|-------------------------------|-----------|------------------|
| Basic functions | 0 | Torque boost (Note 1) | 0 to 30% | 0.1% | 6%/4% (Note 8) | 69 | |
| | 1 | Maximum frequency | 0 to 120Hz | 0.01Hz (Note 3) | 120Hz | 70 | |
| | 2 | Minimum frequency | 0 to 120Hz | 0.01Hz (Note 3) | 0Hz | 70 | |
| | 3 | Base frequency (Note 1) | 0 to 400Hz | 0.01Hz (Note 3) | 50Hz | 71 | |
| | 4 | Multi-speed setting (high speed) | 0 to 400Hz | 0.01Hz (Note 3) | 50Hz | 72 | |
| | 5 | Multi-speed setting (middle speed) | 0 to 400Hz | 0.01Hz (Note 3) | 30Hz | 72 | |
| | 6 | Multi-speed setting (low speed) | 0 to 400Hz | 0.01Hz (Note 3) | 10Hz | 72 | |
| | 7 | Acceleration time | 0 to 3600 s/ 0 to 360 s | 0.1 s/0.01 s | 5 s/10s (Note 4) | 73 | |
| | 8 | Deceleration time | 0 to 3600 s/ 0 to 360 s | 0.1 s/0.01 s | 5 s/10s (Note 4) | 73 | |
| | 9 | Electronic thermal O/L relay | 0 to 500A | 0.01A | Rated output current (Note 5) | 75 | |
| Standard operation functions | 10 | DC injection brake operation frequency | 0 to 120Hz | 0.01Hz (Note 3) | 3Hz | 76 | |
| | 11 | DC injection brake operation time | 0 to 10 s | 0.1 s | 0.5 s | 76 | |
| | 12 | DC injection brake voltage | 0 to 30% | 0.1% | 6% | 76 | |
| | 13 | Starting frequency | 0 to 60Hz | 0.01Hz | 0.5Hz | 77 | |
| | 14 | Load pattern selection (Note 1) | 0 to 3 | 1 | 0 | 78 | |
| | 15 | Jog frequency | 0 to 400Hz | 0.01Hz (Note 3) | 5Hz | 79 | |
| | 16 | Jog acceleration/ deceleration time | 0 to 3600 s/ 0 to 360 s | 0.1 s/ 0.01 s | 0.5 s | 79 | |
| | 18 | High-speed maximum frequency | 120 to 400Hz | 0.1Hz (Note 3) | 120Hz | 70 | |
| | 19 | Base frequency voltage (Note 1) | 0 to 1000V, 8888,9999 | 0.1V | 8888 | 71 | |
| | 20 | Acceleration/deceleration reference frequency | 1 to 400Hz | 0.01Hz (Note 3) | 50Hz | 73 | |
| | 21 | Acceleration/deceleration time increments | 0, 1 | 1 | 0 | 73 | |
| | 22 | Stall prevention operation level | 0 to 200% | 0.1% | 150% | 80 | |
| | 23 | Stall prevention operation level compensation factor at double speed (Note 6) | 0 to 200%, 9999 | 0.1% | 9999 | 80 | |
| | 24 | Multi-speed setting (speed 4) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | |
| | 25 | Multi-speed setting (speed 5) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | |
| | 26 | Multi-speed setting (speed 6) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | |

PARAMETERS

| Function | Parameter Number | Name | Setting Range | Minimum Setting Increments | Factory Setting | Refer To: | Customer Setting |
|------------------------------|---------------------------|---|-------------------------------|----------------------------|----------------------|-----------|------------------|
| Standard operation functions | 27 | Multi-speed setting (speed 7) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | |
| | 29 | Acceleration/deceleration pattern | 0, 1, 2 | 1 | 0 | 82 | |
| | 30 | Regenerative function selection | 0, 1 | 1 | 0 | 83 | |
| | 31 | Frequency jump 1A | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 84 | |
| | 32 | Frequency jump 1B | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 84 | |
| | 33 | Frequency jump 2A | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 84 | |
| | 34 | Frequency jump 2B | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 84 | |
| | 35 | Frequency jump 3A | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 84 | |
| | 36 | Frequency jump 3B | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 84 | |
| | 37 | Speed display | 0, 0.01 to 9998 | 0.001 r/min | 0 | 85 | |
| | 38 | Frequency at 5V (10V) input | 1 to 400Hz | 0.01Hz (Note 3) | 50Hz (Note 2) | 86 | |
| | 39 | Frequency at 20mA input | 1 to 400Hz | 0.01Hz (Note 3) | 50Hz (Note 2) | 86 | |
| | Output terminal functions | 41 | Up-to-frequency sensitivity | 0 to 100% | 0.1% | 10% | 87 |
| 42 | | Output frequency detection | 0 to 400Hz | 0.01Hz (Note 3) | 6Hz | 88 | |
| 43 | | Output frequency detection for reverse rotation | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 88 | |
| Second functions | 44 | Second acceleration/ deceleration time | 0 to 3600 s/ 0 to 360 s | 0.1 s/0.01 s | 5 s/10 s (Note 10) | 73 | |
| | 45 | Second deceleration time | 0 to 3600 s/ 0 to 360 s, 9999 | 0.1 s/0.01 s | 9999 | 73 | |
| | 46 | Second torque boost (Note 1) | 0 to 30%, 9999 | 0.1% | 9999 | 69 | |
| | 47 | Second V/F (base frequency) (Note 1) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 71 | |
| | 48 | Second electronic overcurrent protection | 0 to 500A, 9999 | 0.01A | 9999 | 75 | |
| Display functions | 52 | Control panel/PU main display data selection | 0,23,100 | 1 | 0 | 89 | |
| | 55 | Frequency monitoring reference | 0 to 400Hz | 0.01Hz (Note 3) | 50Hz | 91 | |
| | 56 | Current monitoring reference | 0 to 500A | 0.01A | Rated output current | 91 | |
| Automatic restart functions | 57 | Restart coasting time | 0 to 5 s, 9999 | 0.1 s | 9999 | 92 | |
| | 58 | Restart cushion time | 0 to 60 s | 0.1 s | 1.0 s | 92 | |
| Additional function | 59 | Remote setting function selection | 0, 1, 2 | 1 | 0 | 93 | |

PARAMETERS

Parameter List

| Function | Parameter Number | Name | Setting Range | Minimum Setting Increments | Factory Setting | Refer To: | Customer Setting |
|-------------------------------|--|--|--|----------------------------|-----------------|-----------|------------------|
| Operation selection functions | 60 | Shortest acceleration/ deceleration mode | 0, 1, 2, 11, 12 | 1 | 0 | 95 | |
| | 61 | Reference I for intelligent mode | 0 to 500A, 9999 | 0.01A | 9999 | 95 | |
| | 62 | Ref. I for intelligent mode accel | 0 to 200%, 9999 | 1% | 9999 | 95 | |
| | 63 | Ref. I for intelligent mode decel | 0 to 200%, 9999 | 1% | 9999 | 95 | |
| | 65 | Retry selection | 0, 1, 2, 3 | 1 | 0 | 96 | |
| | 66 | Stall prevention operation level reduction starting frequency (Note 6) | 0 to 400Hz | 0.01Hz (Note 3) | 50Hz | 80 | |
| | 67 | Number of retries at alarm occurrence | 0 to 10, 101 to 110 | 1 | 0 | 96 | |
| | 68 | Retry waiting time | 0.1 to 360 s | 0.1 s | 1 s | 96 | |
| | 69 | Retry count display erasure | 0 | 1 | 0 | 96 | |
| | 70 | Special regenerative brake duty | 0 to 30% | 0.1% | 0% | 83 | |
| | 71 | Applied motor (Note 6) | 0, 1, 3, 5, 6, 13, 15, 16, 23, 100, 101,103, 105, 106, 113, 115, 116,123 | 1 | 0 | 98 | |
| | 72 | PWM frequency selection | 0 to 15 | 1 | 1 | 99 | |
| | 73 | 0-5V/0-10V selection | 0, 1, 10, 11 (Note 9) | 1 | 0 | 100 | |
| | 74 | Filter time constant | 0 to 8 | 1 | 1 | 101 | |
| | 75 | Reset selection/ disconnected PU detection/ PU stop selection | 0 to 3, 14 to 17 | 1 | 14 | 101 | |
| | 77 | Parameter write disable selection | 0, 1, 2 | 1 | 0 | 103 | |
| | 78 | Reverse rotation prevention selection | 0, 1, 2 | 1 | 0 | 104 | |
| | 79 | Operation mode selection (Note 6) | 0 to 4,6 to 8 | 1 | 0 | 105 | |
| | General-purpose magnetic flux vector control | 80 | Motor capacity (Note 6) | 0.2 to 7.5kW, 9999 | 0.01kW | 9999 | 109 |
| 82 | | Motor exciting current | 0 to 500A, 9999 | 0.01A | 9999 | 110 | |
| 83 | | Rated motor voltage (Note 6) | 0 to 1000V | 0.1V | 200V/ 400V | 110 | |
| 84 | | Rated motor frequency (Note 6) | 50 to 120Hz | 0.01Hz (Note 3) | 50Hz | 110 | |
| 90 | | Motor constant (R1) | 0 to 50Ω, 9999 | 0.001Ω | 9999 | 110 | |
| 96 | | Auto-tuning setting/status (Note 6) | 0, 1 | 1 | 0 | 110 | |

| Function | Parameter Number | Name | Setting Range | Minimum Setting Increments | Factory Setting | Refer To: | Customer Setting |
|-------------------------|------------------|--|--|----------------------------|-----------------|-----------|------------------|
| Communication functions | 117 | Station number | 0 to 31 | 1 | 0 | 116 | |
| | 118 | Communication speed | 48, 96, 192 | 1 | 192 | 116 | |
| | 119 | Stop bit length | 0, 1 (data length 8) 10, 11 (data length 7) | 1 | 1 | 116 | |
| | 120 | Parity check presence/absence | 0, 1, 2 | 1 | 2 | 116 | |
| | 121 | Number of communication retries | 0 to 10,9999 | 1 | 1 | 116 | |
| | 122 | Communication check time interval | 0, 0.1 to 999.8 s, 9999 | 0.1 s | 9999 | 116 | |
| | 123 | Waiting time setting | 0 to 150, 9999 | 1 | 9999 | 116 | |
| | 124 | CR-LF presence/absence selection | 0, 1, 2 | 1 | 1 | 116 | |
| PID control | 128 | PID action selection | 0, 20, 21 | 1 | 0 | 128 | |
| | 129 | PID proportional band | 0.1 to 1000%, 9999 | 0.1% | 100% | 128 | |
| | 130 | PID integral time | 0.1 to 3600 s, 9999 | 0.1 s | 1 s | 128 | |
| | 131 | Upper limit | 0 to 100%, 9999 | 0.1% | 9999 | 128 | |
| | 132 | Lower limit | 0 to 100%, 9999 | 0.1% | 9999 | 128 | |
| | 133 | PID action set point for PU operation | 0 to 100% | 0.01% | 0% | 128 | |
| | 134 | PID differential time | 0.01 to 10.00 s, 9999 | 0.01 s | 9999 | 128 | |
| Additional function | 145 | Parameter for option (FR-PU04). | | | | | |
| | 146 | Parameter set by manufacturer. Do not set. | | | | | |
| Current detection | 150 | Output current detection level | 0 to 200% | 0.1% | 150% | 136 | |
| | 151 | Output current detection period | 0 to 10 s | 0.1 s | 0 | 136 | |
| | 152 | Zero current detection level | 0 to 200.0% | 0.1% | 5.0% | 137 | |
| | 153 | Zero current detection period | 0.05 to 1 s | 0.01 s | 0.5 s | 137 | |
| Sub function | 156 | Stall prevention operation selection | 0 to 31,100 | 1 | 0 | 138 | |
| | 158 | AM terminal function selection | 0, 1, 2 | 1 | 0 | 89 | |

PARAMETERS

| Function | Parameter Number | Name | Setting Range | Minimum Setting Increments | Factory Setting | Refer To: | Customer Setting | |
|-------------------------------|------------------|--|------------------|----------------------------|-----------------|-----------|------------------|--|
| Additional function | 160 | User group read selection | 0, 1, 10, 11 | 1 | 0 | 140 | | |
| | 168 | Parameters set by manufacturer. Do not set. | | | | | | |
| | 169 | | | | | | | |
| Initial monitor | 171 | Actual operation hour meter clear | 0 | — | 0 | 142 | | |
| User functions | 173 | User group 1 registration | 0 to 999 | 1 | 0 | 140 | | |
| | 174 | User group 1 deletion | 0 to 999,9999 | 1 | 0 | 140 | | |
| | 175 | User group 2 registration | 0 to 999 | 1 | 0 | 140 | | |
| | 176 | User group 2 deletion | 0 to 999,9999 | 1 | 0 | 140 | | |
| Terminal assignment functions | 180 | RL terminal function selection (Note 6) | 0 to 8, 16, 18 | 1 | 0 | 142 | | |
| | 181 | RM terminal function selection (Note 6) | 0 to 8, 16, 18 | 1 | 1 | 142 | | |
| | 182 | RH terminal function selection (Note 6) | 0 to 8, 16, 18 | 1 | 2 | 142 | | |
| | 183 | MRS terminal function selection (Note 6) | 0 to 8, 16, 18 | 1 | 6 | 142 | | |
| | 190 | RUN terminal function selection (Note 6) | 0 to 99 | 1 | 0 | 144 | | |
| | 191 | FU terminal function selection (Note 6) | 0 to 99 | 1 | 4 | 144 | | |
| | 192 | A, B, C terminal function selection (Note 6) | 0 to 99 | 1 | 99 | 144 | | |
| Multi-speed operation | 232 | Multi-speed setting (speed 8) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 233 | Multi-speed setting (speed 9) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 234 | Multi-speed setting (speed 10) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 235 | Multi-speed setting (speed 11) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 236 | Multi-speed setting (speed 12) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 237 | Multi-speed setting (speed 13) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 238 | Multi-speed setting (speed 14) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| | 239 | Multi-speed setting (speed 15) | 0 to 400Hz, 9999 | 0.01Hz (Note 3) | 9999 | 72 | | |
| Sub functions | 240 | Soft-PWM setting | 0, 1 | 1 | 1 | 99 | | |
| | 244 | Cooling fan operation selection | 0, 1 | 1 | 0 | 145 | | |
| | 245 | Rated motor slip | 0 to 50%, 9999 | 0.01% | 9999 | 146 | | |
| | 246 | Slip compensation response time | 0.01 to 10 s | 0.01 s | 0.5 s | 146 | | |
| | 247 | Constant-output region slip compensation selection | 0, 9999 | 1 | 9999 | 146 | | |

| Function | Parameter Number | Name | Setting Range | | Minimum Setting Increments | Factory Setting | | Refer To: | Customer Setting |
|-------------------------|------------------|---|---|-------------|----------------------------|-----------------|-------|-----------|------------------|
| Stop selection function | 250 | Stop selection | 0 to 100 s, 1000 to 1100 s, 8888, 9999 | | 1 | 9999 | | 147 | |
| Additional function | 251 | Output phase failure protection selection | 0, 1 | | 1 | 1 | | 148 | |
| | 342 | E ² PROM write selection | 0, 1 | | 1 | 0 | | 116 | |
| Calibration functions | 901 | AM terminal calibration | — | | — | — | | 149 | |
| | 902 | Frequency setting voltage bias | 0 to 10V | 0 to 60Hz | 0.01Hz | 0V | 0Hz | 151 | |
| | 903 | Frequency setting voltage gain | 0 to 10V | 1 to 400 Hz | 0.01Hz | 5V | 50 Hz | 151 | |
| | 904 | Frequency setting current bias | 0 to 20 mA | 0 to 60Hz | 0.01Hz | 4 mA | 0Hz | 151 | |
| | 905 | Frequency setting current gain | 0 to 20 mA | 1 to 400 Hz | 0.01Hz | 20 mA | 50 Hz | 151 | |
| | 990 | Parameter for option (FR-PU04). | | | | | | | |
| | 991 | | | | | | | | |

- Note:
1. Indicates the parameter of which setting is ignored when the general-purpose magnetic flux vector control mode is selected.
 2. Since calibration is made before shipment from the factory, the settings differ slightly between inverters. The inverter is preset to provide a frequency slightly higher than 50Hz.
 3. When the control panel is used and the setting is 100Hz or more, the setting increments are 0.1Hz.
The setting increments are 0.01Hz when the communication mode.
 4. The setting depends on the inverter capacity: (0.4K to 3.7K)/(5.5K to 7.5K).
 5. Set to 85% of the rated inverter current for the 0.4K, 0.75K.
 6. If "2" is set in Pr. 77 (parameter write inhibit selection), the setting cannot be changed during operation.
 7. The half-tone screened parameters allow their settings to be changed during operation if "0" (factory setting) has been set in Pr. 77 (parameter write inhibit selection). (However, the Pr. 72 and Pr. 240 values may be changed during PU operation only.)
 8. The setting depends on the inverter capacity: 4% for the FR-E540-5.5K and 7.5K-EC.
 9. To set "10" or "11" in Pr. 73, first "801" must set in Pr. 77.
 10. For the FR-E540-5.5K and 7.5K-EC, the factory setting is 10s.

4.1.2 List of Parameters Classified by Purpose of Use

Set the parameters according to the operating conditions. The following list indicates purpose of use and corresponding parameters.

| Purpose of Use | | Parameter Numbers |
|----------------------------------|--|---|
| | | Parameter numbers which must be set |
| Related to operation | Operation mode selection | Pr. 79 |
| | Acceleration/deceleration time/pattern adjustment | Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 29 |
| | Selection of output characteristics optimum for load characteristics | Pr. 3, Pr. 14, Pr. 19 |
| | Output frequency restriction (limit) | Pr. 1, Pr.2, Pr.18 |
| | Operation over 50Hz | Pr. 1, Pr. 18, Pr. 38, Pr. 39, Pr. 903, Pr. 905 |
| | Adjustment of frequency setting signals and outputs | Pr. 38, Pr. 39, Pr. 73, Pr. 902 to Pr. 905 |
| | Motor output torque adjustment | Pr. 0, Pr. 80 |
| | Brake operation adjustment | Pr. 10, Pr. 11, Pr. 12 |
| | Multi-speed operation | Pr. 1, Pr. 2, Pr. 4, Pr. 5, Pr. 6, Pr. 15, Pr. 24, Pr. 25, Pr. 26, Pr. 27, Pr. 232, Pr. 233, Pr. 234, Pr. 235, Pr. 236, Pr. 237, Pr. 238, Pr. 239 |
| | Jog operation | Pr. 15, Pr. 16 |
| | Frequency jump operation | Pr. 31, Pr. 32, Pr. 33, Pr. 34, Pr. 35, Pr. 36 |
| | Automatic restart operation after instantaneous power failure | Pr. 57, Pr. 58 |
| | Optimum acceleration/deceleration within continuous rated range | Pr. 60 |
| | Slip compensation setting | Pr. 245 to Pr. 247 |
| | Output stop method selection | Pr. 250 |
| Related to application operation | General-purpose magnetic flux vector control operation | Pr. 80 |
| | Electromagnetic brake operation timing | Pr. 42, Pr. 190 to Pr. 192 |
| | Offline auto tuning setting | Pr. 82 to Pr. 84, Pr. 90, Pr. 96 |
| | Sub-motor operation | Pr. 0, Pr. 3, Pr. 7, Pr. 8, Pr. 9, Pr. 44, Pr. 45, Pr. 46, Pr. 47, Pr. 48 |
| | Regenerative function selection | Pr. 30, Pr. 70 |
| | Operation in communication with personal computer | Pr. 117 to Pr. 124, Pr. 342 |
| | Operation under PID control | Pr. 73, Pr. 79, Pr. 128 to Pr. 134, Pr. 180 to Pr. 183, Pr. 190 to Pr. 192 |
| | Noise reduction | Pr. 72, Pr. 240 |

| Purpose of Use | | Parameter Numbers |
|---|---|--|
| | | Parameter numbers which must be set |
| Related to monitoring | Frequency meter calibration | Pr. 55, Pr. 56, Pr. 158, Pr. 901 |
| | Monitor display on control panel (FR-PA02-02) or parameter unit (FR-PU04) | Pr. 55, Pr. 56, Pr. 158, Pr. 901 |
| | Display of speed, etc. | Pr. 37, Pr. 52 |
| | Clearing of inverter's actual operation time | Pr.171 |
| Related to incorrect operation prevention | Function write prevention | Pr. 77 |
| | Reverse rotation prevention | Pr. 78 |
| | Parameter grouping | Pr. 160, Pr. 173 to Pr. 176 |
| | Current detection | Pr. 150 to Pr. 153, Pr. 190 to Pr. 192 |
| | Motor stall prevention | Pr. 22, Pr. 23, Pr. 66, Pr. 156 |
| Others | Input terminal function assignment | Pr. 180 to Pr. 183 |
| | Output terminal function assignment | Pr. 190 to Pr. 192 |
| | Increased cooling fan life | Pr. 244 |
| | Motor protection from overheat | Pr. 9, Pr. 71 |
| | Automatic restart operation at alarm stop | Pr. 65, Pr. 67, Pr. 68, Pr. 69 |
| | Inverter reset selection | Pr. 75 |

4.1.3 Parameters recommended to be set by the user

We recommend the following parameters to be set by the user.

Set them according to the operation specifications, load, etc.

| Parameter Number | Name | Application |
|------------------|--------------------------------|--|
| 1 | Maximum frequency | Used to set the maximum and minimum output frequencies. |
| 2 | Minimum frequency | |
| 7 | Acceleration time | Used to set the acceleration and deceleration times. |
| 8 | Deceleration time | |
| 9 | Electronic thermal O/L relay | Used to set the current of the electronic overcurrent protection to protect the motor from overheat. |
| 14 | Load pattern selection | Used to select the optimum output characteristics which match the application and load characteristics. |
| 71 | Applied motor | Used to set the thermal characteristics of the electronic overcurrent protection according to the motor used. |
| 73 | 0-5V/0-10V selection | Used to select the specifications of the frequency setting signal entered across terminal 2-5 to perform operation with the voltage input signal. |
| 901 | AM terminal calibration | Used to calibrate the meter connected across terminals AM-5. |
| 902 | Frequency setting voltage bias | Used to set the magnitude (slope) of the output frequency relative to the frequency setting signal (0 to 5V, 0 to 10V or 4 to 20mA DC) as desired. |
| 903 | Frequency setting voltage gain | |
| 904 | Frequency setting current bias | |
| 905 | Frequency setting current gain | |

4.2 Parameter Function Details

4.2.1 Torque boost (Pr. 0, Pr. 46)

Pr. 0 "torque boost"

Pr. 46 "second torque boost"


Related parameters

- Pr. 3 "base frequency"
- Pr. 19 "base frequency voltage"
- Pr. 71 "applied motor"
- Pr. 80 "motor capacity"
- Pr. 180 to Pr. 183 (input terminal function selection)

Increase the setting when the inverter-to-motor distance is long or motor torque in the low-speed range is insufficient, for example;

- Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- You can select either of the two starting torque boosts by RT terminal switching.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|----------------|--|
| 0 | 6%/4% (Note) | 0 to 30% | (Note) FR-E520S-0.4K to 2.2K-EC } 6% FR-E540-0.4K to 3.7K-EC } FR-E540-5.5K, 7.5K-EC: 4% |
| 46 | 9999 | 0 to 30%, 9999 | 9999: Function invalid |



<Setting>

- Assuming that the base frequency voltage is 100%, set the 0Hz voltage in %.
- Pr. 46 "Second torque boost" is valid when the RT signal is on. (Note 3)
- When using the inverter-dedicated motor (constant-torque motor), change the setting as indicated below:
 - FR-E540-0.4K, 0.75K-EC, FR-E520S-0.4K, 0.75K-EC.....6%
 - FR-E540-1.5K to 3.7K-EC, FR-E520S-1.5K, 2.2K-EC.....4%
 - FR-E540-5.5K, 7.5K-EC3%

If you leave the factory setting as it is and change the Pr. 71 value to the setting for use of the constant-torque motor, the Pr. 0 setting changes to the above value.

Note: 1. This parameter setting is ignored when the general-purpose magnetic flux vector control mode has been selected.

2. A large setting may result in an overheated motor or overcurrent trip. The guideline for the largest value for this parameter is about 10%.

3. The RT signal serves as the second function selection signal and makes the other second functions valid. Refer to page 142 for Pr. 180 to Pr. 183 (input terminal function selection).

4.2.2 Output frequency range (Pr. 1, Pr. 2, Pr. 18)

Pr. 1 "maximum frequency"

Pr. 2 "minimum frequency"

Pr. 18 "high-speed maximum frequency"


Related parameters

- Pr. 13 "starting frequency"
- Pr. 38 "frequency at 5V (10V) input"
- Pr. 39 "frequency at 20mA input"
- Pr. 79 "operation mode selection"

Used to clamp the upper and lower limits of the output frequency. Used for high-speed operation at or over 120Hz.

- Can be used to set the upper and lower limits of motor speed.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 1 | 120Hz | 0 to 120Hz |
| 2 | 0Hz | 0 to 120Hz |
| 18 | 120Hz | 120 to 400Hz |



<Setting>

- Use Pr. 1 to set the upper limit of the output frequency. If the frequency of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
- To perform operation over 120Hz, set the upper limit of the output frequency in Pr. 18.
(When the Pr. 18 value is set, Pr. 1 automatically changes to the frequency in Pr. 18. Also, when the Pr. 1 value is set, Pr. 18 automatically changes to the frequency in Pr. 1.)
- Use Pr. 2 to set the lower limit of the output frequency.

Note: When the potentiometer (frequency setting potentiometer) connected across terminals 2-5 is used for operation beyond 50Hz, change the value of Pr. 38 (or Pr. 39 for use of the potentiometer connected across terminals 4-5). If the Pr. 1 or Pr. 18 value is only changed, the motor cannot run beyond 50Hz.

⚠ CAUTION

⚠ When the Pr. 2 setting is higher than the Pr. 13 "starting frequency" value, note that the motor will run at the set frequency by merely switching the start signal on, without entering the command frequency.

4.2.3 Base frequency, base frequency voltage (Pr. 3, Pr. 19, Pr. 47)

Pr. 3 "base frequency"

Pr. 19 "base frequency voltage"

Pr. 47 "second V/F (base frequency) "


Related parameters

- Pr. 14 "load pattern selection"
- Pr. 71 "applied motor"
- Pr. 80 "motor capacity"
- Pr. 83 "rated motor voltage"
- Pr. 180 to Pr. 183 (input terminal function selection)

Used to adjust the inverter outputs (voltage, frequency) to the motor rating.

- When running a standard motor, generally set the rated motor frequency. When running the motor using the commercial power supply-inverter switch-over, set the base frequency to the same value as the power supply frequency.
- If the frequency given on the motor rating plate is "50Hz" only, always set to "50Hz". Leaving it as "60Hz" may make the voltage too low and the torque less, resulting in overload tripping. Care must be taken especially when Pr. 14 "load pattern selection" = 1.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|------------------------|---|
| 3 | 50Hz | 0 to 400Hz | |
| 19 | 8888 | 0 to 1000V, 8888, 9999 | 8888: 95% of power supply voltage 9999: Same as power supply voltage |
| 47 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |



<Setting>

- Use Pr. 3 and Pr. 47 to set the base frequency (rated motor frequency). Two base frequencies can be set and the required frequency can be selected from them.
- Pr. 47 "Second V/F (base frequency) " is valid when the RT signal is on. (Note 3)
- Use Pr. 19 to set the base voltage (e.g. rated motor voltage).

Note: 1. Set 60Hz in Pr. 3 "base frequency" when using a Mitsubishi constant-torque motor.

2. When the general-purpose magnetic flux vector control mode has been selected, Pr. 3, Pr. 19 and Pr. 47 are made invalid and Pr. 83 and Pr. 84 are made valid.

3. The RT signal serves as the second function selection signal and makes the other second functions valid. Refer to page 142 for Pr. 180 to Pr. 183 (input terminal function selection).

4.2.4 Multi-speed operation (Pr. 4, Pr. 5, Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)

Pr. 4 "multi-speed setting (high speed)"

Pr. 5 "multi-speed setting (middle speed)"

Pr. 6 "multi-speed setting (low speed)"

Pr. 24 to Pr. 27 "multi-speed setting (speeds 4 to 7)"

Pr. 232 to Pr. 239 "multi-speed setting (speeds 8 to 15)"



Related parameters

- Pr. 1 "maximum frequency"
- Pr. 2 "minimum frequency"
- Pr. 29 "acceleration/deceleration pattern"
- Pr. 79 "operation mode selection"
- Pr. 180 to Pr. 183 (input terminal function selection)

Used to switch between the predetermined running speeds.

- Any speed can be selected by merely switching on/off the corresponding contact signals (RH, RM, RL, REX signals).
- By using these functions with Pr. 1 "maximum frequency" and Pr. 2 "minimum frequency", up to 17 speeds can be set.
- Valid in the external operation mode or combined mode (Pr. 79 = 4).

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|------------------|--------------------|
| 4 | 50Hz | 0 to 400Hz | |
| 5 | 30Hz | 0 to 400Hz | |
| 6 | 10Hz | 0 to 400Hz | |
| 24 to 27 | 9999 | 0 to 400Hz, 9999 | 9999: Not selected |
| 232 to 239 | 9999 | 0 to 400Hz, 9999 | 9999: Not selected |



<Setting>

- Set the running frequencies in the corresponding parameters.
- Each speed (frequency) can be set as desired between 0 and 400Hz during inverter operation.
After the required multi-speed setting parameter has been read, the setting can be changed by pressing the ▲ / ▼ key. In this case, when you release the ▲ / ▼ key, press the SET key (WRITE key when using the parameter unit (FR-PU04)) to store the set frequency.
- Use any of Pr. 180 to Pr. 183 to assign the terminal used to input the REX signal.

- Note: 1. The multi-speed settings override the main speeds (across terminals 2-5, 4-5).
 2. The multi-speeds can also be set in the PU or external operation mode.
 3. For 3-speed setting, if two or three speeds are simultaneously selected, priority is given to the frequency setting of the lower signal.
 4. Pr. 24 to Pr. 27 and Pr. 232 to Pr. 239 settings have no priority between them.
 5. The parameter values can be changed during operation.
 6. When terminal assignment is changed using Pr. 180 to Pr. 183, the other functions may be affected. Check the functions of the corresponding terminals before making setting.

4.2.5 Acceleration/deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45)

Pr. 7 "acceleration time"

Pr. 8 "deceleration time"

Pr. 20 "acceleration/deceleration reference frequency"

Pr. 21 "acceleration/deceleration time increments"

Pr. 44 "second acceleration/deceleration time"


Pr. 45 "second deceleration time"

Related parameters
 Pr. 3 "base frequency"
 Pr. 29 "acceleration/deceleration pattern"

Used to set motor acceleration/deceleration time.
 Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease.

| Parameter Number | Factory Setting | | Setting Range | Remarks |
|------------------|-----------------|-----|--------------------------------|---|
| 7 | 0.4K to 3.7K | 5s | 0 to 3600s/0 to 360s | |
| | 5.5K, 7.5K | 10s | | |
| 8 | 0.4K to 3.7K | 5s | 0 to 3600s/0 to 360s | |
| | 5.5K, 7.5K | 10s | | |
| 20 | 50Hz | | 1 to 400Hz | |
| 21 | 0 | | 0, 1 | 0: 0 to 3600s 1: 0 to 360s |
| 44 | 5s (Note) | | 0 to 3600s/0 to 360s | |
| 45 | 9999 | | 0 to 3600s/ 0 to 360s, 9999 | 9999: acceleration time = deceleration time |

Note: The FR-E540-5.5K-EC and 7.5K-EC are factory-set to 10 s.



<Setting>

- Use Pr. 21 to set the acceleration/deceleration time and minimum setting increments:
 Set value "0" (factory setting).... 0 to 3600 s (minimum setting increments: 0.1 s)
 Set value "1"..... 0 to 360 s (minimum setting increments: 0.01 s)
- Use Pr. 7 and Pr. 44 to set the acceleration time required to reach the frequency set in Pr. 20 from 0Hz.
- Use Pr. 8 and Pr. 45 to set the deceleration time required to reach 0Hz from the frequency set in Pr. 20.
- Pr. 44 and Pr. 45 are valid when the RT signal is on.
- Set "9999" in Pr. 45 to make the deceleration time equal to the acceleration time (Pr. 44).

Note: 1. In S-shaped acceleration/deceleration pattern A (refer to page 82), the set time is the period required to reach the base frequency set in Pr. 3.

- Acceleration/deceleration time calculation expression when the set frequency is the base frequency or higher

$$t = \frac{4}{9} \times \frac{T}{(\text{Pr. 3})^2} \times f^2 + \frac{5}{9} T$$

T: Acceleration/deceleration time setting (s)

f : Set frequency (Hz)

- Guideline for acceleration/deceleration time at the base frequency of 60Hz (0Hz to set frequency)

| Frequency setting (Hz) \ Acceleration/ deceleration time (s) | 60 | 120 | 200 | 400 |
|--|----|-----|-----|-----|
| 5 | 5 | 12 | 27 | 102 |
| 15 | 15 | 35 | 82 | 305 |

2. If the Pr. 20 setting is changed, the settings of calibration functions Pr. 903 and Pr. 905 (frequency setting signal gains) remain unchanged.
 To adjust the gains, adjust calibration functions Pr. 903 and Pr. 905.
3. When the setting of Pr. 7, Pr. 8, Pr. 44 or Pr. 45 is "0", the acceleration/ deceleration time is 0.04 seconds. At this time, set 120Hz or less in Pr. 20.
4. When the RT signal is on, the other second functions such as second torque boost are also selected.
5. If the shortest acceleration/deceleration time is set, the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mechanical system's J (inertia moment) and motor torque.

4.2.6 Electronic overcurrent protection (Pr. 9, Pr. 48)

Pr. 9 "electronic thermal O/L relay"

Pr. 48 "second electronic overcurrent protection"

Related parameter

Pr. 71 "applied motor"
Pr. 180 to Pr. 183
"input terminal function selection"

Set the current of the electronic overcurrent protection to protect the motor from overheat.

This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------------|-----------------|------------------------|
| 9 | Rated output current* | 0 to 500A | |
| 48 | 9999 | 0 to 500A, 9999 | 9999: Function invalid |

*0.4K and 0.75K are set to 85% of the rated inverter current.

<Setting>

- Set the rated current [A] of the motor.
- Setting "0" makes the electronic overcurrent protection (motor protective function) invalid. (The inverter's protective function is valid.)
- When using a Mitsubishi constant-torque motor, first set "1" in Pr. 71 to choose the 100% continuous torque characteristic in the low-speed range. Then, set the rated motor current in Pr. 9.
- Pr. 48 "Second electronic overcurrent protection" is made valid when the RT signal is on. (Note 4)

- Note: 1. When two or more motors are connected to the inverter, they cannot be protected by the electronic overcurrent protection. Install an external thermal relay to each motor.
2. When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic overcurrent protection will be deteriorated. In this case, use an external thermal relay.
3. A special motor cannot be protected by the electronic overcurrent protection. Use an external thermal relay.
4. The RT signal serves as the second function selection signal and makes the other second functions valid. Refer to page 142 for Pr. 180 to Pr. 183 (input terminal function selection).

4.2.7 DC injection brake (Pr. 10 to Pr. 12)


Pr. 10 "DC injection brake operation frequency"

Pr. 11 "DC injection brake operation time"

Pr. 12 "DC injection brake voltage"

By setting the DC injection brake voltage (torque), operation time and operation starting frequency, the stopping accuracy of positioning operation, etc. or the timing of operating the DC injection brake to stop the motor can be adjusted according to the load.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 10 | 3Hz | 0 to 120Hz |
| 11 | 0.5 s | 0 to 10 s |
| 12 | 6% | 0 to 30% |



<Setting>

- Use Pr. 10 to set the frequency at which the DC injection brake operation is started.
- Use Pr. 11 to set the period during when the brake is operated.
- Use Pr. 12 to set the percentage of the power supply voltage.
- When using an inverter-dedicated motor (constant-torque motor), set 6% (factory setting) in Pr. 12.

! CAUTION

! Install a mechanical brake. No holding torque is provided.

4.2.8 Starting frequency (Pr. 13)


Pr. 13 "starting frequency"

Related parameter
Pr. 2 "minimum frequency"

You can set the starting frequency between 0 and 60Hz.


- Set the starting frequency at which the start signal is switched on.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 13 | 0.5Hz | 0 to 60Hz |



Note: The inverter will not start if the frequency setting signal is less than the value set in Pr. 13 "starting frequency".
For example, when 5Hz is set in Pr. 13, the motor will not start running until the frequency setting signal reaches 5Hz.

CAUTION

 **When the Pr. 13 setting is equal to or less than the Pr. 2 value, note that merely switching on the start signal will start the motor at the preset frequency if the command frequency is not input.**

4.2.9 Load pattern selection (Pr. 14)





Pr. 14 "load pattern selection"

Related parameter

- Pr. 0 "torque boost"
- Pr.46 "second torque boost"
- Pr. 80 "motor capacity"
- Pr.180 to Pr.183
(input terminal function selection)

You can select the optimum output characteristic (V/F characteristic) for the application and load characteristics.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 14 | 0 | 0 to 3 |



Note: 1. This parameter setting is ignored when the general-purpose magnetic flux vector control mode has been selected.

2. Pr. 46 "second torque boost" is made valid when the RT signal turns on. The RT signal acts as the second function selection signal and makes the other second functions valid.

Refer to page 142 for Pr. 180 to Pr. 183 (input terminal function selection).

4.2.10 Jog operation (Pr. 15, Pr. 16)

Pr. 15 "jog frequency"

Pr. 16 "jog acceleration/deceleration time"


Related parameters

- Pr. 20 "acceleration/deceleration reference frequency"
- Pr. 21 "acceleration/deceleration time increments"

Jog operation can be started and stopped by selecting the jog mode from the control panel and pressing and releasing the **RUN** key (**FWD**, **REV** key).

- Set the frequency and acceleration/deceleration time for jog operation.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|---------------|-----------------|
| 15 | 5Hz | 0 to 400Hz | |
| 16 | 0.5 s | 0 to 3600 s | When Pr. 21 = 0 |
| | | 0 to 360 s | When Pr. 21 = 1 |



Note: 1. In S-shaped acceleration/deceleration pattern A, the acceleration/deceleration time is the period of time required to reach Pr. 3 "base frequency", not Pr. 20.
 2. The acceleration time and deceleration time cannot be set separately for jog operation.
 3. The value set in Pr. 15 "jog frequency" should be equal to or greater than the Pr. 13 "starting frequency" setting.

Pr. 18 → Refer to Pr. 1, Pr. 2.

Pr. 19 → Refer to Pr. 3.

Pr. 20, Pr. 21 → Refer to Pr. 7, Pr. 8.

4.2.11 Stall prevention (Pr. 22, Pr. 23, Pr. 66)

Pr. 22 "stall prevention operation level"

Pr. 23 "stall prevention operation level compensation factor at double speed"



Related parameters

- Pr. 9 "electronic thermal O/L relay"
- Pr. 48 "second electronic overcurrent protection"
- Pr. 73 "0-5V/0-10V selection"

Pr. 66 "stall prevention operation level reduction starting frequency"

- Set the output current level at which the output frequency is adjusted to prevent the inverter from coming to an alarm stop due to overcurrent etc.
- For high-speed operation at or over the motor base frequency, acceleration may not be made because the motor current does not increase.
To improve the operation characteristics of the motor in such a case, the stall prevention level in the high-frequency range can be reduced. This is effective for operation of a centrifugal separator up to the high-speed range. Normally, set 50Hz in Pr. 66 and 100% in Pr. 23.
- For operation in the high-frequency range, the current in the locked motor state is smaller than the rated output current of the inverter and the inverter does not result in an alarm (protective function is not activated) if the motor is at a stop. To improve this and activate the alarm, the stall prevention level can be reduced.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|--------------------|------------------------------------|
| 22 | 150% | 0 to 200% | |
| 23 | 9999 | 0 to 200%, 9999 | 9999: Constant according to Pr. 22 |
| 66 | 50Hz | 0 to 400Hz | |



<Setting>

- In Pr. 22, set the stall prevention operation level. Normally set it to 150% (factory setting). Set "0" in Pr. 22 to disable the stall prevention operation.
- To reduce the stall prevention operation level in the high-frequency range, set the reduction starting frequency in Pr. 66 and the reduction ratio compensation factor in Pr. 23.

Calculation expression for stall prevention operation level



$$\text{Stall prevention operation level (\%)} = A + B \times \left[\frac{\text{Pr. 22-A}}{\text{Pr. 22-B}} \right] \times \left[\frac{\text{Pr. 23-100}}{100} \right]$$

$$\text{where, } A = \frac{\text{Pr. 66 (Hz)} \times \text{Pr. 22 (\%)}}{\text{output frequency (Hz)}}, \quad B = \frac{\text{Pr. 66 (Hz)} \times \text{Pr. 22 (\%)}}{400\text{Hz}}$$

- By setting "9999" (factory setting) in Pr. 23, the stall prevention operation level is constant at the Pr. 22 setting up to 400Hz.

Note: When the fast-response current limit has been set in Pr. 156 (factory setting has the current limit activated), do not set the Pr. 22 value to 170% or more. Torque will not be developed by doing so.

 **CAUTION**

-  **Do not set a small value as the stall prevention operation current. Otherwise, torque generated will reduce.**
-  **Test operation must be performed.**
 Stall prevention operation during acceleration may increase the acceleration time.
 Stall prevention operation during constant speed may change the speed suddenly.
 Stall prevention operation during deceleration may increase the deceleration time, increasing the deceleration distance.

Pr. 24 to Pr. 27 → Refer to Pr. 4 to Pr. 6.

4.2.12 Acceleration/deceleration pattern (Pr. 29)


Pr. 29 "acceleration/deceleration pattern"

Related parameters

- Pr. 3 "base frequency"
- Pr. 7 "acceleration time"
- Pr. 8 "deceleration time"
- Pr. 20 "acceleration/deceleration reference frequency"
- Pr. 44 "second acceleration/deceleration time"
- Pr. 45 "second deceleration time"

Set the acceleration/deceleration pattern.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 29 | 0 | 0, 1, 2 |



<Setting>

| Pr. 29 Setting | Function | Description |
|----------------|--|---|
| 0 | Linear acceleration/deceleration | Linear acceleration/deceleration is made up/down to the preset frequency (factory setting). |
| 1 | S-shaped acceleration/deceleration A (Note) | For machine tool spindles This setting is used when it is necessary to make acceleration/deceleration in a short time up to the base frequency or higher speed range. In this acceleration/deceleration pattern, fb (base frequency) is always the inflection point of an S shape, and you can set the acceleration/deceleration time according to the reduction in motor torque in the base frequency or higher constant-output operation range. |
| 2 | S-shaped acceleration/deceleration B | For prevention of cargo collapse on conveyor, etc. This setting provides S-shaped acceleration/deceleration from f2 (current frequency) to f1 (target frequency), easing an acceleration/deceleration shock. This pattern has an effect on the prevention of cargo collapse, etc. |

Note: For the acceleration/deceleration time, set the time required to reach the "base frequency" in Pr. 3, not the "acceleration/deceleration reference frequency" in Pr. 20. For details, refer to Pr. 7 and Pr. 8.

4.2.13 Regenerative brake duty (Pr. 30, Pr. 70)

Pr. 30 "regenerative function selection"

Pr. 70 "special regenerative brake duty"

- When making frequent starts/stops, use the optional "brake resistor" to increase the regenerative brake duty.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 30 | 0 | 0,1 |
| 70 | 0% | 0 to 30% |

<Setting>

(1) When using the brake resistor (MRS), brake unit, high power factor converter

- Set "0" in Pr. 30.
- The Pr. 70 setting is made invalid.

(2) When using the brake resistors (2 MYs in parallel) (3.7K is only allowed)

- Set "1" in Pr. 30.
- Set "6%" in Pr. 70.


(3) When using the high-duty brake resistor (FR-ABR)

- Set "1" in Pr. 30.
- Set "10%" in Pr. 70.

Note: 1. Pr. 70 "regenerative brake duty" indicates the %ED of the built-in brake transistor operation. The setting should not be higher than the permissible value of the brake resistor used. Otherwise, the resistor can overheat.

2. When Pr. 30 = "0", Pr. 70 is not displayed but the brake duty is fixed at 3%. (Fixed at 2% for 5.5K, 7.5K)

WARNING

 The value set in Pr. 70 should not exceed the value set to the brake resistor used.
Otherwise, the resistor can overheat.

4.2.14 Frequency jump (Pr. 31 to Pr. 36)

Pr. 31 "frequency jump 1A"

Pr. 32 "frequency jump 1B"

Pr. 33 "frequency jump 2A"


Pr. 34 "frequency jump 2B"

Pr. 35 "frequency jump 3A"

Pr. 36 "frequency jump 3B"



- When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped. Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The value set to 1A, 2A or 3A is a jump point and operation is performed at this frequency.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|------------------|------------------------|
| 31 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |
| 32 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |
| 33 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |
| 34 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |
| 35 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |
| 36 | 9999 | 0 to 400Hz, 9999 | 9999: Function invalid |



<Setting>

- To fix the frequency at 30Hz between Pr. 33 and Pr. 34 (30Hz and 35Hz), set 35Hz in Pr. 34 and 30Hz in Pr. 33.
- To jump to 35Hz between 30 and 35Hz, set 35Hz in Pr. 33 and 30Hz in Pr. 34.



Note: During acceleration/deceleration, the running frequency within the set area is valid.

4.2.15 Speed display (Pr. 37)

Pr. 37 "speed display"

Related parameter

Pr. 52 "control panel/PU main display data selection"

The unit of the output frequency display of the control panel (FR-PA02-02) and PU (FR-PU04) can be changed from the frequency to the motor speed or machine speed.


| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|-----------------|---------------------|
| 37 | 0 | 0, 0.01 to 9998 | 0: Output frequency |

<Setting>

- To display the machine speed, set in Pr. 37 the machine speed for 60Hz operation.

Note: 1. The motor speed is converted into the output frequency and does not match the actual speed.
 2. To change the control panel monitor (PU main display), refer to Pr. 52.
 3. As the control panel display is 4 digits, "----" is displayed when the monitored value exceeds "9999".
 4. Only the PU monitor display uses the unit set in this parameter. Set the other speed-related parameters (e.g. Pr. 1) in the frequency unit.
 5. Due to the restrictions of the resolution of the set frequency, the displayed value may be different from the setting for the second decimal place.

CAUTION

 **Make sure that the running speed setting is correct.**
 Otherwise, the motor might run at extremely high speed, damaging the machine.


4.2.16 Frequency at 5V (10V) input (Pr. 38)

Pr. 38 "frequency at 5V (10V) input"

Related parameters

- Pr. 73 "0-5V/0-10V selection"
- Pr. 79 "operation mode selection"
- Pr. 902 "frequency setting voltage bias"
- Pr. 903 "frequency setting voltage gain"

- You can set the frequency provided when the frequency setting signal from the potentiometer connected across terminals 2-5 (frequency setting potentiometer) is 5VDC (or 10VDC).



| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 38 | 50Hz | 1 to 400Hz |


4.2.17 Frequency at 20mA input (Pr. 39)

Pr. 39 "frequency at 20mA input"

Related parameters

- Pr. 73 "0-5V/0-10V selection"
- Pr. 79 "operation mode selection"
- Pr. 904 "frequency setting current bias"
- Pr. 905 "frequency setting current gain"

- You can set the frequency provided when the frequency setting signal input across terminals 4-5 is 20mA.



| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 39 | 50Hz | 1 to 400Hz |

4.2.18 Up-to-frequency sensitivity (Pr. 41)

Pr. 41 "up-to-frequency sensitivity"


Related parameters

Pr. 190 "RUN terminal function selection"
Pr. 191 "FU terminal function selection"
Pr. 192 "A, B, C terminal function selection"

The ON range of the up-to-frequency signal (SU) output when the output frequency reaches the running frequency can be adjusted between 0 and $\pm 100\%$ of the running frequency.

This parameter can be used to ensure that the running frequency has been reached or used as the operation start signal etc. for related equipment.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 41 | 10% | 0 to 100% |



- Use any of Pr. 190 to Pr. 192 to allocate the terminal used for SU signal output. Refer to page 144 for Pr. 190 to Pr. 192 (output terminal function selection).

Note: When terminal assignment is changed using Pr. 190 to Pr. 192, the other functions may be affected. Check the functions of the corresponding terminals before making settings.

4.2.19 Output frequency detection (Pr. 42, Pr. 43)

Pr. 42 "output frequency detection"

Pr. 43 "output frequency detection for reverse rotation"

Related parameters

- Pr. 190 "RUN terminal function selection"
- Pr. 191 "FU terminal function selection"
- Pr. 192 "A, B, C terminal function selection"

The output frequency detection signal (FU) is output when the output frequency reaches or exceeds the setting. This function can be used for electromagnetic brake operation, open signal etc.

- You can also set the detection of the frequency used exclusively for reverse rotation. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during vertical lift operation etc.


| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|------------------|------------------------------|
| 42 | 6Hz | 0 to 400Hz | |
| 43 | 9999 | 0 to 400Hz, 9999 | 9999: Same as Pr. 42 setting |

<Setting>

Refer to the figure below and set the corresponding parameters:

- When Pr. 43 ≠ 9999, the Pr. 42 setting applies to forward rotation and the Pr. 43 setting applies to reverse rotation.
- Assign the terminal used for FU signal output with any of Pr. 190 to Pr. 192 (output terminal function selection).

Refer to page 144 for Pr. 190 to Pr. 192 (output terminal function selection).



Note: Changing the terminal assignment using Pr. 190 to Pr. 192 may affect the other functions. Make setting after confirming the function of each terminal.

Pr. 44, Pr. 45 → Refer to Pr. 7.

Pr. 46 → Refer to Pr. 0.

Pr. 47 → Refer to Pr. 3.

Pr. 48 → Refer to Pr. 9

4.2.20 Monitor display (Pr. 52, Pr. 158)

**Pr. 52 "control panel/PU main display
data selection"**

Pr. 158 "AM terminal function selection"

Related parameters

Pr. 37 "speed display"
Pr. 55 "frequency monitoring
reference"
Pr. 56 "current monitoring
reference"
Pr. 171 "actual operation hour
meter clear"
Pr. 901 "AM terminal calibration"

You can select the signals shown on the control panel (FR-PA02-02) /parameter unit (FR-PU04) main display screen and the signal output to the AM terminal.

- The analog output terminal AM is provided for signal output. Select the signal using Pr. 158.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 52 | 0 | 0, 23, 100 |
| 158 | 0 | 0, 1, 2 |

<Setting>

Set Pr. 52 and Pr. 158 in accordance with the following table:

| Signal Type | Unit | Parameter Setting | | | Full-Scale Value of AM Level Meter |
|-----------------------|------|-------------------|-----------------|-------------|------------------------------------|
| | | Pr. 52 | | Pr. 158 | |
| | | Control panel LED | PU main monitor | AM terminal | |
| Output frequency | Hz | 0/100 | 0/100 | 0 | Pr. 55 |
| Output current | A | 0/100 | 0/100 | 1 | Pr. 56 |
| Output voltage | — | 0/100 | 0/100 | 2 | 400V or 800V |
| Alarm display | — | 0/100 | 0/100 | × | — |
| Actual operation time | 10h | 23 | 23 | × | — |

When 100 is set in Pr. 52, the monitored values during stop and during operation differ as indicated below:

| | Pr. 52 | | |
|------------------|------------------------------|---------------|------------------|
| | 0 | 100 | |
| | During operation/during stop | During stop | During operation |
| Output frequency | Output frequency | Set frequency | Output frequency |
| Output current | Output current | | |
| Output voltage | Output voltage | | |
| Alarm display | Alarm display | | |

- Note: 1. During an error, the output frequency at error occurrence is displayed.
 2. During MRS, the values are the same as during a stop.
 During offline auto tuning, the tuning status monitor has priority.

- Note: 1. The monitoring of items marked × cannot be selected.
 2. By setting "0" in Pr. 52, the monitoring of "output frequency to alarm display" can be selected in sequence by the SHIFT key.
 3. Running speed on the PU main monitor is selected by "other monitor selection" of the parameter unit (FR-PU04).
 4. The actual operation time displayed by setting "23" in Pr. 52 is calculated using the inverter operation time. (Inverter stop time is not included.) Set "0" in Pr. 171 to clear it.
 5. The actual operation time is calculated from 0 to 99990 hours, then cleared, and recalculated from 0. If the operation time is less than 10 hours there is no display.
 6. The actual operation time is not calculated if the inverter has not operated for more than 1 hour continuously.
 7. When the control panel is used, the display unit is Hz or A only.

4.2.21 Monitoring reference (Pr. 55, Pr. 56)

Pr. 55 "frequency monitoring reference"

Pr. 56 "current monitoring reference"



Related parameters

Pr. 158 "AM terminal function selection"

Pr. 901 "AM terminal calibration"

Set the frequency or current which is referenced when the output frequency or output current is selected for the AM terminal.

| Parameter Number | Factory Setting | Setting Range |
|------------------|----------------------|---------------|
| 55 | 50Hz | 0 to 400Hz |
| 56 | Rated output current | 0 to 500A |



<Setting>

Refer to the above diagrams and set the frequency monitoring reference value in Pr. 55 and the current monitoring reference value in Pr. 56.

Pr. 55 is set when Pr. 158 = 0 and Pr. 56 is set when Pr. 158 = 1.

In Pr. 55 and Pr. 56, set the frequency and current at which the output voltage of terminal AM will be 10V.

Note: The maximum output voltage of terminal AM is 10VDC.

4.2.22 Automatic restart after instantaneous power failure (Pr. 57, Pr. 58)

Pr. 57 "restart coasting time"

Pr. 58 "restart cushion time"


- You can restart the inverter without stopping the motor (with the motor coasting) when power is restored after an instantaneous power failure.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|----------------|------------------|
| 57 | 9999 | 0 to 5 s, 9999 | 9999: No restart |
| 58 | 1.0 s | 0 to 60 s | |

<Setting>


Refer to the following table and set the parameters:

| Parameter Number | Setting | Description |
|------------------|------------|---|
| 57 | 0 | 0.4K to 1.5K 2.2K to 7.5K |
| | 0.1 to 5 s | 0.5 s coasting time 1.0 s coasting time |
| | 9999 | Generally use this setting. Waiting time for inverter-triggered restart after power is restored from an instantaneous power failure. (Set this time between 0.1 s and 5 s according to the inertia moment (J) and torque of the load.) |
| | 9999 | No restart |
| 58 | 0 to 60 s | Normally the inverter may be run with the factory settings. These values are adjustable to the load (inertia moment, torque). |



- Note: 1. Automatic restart after instantaneous power failure uses a reduced-voltage starting system in which the output voltage is raised gradually with the preset frequency unchanged, independently of the coasting speed of the motor. As in the FR-A024S/A044, a motor coasting speed detection system (speed search system) is not used but the output frequency before an instantaneous power failure is output. Therefore, if the instantaneous power failure time is longer than 0.2 s, the frequency before the instantaneous power failure cannot be stored and the inverter will start at 0Hz.
2. The SU and FU signals are not output during restart but are output after the restart cushion time has elapsed.

! CAUTION

- ! When automatic restart after instantaneous power failure has been selected, the motor and machine will start suddenly (after the reset time has elapsed) after occurrence of an instantaneous power failure. Stay away from the motor and machine. When you have selected automatic restart after instantaneous power failure, apply the supplied CAUTION seals in easily visible places.**
- ! When the start signal is turned off or the  key is pressed during the cushion time for automatic restart after instantaneous power failure, deceleration starts after the automatic restart cushion time set in Pr. 58 "cushion time for automatic restart after instantaneous power failure" has elapsed.**

4.2.23 Remote setting function selection (Pr. 59)

Pr. 59 "remote setting function selection"


If the operator panel is located away from the control box, you can use contact signals to perform continuous variable-speed operation, without using analog signals.

- By merely setting this parameter, you can use the acceleration, deceleration and setting clear functions of the motorized speed setter (FR-FK).
- When the remote function is used, the output frequency of the inverter can be compensated for as follows:
 External operation mode Frequency set by RH/RM operation plus built-in frequency setting potentiometer or external analog frequency command
 PU operation mode Frequency set by RH/RM operation plus PU's digitally-set frequency

Related parameters

- Pr. 1 "maximum frequency"
- Pr. 7 "acceleration time"
- Pr. 8 "deceleration time"
- Pr. 18 "high-speed maximum frequency"
- Pr. 44 "second acceleration/ deceleration time"
- Pr. 45 "second deceleration time"

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 59 | 0 | 0, 1, 2 |



Note: External operation frequency or PU operation frequency other than multi-speed

| Pr. 59 Setting | Operation | |
|----------------|-------------------------|--|
| | Remote setting function | Frequency setting storage function (E ² PROM) |
| 0 | No | — |
| 1 | Yes | Yes |
| 2 | Yes | No |

- Use Pr. 59 to select whether the remote setting function is used or not and whether the frequency setting storage function* in the remote setting mode is used or not. When "remote setting function - yes" is selected, the functions of signals RH, RM and RL are changed to acceleration (RH), deceleration (RM) and clear (RL). Use Pr. 180 to Pr. 183 (input terminal function selection) to set signals RH, RM and RL.

* Frequency setting storage function

The remote setting frequency (frequency set by RH, RM operation) is stored into memory. When power is switched off once, then on again, operation is resumed at this setting of the output frequency. (Pr. 59=1)


<Frequency setting storage condition>

- Frequency at the time when the start signal (STF or STR) has switched off
- Frequency at the time when the RH (acceleration) and RM (deceleration) signals have remained off for more than 1 minute

Note: 1. The frequency can be varied by RH (acceleration) and RM (deceleration) between 0 and the maximum frequency (Pr. 1 or Pr. 18 setting).
 2. When the acceleration or deceleration signal switches on, the set frequency varies according to the slope set in Pr. 44 or Pr. 45. The output frequency acceleration/deceleration times are as set in Pr. 7 and Pr. 8, respectively. Therefore, the longer preset times are used to vary the actual output frequency.
 3. If the start signal (STF or STR) is off, turning on the acceleration (RH) or deceleration (RM) signal varies the set frequency.

REMARKS

A restart (STF signal ON) after ON-OFF of the clear signal (RL) should be made after more than 1 minute has elapsed. The output frequency provided when a restart is made within 1 minute is the output frequency given after the clear signal (RL) is turned off (multi-speed frequency).



(*1) External operation frequency or PU operation frequency except multi-speed
 (*2) Multi-speed frequency

! CAUTION

! When selecting this function, re-set the maximum frequency according to the machine.

4.2.24 Shortest acceleration/deceleration mode (Pr. 60 to Pr. 63)

Pr. 60 "shortest acceleration/deceleration mode"

Pr. 61 "reference I for intelligent mode"

Pr. 62 "ref. I for intelligent mode accel"

Pr. 63 "ref. I for intelligent mode decel"

Related parameters

Pr. 7 "acceleration time"
Pr. 8 "deceleration time"

The inverter automatically sets appropriate parameters for operation.

- If you do not set the acceleration and deceleration times and V/F pattern, you can run the inverter as if appropriate values had been set in the corresponding parameters. This operation mode is useful to start operation immediately without making fine parameter settings.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|-----------------|---|
| 60 | 0 | 0, 1, 2, 11, 12 | |
| 61 | 9999 | 0 to 500A, 9999 | 9999: Referenced from rated inverter current. |
| 62 | 9999 | 0 to 200%, 9999 | |
| 63 | 9999 | 0 to 200%, 9999 | |

< Setting >

| Pr. 60 Setting | Operation Mode | Description | Automatically Set Parameters |
|----------------|---|--|------------------------------|
| 0 | Ordinary operation mode | _____ | _____ |
| 1, 2, 11, 12 | Shortest acceleration/deceleration mode | Set to accelerate/decelerate the motor in the shortest time. The inverter makes acceleration/deceleration in the shortest time using its full capabilities. During deceleration, an insufficient brake capability may cause the regenerative overvoltage alarm (E.OV3). "1" : Stall prevention operation level 150% "2" : Stall prevention operation level 180% "11": Stall prevention operation level 150% when brake resistor or brake unit is used "12": Stall prevention operation level 180% when brake resistor or brake unit is used | Pr. 7, Pr. 8 |

<Setting>

- Set the parameters when it is desired to improve the performance in the shortest acceleration/deceleration mode.

(1) Pr. 61 "reference I for intelligent mode"

| Setting | Reference Current |
|------------------------|---|
| 9999 (factory setting) | Referenced from rated inverter current |
| 0 to 500A | Referenced from setting (rated motor current) |

(2) Pr. 62 "ref. I for intelligent mode accel"

The reference current setting can be changed.

| Setting | Reference Current |
|------------------------|--|
| 9999 (factory setting) | 150% (180%) is the limit value. |
| 0 to 200% | The setting of 0 to 200% is the limit value. |

(3) Pr. 63 "ref. I for intelligent mode decel"

The reference current setting can be changed.

| Setting | Reference Current |
|------------------------|--|
| 9999 (factory setting) | 150% (180%) is the limit value. |
| 0 to 200% | The setting of 0 to 200% is the limit value. |

Note: Pr. 61 to Pr. 63 are only valid when any of "1, 2, 11, 12" are selected for Pr. 60.

4.2.25 Retry function (Pr. 65, Pr. 67 to Pr. 69)

Pr. 65 "retry selection"

Pr. 67 "number of retries at alarm occurrence"

Pr. 68 "retry waiting time"

Pr. 69 "retry count display erasure"

When any protective function (major fault) is activated and the inverter stops its output, the inverter itself resets automatically and performs retries. You can select whether retry is made or not, alarms reset for retry, number of retries made, and waiting time.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------------|
| 65 | 0 | 0 to 3 |
| 67 | 0 | 0 to 10, 101 to 110 |
| 68 | 1 s | 0.1 to 360 s |
| 69 | 0 | 0 |

<Setting>

Use Pr. 65 to select the protective functions (major faults) which execute retry.

| Errors Reset for Retry | Setting | | | |
|------------------------|---------|---|---|---|
| | 0 | 1 | 2 | 3 |
| Display | | | | |
| E.OC1 | ● | ● | | ● |
| E.OC2 | ● | ● | | ● |
| E.OC3 | ● | ● | | ● |
| E.OV1 | ● | | ● | ● |
| E.OV2 | ● | | ● | ● |
| E.OV3 | ● | | ● | ● |
| E.THM | ● | | | |
| E.THT | ● | | | |
| E.FIN | | | | |
| E. BE | ● | | | |
| E. GF | ● | | | |
| E. LF | | | | |
| E.OHT | ● | | | |
| E.OLT | ● | | | |
| E.OPT | ● | | | |
| E. PE | ● | | | |
| E.PUE | | | | |
| E.RET | | | | |
| E.CPU | | | | |
| E. 6 | | | | |
| E. 7 | | | | |

Note: ● indicates the retry items selected.

Use Pr. 67 to set the number of retries at alarm occurrence.

| Pr. 67 Setting | Number of Retries | Alarm Signal Output |
|----------------|--------------------|---------------------|
| 0 | Retry is not made. | ————— |
| 1 to 10 | 1 to 10 times | Not output. |
| 101 to 110 | 1 to 10 times | Output. |

- Use Pr. 68 to set the waiting time from when an inverter alarm occurs until a restart in the range 0.1 to 360 seconds.
- Reading the Pr. 69 value provides the cumulative number of successful restart times made by retry. The setting of "0" erases the cumulative number of times.

Note: 1. The cumulative number in Pr. 69 is incremented by "1" when retry operation is regarded as successful, i.e. when normal operation is continued without the protective function (major fault) activated during a period five times longer than the time set in Pr. 68.

2. If the protective function (major fault) is activated consecutively within a period five times longer than the above waiting time, the control panel may show data different from the most recent data or the parameter unit (FR-PU04) may show data different from the first retry data. The data stored as the error reset for retry is only that of the protective function (major fault) which was activated the first time.

3. When an inverter alarm is reset by the retry function at the retry time, the stored data of the electronic over current protection, etc. are not cleared. (Different from the power-on reset.)

⚠ CAUTION

⚠ When you have selected the retry function, stay away from the motor and machine unless required. They will start suddenly (after the reset time has elapsed) after occurrence of an alarm.
When you have selected the retry function, apply the supplied CAUTION seals in easily visible places.

Pr. 66 → Refer to Pr. 22.

Pr. 70 → Refer to Pr. 30.

4.2.26 Applied motor (Pr. 71)

Pr. 71 "applied motor"

Related parameters

- Pr. 0 "torque boost"
- Pr. 12 "DC injection brake voltage"
- Pr. 19 "base frequency voltage"
- Pr. 80 "motor capacity"
- Pr. 96 "auto-tuning setting/status"

Set the motor used.

- When using the Mitsubishi constant-torque motor, set "1" in Pr. 71 for either V/F control or general-purpose magnetic flux vector control.
The electronic overcurrent protection is set to the thermal characteristic of the constant-torque motor.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|--|
| 71 | 0 | 0, 1, 3, 5, 6, 13, 15, 16, 23, 100, 101, 103, 105, 106, 113, 115, 116, 123 |

<Setting>

- Refer to the following list and set this parameter according to the motor used.

| Pr. 71 Setting | Thermal Characteristics of Electronic Overcurrent Protection | | Applied motor | |
|----------------|---|---------------------------------------|--|-----------------|
| | | | Standard | Constant-Torque |
| 0, 100 | Thermal characteristics matching a standard motor | | ○ | |
| 1, 101 | Thermal characteristics matching the Mitsubishi constant-torque motor | | | ○ |
| 3, 103 | Standard motor | Select "offline auto tuning setting". | ○ | |
| 13, 113 | Constant-torque motor | | | ○ |
| 23, 123 | Mitsubishi general-purpose motor SF-JR4P (1.5kW or less) | | ○ | |
| 5, 105 | Standard motor | Star connection | Motor constants can be entered directly. | ○ |
| 15, 115 | Constant-torque motor | | | |
| 6, 106 | Standard motor | Delta connection | | ○ |
| 16, 116 | Constant-torque motor | | | |

By setting any of "100 to 123", the electronic overcurrent protection thermal characteristic (applied motor) can be changed as indicated below according to the ON/OFF status of the RT signal:

| RT Signal | Electronic Overcurrent Protection Thermal Characteristic (Applied Motor) |
|-----------|--|
| OFF | As indicated in the above table |
| ON | Constant-torque motor |

⚠ CAUTION

⚠ Set this parameter correctly according to the motor used. Incorrect setting may cause the motor to overheat and burn.

4.2.27 PWM carrier frequency (Pr. 72, Pr. 240)

Pr. 72 "PWM frequency selection"

Pr. 240 "Soft-PWM setting"

You can change the motor tone.

- By parameter setting, you can select Soft-PWM control which changes the motor tone.
- Soft-PWM control changes motor noise from a metallic tone into an unoffending complex tone.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|---------------|-----------------------------|
| 72 | 1 | 0 to 15 | 0 : 0.7kHz, 15 : 14.5kHz |
| 240 | 1 | 0, 1 | 1: Soft-PWM valid |

<Setting>

- Refer to the following list and set the parameters:

| Parameter Number | Setting | Description |
|------------------|---------|---|
| 72 | 0 to 15 | PWM carrier frequency can be changed. The setting displayed is in [kHz]. Note that 0 indicates 0.7kHz and 15 indicates 14.5kHz. |
| 240 | 0 | Soft-PWM invalid |
| | 1 | When any of "0 to 5" is set in Pr. 72, Soft-PWM is made valid. |

Note: 1. Note that when the inverter is run at the ambient temperature above 40°C with a 2kHz or higher value set in Pr. 72, the rated output current of the inverter must be reduced. (Refer to page 180 (depending upon the inverter.)
2. An increased PWM frequency will decrease motor noise but noise and leakage current will increase. Take proper action (refer to pages 32 to 37).

4.2.28 Voltage input (Pr. 73)

Pr. 73 "0-5V/0-10V selection"

Related parameters

Pr. 22 "stall prevention operation level"
Pr. 38 "frequency at 5V (10V) input"

- You can change the input (terminal 2) specifications in response to the frequency setting voltage signal. When entering 0 to 10VDC, always make this setting.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------------|
| 73 | 0 | 0, 1, 10, 11 (Note) |


Note: To set "10" or "11" in Pr. 73, first "801" must be set in Pr. 77.

| Setting | Terminal 2 Input Voltage | Polarity Reversible |
|---------|---------------------------------------|---------------------|
| 0 | For 0 to 5VDC input (factory setting) | No |
| 1 | For 0 to 10VDC input | |
| 10 | For 0 to 5VDC input | Valid |
| 11 | For 0 to 10VDC input | |

Note: 1. To change the maximum output frequency at the input of the maximum frequency command voltage, use Pr. 38. Also, the acceleration/deceleration time, which is a slope up/down to the acceleration/deceleration reference frequency, is not affected by the change in Pr. 73 setting.
2. When connecting a frequency setting potentiometer across terminals 10-2-5 for operation, always set "0" in this parameter.

- Polarity reversible operation**
By changing the input voltage, you can switch between forward rotation and reverse rotation. Set "801" in Pr. 77 and "10" or "11" in Pr. 73 to make this function valid.

- Set the output frequency using Pr. 902 "frequency setting voltage bias" and Pr. 903 "frequency setting voltage gain". The output frequency is 0Hz at the factory-set input voltage of 2.5V (5V).
- When Pr. 73 = "10" as factory-set, Pr. 902 = 2.5V. When Pr. 73 = "11", Pr. 902 = 5V.



Note: To calibrate the input voltage value at 0Hz, use Pr. 902 "frequency setting voltage bias".

⚡ WARNING

⚠ Do not design the wiring and facility which will make the voltage lower than the Pr. 902 setting suddenly.
Doing so can cause the inverter to provide reverse rotation output if the analog signal wiring is disconnected or the speed command analog signal turns to 0V, resulting in hazardous conditions.

4.2.29 Input filter time constant (Pr. 74)

Pr. 74 "filter time constant"

You can set the input section's internal filter constant for an external voltage or current frequency setting signal.


- Effective for eliminating noise in the frequency setting circuit.
- Increase the filter time constant if steady operation cannot be performed due to noise. A larger setting results in slower response. (The time constant can be set between approximately 1ms to 1s with the setting of 0 to 8. A larger setting results in a larger filter time constant.)

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 74 | 1 | 0 to 8 |

4.2.30 Reset selection/disconnected PU detection/PU stop selection (Pr. 75)





Pr. 75 "reset selection/disconnected PU detection/PU stop selection"

You can select the reset input acceptance, control panel (FR-PA02-02) or PU (FR-PU04) connector disconnection detection function and PU stop function.

- Reset selection : You can select the reset function input timing.
- PU disconnection detection : When it is detected that the control panel (FR-PA02-02) /PU (FR-PU04) is disconnected from the inverter for more than 1 second, the inverter outputs an alarm code (E.PUE) and comes to an alarm stop.
- PU stop selection : When an alarm occurs in any operation mode, you can stop the inverter from the PU by pressing the  key.


| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|------------------|
| 75 | 14 | 0 to 3, 14 to 17 |



<Setting>

| Pr. 75 Setting | Reset Selection | PU Disconnection Detection | PU Stop Selection |
|----------------|---|---|---|
| 0 | Reset input normally enabled. | If the PU is disconnected, operation will be continued. | Pressing the  key decelerates the inverter to a stop only in the PU operation mode. |
| 1 | Reset input enabled only when the protective function is activated. | | |
| 2 | Reset input normally enabled. | When the PU is disconnected, an error is displayed on the PU and the inverter output is shut off. | Pressing the  key decelerates the inverter to a stop in any of the PU, external and communication operation modes. |
| 3 | Reset input enabled only when the protective function is activated. | | |
| 14 | Reset input normally enabled. | If the PU is disconnected, operation will be continued. | Pressing the  key decelerates the inverter to a stop in any of the PU, external and communication operation modes. |
| 15 | Reset input enabled only when the protective function is activated. | | |
| 16 | Reset input normally enabled. | When the PU is disconnected, an error is displayed on the PU and the inverter output is shut off. | Pressing the  key decelerates the inverter to a stop in any of the PU, external and communication operation modes. |
| 17 | Reset input enabled only when the protective function is activated. | | |


How to make a restart after a stop by the  key on the PU

(1) Control panel (FR-PA02-02)


- 1) After completion of deceleration to a stop, switch off the STF or STR signal.
- 2) Press the  key two times* to display *OPnd*.


Note: When Pr. 79 = 3, press the  key three times to display *PU*. Then, press the  key and proceed to step 3).

(For the monitor screen) Refer to page 50 for the monitor display provided by pressing the  key.

- 3) Press the  key.
- 4) Switch on the STF or STR signal.

(2) Parameter unit (FR-PU04)

- 1) After completion of deceleration to a stop, switch off the STF or STR signal.
- 2) Press the  key.
- 3) Switch on the STF or STR signal.



Stop and restart example for external operation

The other way of making a restart other than the above method is to perform a power-reset or to make a reset with the inverter reset terminal.

Note: 1. By entering the reset signal (RES) during operation, the inverter shuts off output while it is reset, the data of the electronic overcurrent protection and regenerative brake duty are reset, and the motor coasts.

2. The PU disconnection detection function judges that the PU is disconnected when it is removed from the inverter for more than 1 second. If the PU had been disconnected before power-on, it is not judged as an alarm.

3. To resume operation, reset the inverter after confirming that the PU is connected securely.

4. The Pr. 75 value can be set any time. Also, if parameter (all) clear is executed, this setting will not return to the initial value.

5. When the inverter is stopped by the PU stop function, PS is displayed but an alarm is not output.

When the PU connector is used for RS-485 communication operation, the reset selection and PU stop selection functions are valid but the PU disconnection detection function is invalid.

⚠ CAUTION

⚠ Do not reset the inverter with the start signal on. Otherwise, the motor will start instantly after resetting, leading to potentially hazardous conditions.

4.2.31 Parameter write inhibit selection (Pr. 77)

Related parameters

Pr. 77 "parameter write disable selection"

Pr. 79 "operation mode selection"

You can select between write-enable and disable for parameters. This function is used to prevent parameter values from being rewritten by incorrect operation.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 77 | 0 | 0, 1, 2 |

<Setting>

| Pr. 77 Setting | Function |
|----------------|---|
| 0 | Parameter values may only be written during a stop in the PU operation mode. (Note 1) |
| 1 | Write disabled. Values of Pr. 22, Pr. 75, Pr. 77 and Pr. 79 "operation mode selection" can be written. |
| 2 | Write enabled even during operation. |

- Note: 1. The parameters half-tone screened in the parameter list can be set at any time.
- If Pr. 77 = "2", the values of Pr. 23, Pr. 66, Pr. 71, Pr. 79, Pr. 80, Pr. 83, Pr. 84, Pr. 96, Pr. 180 to Pr. 183 and Pr. 190 to Pr. 192 cannot be written during operation. Stop operation when changing their parameter settings.
 - By setting "1" in Pr. 77, the following clear operations can be inhibited:
 - Parameter clear
 - All clear

4.2.32 Reverse rotation prevention selection (Pr. 78)

Pr. 78 "reverse rotation prevention selection"

Related parameters

Pr. 79 "operation mode selection"

This function can prevent any reverse rotation fault resulting from the incorrect input of the start signal.

- Used for a machine which runs only in one direction, e.g. fan, pump.
(The setting of this function is valid for the combined, PU, external and communication operations.)

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 78 | 0 | 0, 1, 2 |

<Setting>

| Pr. 78 Setting | Function |
|----------------|--|
| 0 | Both forward and reverse rotations allowed |
| 1 | Reverse rotation disallowed |
| 2 | Forward rotation disallowed |

4.2.33 Operation mode selection (Pr. 79)

Pr. 79 "operation mode selection"

Used to select the operation mode of the inverter. The inverter can be run from the control panel or parameter unit (PU operation), with external signals (external operation), or by combination of PU operation and external operation (external/PU combined operation).

When power is switched on (factory setting), the external operation mode is selected.


Related parameters
 Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239
 "multi-speed operation"
 Pr. 180 to Pr. 183
 (input terminal function selection)

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|----------------|
| 79 | 0 | 0 to 4, 6 to 8 |

<Setting>

In the following table, operation using the control panel or parameter unit is abbreviated to PU operation.

| Pr. 79 Setting | Function | | |
|----------------|---|---|---|
| 0 | When power is switched on, the external operation mode is selected. PU or external operation can be selected by pressing the keys of the control panel or parameter unit. (Refer to page 53) For these modes, refer to the setting 1 and 2 below. | | |
| | Operation mode | Running frequency | Start signal |
| 1 | PU operation mode | Digital setting made by the key operation of the control panel or parameter unit | (,) key of control panel or or key of parameter unit |
| 2 | External operation mode | External signal input (across terminals 2 (4)-5, multi-speed selection) | External signal input (terminal STF, STR) |
| 3 | External/PU combined operation mode 1 | Digital setting made by the key operation of the control panel or parameter unit, or external signal input (multi-speed setting only) | External signal input (terminal STF, STR) |
| 4 | External/PU combined operation mode 2 | External signal input (across terminals 2 (4)-5, multi-speed selection) | (,) key of control panel or or key of parameter unit |
| 6 | Switch-over mode Switch-over between PU and external operation modes can be done while running. | | |
| 7 | External operation mode (PU operation interlock) MRS signal ON Able to be switched to PU operation mode (output stop during external operation) MRS signal OFF Switching to PU operation mode inhibited | | |
| 8 | Switching to other than external operation mode (disallowed during operation) X16 signal ON..... Switched to external operation mode X16 signal OFF Switched to PU operation mode | | |



Note: Either "3" or "4" may be set to select the PU/external combined operation. These settings differ in starting method.

(1) Switch-over mode

During operation, you can change the current operation mode to another operation mode.

| Operation Mode Switching | Switching Control/Operating Status |
|------------------------------------|---|
| External operation to PU operation | 1) Operate the control panel keys to select the PU operation mode. <ul style="list-style-type: none"> • Rotation direction is the same as that of external operation. • Set frequency is the same as the external frequency setting signal value. (Note that the setting will disappear when power is switched off or the inverter is reset.) |
| PU operation to external operation | 1) Operate the control panel keys to select the external operation mode. <ul style="list-style-type: none"> • Rotation direction is determined by the external operation input signal. • Set frequency is determined by the external frequency setting signal. |

(2) PU operation interlock

PU operation interlock forces the operation mode to be changed to the external operation mode when the MRS signal switches off. This function prevents the inverter from being inoperative by the external command if the mode is accidentally left unswitched from the PU operation mode.

1) Preparation

- Set "7" in Pr. 79 (PU operation interlock).
- Set the terminal used for MRS signal input with any of Pr. 180 to Pr. 183 (input terminal function selection).

Refer to page 142 for Pr. 180 to Pr. 183 (input terminal function selection).


Note: When terminal assignment is changed using Pr. 180 to Pr. 183, the other functions may be affected. Check the functions of the corresponding terminals before making settings.

2) Function

| MRS Signal | Function/Operation |
|------------|---|
| ON | Output stopped during external operation. Operation mode can be switched to PU operation mode. Parameter values can be rewritten in PU operation mode. PU operation allowed. |
| OFF | Forcibly switched to external operation mode. External operation allowed. Switching to PU operation mode inhibited. |

<Function/operation changed by switching on-off the MRS signal>

| Operating Condition | | MRS Signal | Operation Mode (Note 4) | Operating Status | Parameter Write | Switching to PU Operation Mode |
|---------------------|------------------|-------------------|-------------------------|--|-------------------------|--------------------------------|
| Operation mode | Status | | | | | |
| PU | During stop | ON → OFF (Note 3) | External | During stop | Allowed → disallowed | Disallowed |
| | During operation | ON → OFF (Note 3) | | If external operation frequency setting and start signal are entered, operation is performed in that status. | Allowed → disallowed | Disallowed |
| External | During stop | OFF → ON | External | During stop | Disallowed → disallowed | Allowed |
| | | ON → OFF | | | Disallowed → disallowed | Disallowed |
| | During operation | OFF → ON | | During operation → output stop | Disallowed → disallowed | Disallowed |
| | | ON → OFF | | Output stop → During operation | Disallowed → disallowed | Disallowed |

Note: 1. If the MRS signal is on, the operation mode cannot be switched to the PU operation mode when the start signal (STF, STR) is on.
 2. The operation mode switches to the external operation mode independently of whether the start signal (STF, STR) is on or off.
 Therefore, the motor is run in the external operation mode when the MRS signal is switched off with either of STF and STR on.
 3. When the protective function (major fault) is activated, the inverter can be reset by pressing the  key of the control panel.
 4. Switching the MRS signal on and rewriting the Pr. 79 value to other than "7" in the PU operation mode causes the MRS signal to provide the ordinary MRS function (output stop). Also as soon as "7" is set in Pr. 79, the operation mode is switched to PU operation mode.

(3) Operation mode switching by external signal

1) Preparation

Set "8" (switching to other than external operation mode) in Pr. 79.

Use any of Pr. 180 to Pr. 183 (input terminal function selection) to set the terminal used for X16 signal input.

Refer to page 142 for Pr. 180 to Pr. 183 (input terminal function selection).

Note: When terminal assignment is changed using Pr. 180 to Pr. 183, the other functions may be affected.
Check the functions of the corresponding terminals before making settings.

2) Function

This switching is enabled during an inverter stop only and cannot be achieved during operation.

| X16 Signal | Operation Mode |
|-------------------|--|
| ON | External operation mode (cannot be changed to the PU operation mode) |
| OFF | PU operation mode (cannot be changed to the external operation mode) |

4.2.34 General-purpose magnetic flux vector control selection (Pr. 80)

Pr. 80 "motor capacity"

You can set the general-purpose magnetic flux vector control.

- General-purpose magnetic flux vector control

Provides large starting torque and sufficient low-speed torque.

If the motor constants vary slightly, stable, large low-speed torque is provided without specific motor constant setting or tuning.

Related parameters

Pr. 71 "applied motor"
Pr. 83 "rated motor voltage"
Pr. 84 "rated motor frequency"
Pr. 96 "auto-tuning setting/status"

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|-------------------------|-------------------|
| 80 | 9999 | 0.2kW to 7.5kW, 9999 | 9999: V/F control |

If any of the following conditions are not satisfied, faults such as torque shortage and speed fluctuation may occur. In this case, select V/F control.

<Operating conditions>

- The motor capacity is equal to or one rank lower than the inverter capacity.
- The number of motor poles is any of 2, 4, and 6. (4 poles only for the constant-torque motor)
- Single-motor operation (one motor for one inverter) is performed.
- The wiring length between the inverter and motor is within 30m. (If the length is over 30m, perform offline auto tuning with the cables wired.)

<Setting>

(1) General-purpose magnetic flux vector control

- The general-purpose magnetic flux vector control can be selected by setting the capacity of the motor used in Pr. 80.

| Parameter Number | Setting | Description | |
|------------------|------------|---------------------------------|--|
| 80 | 9999 | V/F control | |
| | 0.2 to 7.5 | Set the motor capacity applied. | General-purpose magnetic flux vector control |

- When using Mitsubishi's constant-torque motor (SF-JRCA), set "1" in Pr. 71. (When using the SF-JRC, perform the offline auto tuning.)

4.2.35 Offline auto tuning function (Pr. 82 to Pr. 84, Pr. 90, Pr. 96)

Pr. 82 "motor exciting current"

Pr. 83 "rated motor voltage"

Pr. 84 "rated motor frequency"

Pr. 90 "motor constant (R1)"

Pr. 96 "auto-tuning setting/status"

Related parameters

- Pr. 7 "acceleration time"
- Pr. 9 "electronic thermal O/L relay"
- Pr. 71 "applied motor"
- Pr. 79 "operation mode selection"
- Pr. 80 "motor capacity"

What is auto tuning?

- (1)The general-purpose magnetic flux vector control system gets the best performance from the motor for operation.
- (2)Using the offline auto tuning function to improve the operational performance of the motor.

When you use the general-purpose magnetic flux vector control, you can perform the offline auto tuning operation to calculate the motor constants automatically.

- Offline auto tuning is made valid only when Pr. 80 is set to other than "9999" to select the general-purpose magnetic flux vector control.
- The Mitsubishi standard motor (SF-JR0.4kW or more) or Mitsubishi constant-torque motor (By SF-JRCA 200V class and 4-pole motor of 0.4kW to 7.5kW) allows general-purpose magnetic flux vector control operation to be performed without using the offline auto tuning function. However, if any other motor (Motor made of the other manufacturers or SF-JRC, etc.) is used or the wiring distance is long, using the offline auto tuning function allows the motor to be operated with the optimum operational characteristics.
- Offline auto tuning
 - Automatically measures the motor constants used for general-purpose magnetic flux vector control.
 - Offline auto tuning can be performed with the load connected. (As the load is smaller, tuning accuracy is higher. Tuning accuracy does not change if inertia is large.)
 - The offline auto tuning status can be monitored with the control panel (FR-PA02-02) or PU (FR-PU04).
 - Offline auto tuning is available only when the motor is at a stop.
- Tuning data (motor constants) can be copied to another inverter with the PU (FR-PU04).
 - You can read, write and copy the motor constants tuned by the offline auto tuning.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|-----------------|---------------------------------|
| 82 | 9999 | 0 to 500A, 9999 | 9999: Mitsubishi standard motor |
| 83 | 200V/400V | 0 to 1000V | Rated inverter voltage |
| 84 | 50Hz | 50 to 120Hz | |
| 90 | 9999 | 0 to 50Ω, 9999 | 9999: Mitsubishi standard motor |
| 96 | 0 | 0, 1 | 0: No tuning |

<Operating conditions>

- The motor is connected.
- The motor capacity is equal to or one rank lower than the inverter capacity.
- Special motors such as high-slip motors and high-speed motors cannot be tuned.
- The motor may move slightly. Therefore, fix the motor securely with a mechanical brake, or before tuning, make sure that there will be no problem in safety if the motor runs.

*This instruction must be followed especially for vertical lift applications.

If the motor runs slightly, tuning performance is unaffected.

- Offline auto tuning will not be performed properly if it is started when a reactor or surge voltage suppression filter (FR-ASF-H) is connected between the inverter and motor. Remove it before starting tuning.

<Setting>**(1) Parameter setting**

- Set the motor capacity (kW) in Pr. 80 and select the general-purpose magnetic flux vector control.
- Refer to the parameter details list and set the following parameters:
 - 1) Set "1" in Pr. 96.
 - 2) Set the rated motor current (A) in Pr. 9.
 - 3) Set the rated motor voltage (V) in Pr. 83.
 - 4) Set the rated motor frequency (Hz) in Pr. 84.
 - 5) Select the motor using Pr. 71.
 - Standard motor Pr. 71 = "3" or "103"
 - Constant-torque motor Pr. 71 = "13" or "113"
 - Mitsubishi standard motor SF-JR 4 poles (1.5kW or less). Pr. 71 = "23" or "123"

Note: Pr. 83 and Pr. 84 are only displayed when the general-purpose magnetic flux vector control is selected.

In these parameters, set the values given on the motor plate. Set 200V/60Hz or 400V/60Hz if the standard or other motor has more than one rated value.

After tuning is over, set the Pr. 9 "electronic overcurrent protection" value to the rated current at the operating voltage/frequency.

■ **Parameter details**

| Parameter Number | Setting | Description | | |
|------------------|----------------|--|---|------------------|
| 9 | 0 to 500A | Set the rated motor current (A). | | |
| 71 (Note) | 0, 100 | Thermal characteristics suitable for standard motor | | |
| | 1, 101 | Thermal characteristics suitable for Mitsubishi's constant-torque motor | | |
| | 3, 103 | Standard motor | Select "offline auto tuning setting" | |
| | 13, 113 | Constant-torque motor | | |
| | 23, 123 | Mitsubishi's SF-JR4P standard motor (1.5kW or less) | Direct input of motor constants enabled | |
| | 5, 105 | Standard motor | | Star connection |
| | 15, 115 | Constant-torque motor | | Delta connection |
| | 6, 106 | Standard motor | | |
| | 16, 116 | Constant-torque motor | | |
| 83 | 0 to 1000V | Set the rated motor voltage (V). | | |
| 84 | 50 to 120Hz | Set the rated motor frequency (Hz). | | |
| 90 | 0 to 50Ω, 9999 | Tuning data (Values measured by offline auto tuning are set automatically.) | | |
| 96 | 0 | Offline auto tuning is not performed. | | |
| | 1 | Offline auto tuning is performed. | | |

Note: The electronic overcurrent protection characteristics are also selected simultaneously. By setting any of "100 to 123", the electronic overcurrent protection changes to the thermal characteristic of the constant-torque motor when the RT signal switches on.

(2) Tuning execution

- For PU operation or combined operation 2, press the **FWD** or **REV** key.
- For external operation or combined operation 1, switch on the run command.

Note:

- To force tuning to end
 - Switch on the MRS or RES signal or press the **STOP RESET** key to end.
 - Switch off the tuning start command to make a forced end.
- During offline auto tuning, only the following I/O signals are valid:
 - Input signals
<Valid signals>
MRS, RES, STF, STR
 - Output signals
RUN, AM, A, B, C
- Special caution should be exercised when a sequence has been designed to open the mechanical brake with the RUN signal.

(3) Monitoring the offline tuning status

When the parameter unit (FR-PU04) is used, the Pr. 96 value is displayed during tuning on the main monitor as shown below. When the control panel is used, the same value as on the PU is only displayed:

- Control panel (FR-PA02-02) display

(For inverter trip)

| | 1. Setting | 2. Tuning in progress | 3. Completion | 4. Error-activated end |
|-----------------|------------|-----------------------|---------------|------------------------|
| Displayed value | 1 | 2 | 3 | 9 |

- Parameter unit (FR-PU04) main monitor

(For inverter trip)

| | 1. Setting | 2. Tuning in progress | 3. Completion | 4. Error-activated end |
|---------|-----------------|-----------------------|-------------------------------------|--------------------------------|
| Display | 1 ---STOP PU | TUNE 2 STF FWD PU | TUNE 3 COMPLETION STF STOP PU | TUNE 9 ERROR STF STOP PU |


- Reference: Offline auto tuning time (factory setting) is about 10 seconds.

(4) Ending the offline auto tuning

1) Confirm the Pr. 96 value.

- Normal end: "3" is displayed.
- Abnormal end: "9", "91", "92" or "93" is displayed.
- Forced end: "8" is displayed.

2) When tuning ended normally

For PU operation or combined operation 2, press the  key. For external operation or combined operation 1, switch off the start signal (STF or STR) once. This operation resets the offline auto tuning and the PU's monitor display returns to the ordinary indication. (Without this operation, next operation cannot be done.)

3) When tuning was ended due to an error


Offline auto tuning did not end normally. (The motor constants have not been set.) Reset the inverter and start tuning all over again.

4) Error display definitions

| Error Display | Error Cause | Remedy |
|----------------------|--|--|
| 9 | Inverter trip | Make setting again. |
| 91 | Current limit (stall prevention) function was activated. | Increase acceleration/deceleration time. Set "1" in Pr. 156. |
| 92 | Converter output voltage reached 75% of rated value. | Check for fluctuation of power supply voltage. |
| 93 | Calculation error | Check the motor wiring and make setting again. |

No connection with motor will result in a calculation (93) error.

5) When tuning was forced to end

An forced end occurs when you forced the tuning to end by pressing the  key or switching off the start signal (STF or STR) during tuning.


In this case, the offline auto tuning has not ended normally.

(The motor constants are not set.)

Reset the inverter and restart the tuning.

- Note: 1. The R1 motor constant measured during in the offline auto tuning is stored as a parameter and its data is held until the offline auto tuning is performed again.
2. An instantaneous power failure occurring during tuning will result in a tuning error.
After power is restored, the inverter goes into the ordinary operation mode. Therefore, when STF (STR) is on, the motor runs in forward (reverse) rotation.
3. Any alarm occurring during tuning is handled as in the ordinary mode. Note that if an error retry has been set, retry is ignored.
4. The set frequency monitor displayed during the offline auto tuning is 0Hz.

 **CAUTION**

 **When the offline auto tuning is used in vertical lift application, e.g. a lifter, it may drop due to insufficient torque.**

<Setting the motor constant as desired>

- To set the motor constant without using the offline auto tuning data

<Operating procedure>

1. Set any of the following values in Pr. 71:

| | | Star Connection Motor | Delta Connection Motor |
|---------|-----------------------|------------------------------|-------------------------------|
| Setting | Standard motor | 5 or 105 | 6 or 106 |
| | Constant-torque motor | 15 or 115 | 16 or 116 |

By setting any of "105 to 116", the electronic overcurrent protection changes to the thermal characteristics of the constant-torque motor when the RT signal switches on.

2. Set "801" in Pr. 77.

(Only when the Pr. 80 setting is other than "9999", the parameter values of the motor exciting current (Pr. 82) and motor constant (Pr. 90) can be displayed. Though the parameter values other than Pr. 82 and Pr. 90 can also be displayed, they are parameters for manufacturer setting and should be handled carefully without misuse.)

3. In the parameter setting mode, read the following parameters and set desired values:

| Parameter Number | Name | Setting Range | Setting Increments | Factory Setting |
|-------------------------|------------------------|----------------------|---------------------------|------------------------|
| 82 | Motor exciting current | 0 to 500A, 9999 | 0.01A | 9999 |
| 90 | Motor constant (R1) | 0 to 10Ω, 9999 | 0.001Ω | 9999 |

4. Return the Pr. 77 setting to the original value.

5. Refer to the following table and set Pr. 84:

| Parameter Number | Name | Setting Range | Setting Increments | Factory Setting |
|-------------------------|-----------------------|----------------------|---------------------------|------------------------|
| 84 | Rated motor frequency | 50 to 120Hz | 0.01Hz | 50Hz |

Note: 1. The Pr. 90 value may only be read when general-purpose magnetic flux vector control has been selected.
 2. Set "9999" in Pr. 90 to use the standard motor constant (including that for the constant-torque motor).
 3. If "star connection" is mistaken for "delta connection" or vice versa during setting of Pr. 71, general-purpose magnetic flux vector control cannot be exercised normally.

4.2.36 Computer link operation (Pr. 117 to Pr. 124, Pr. 342)

Pr. 117 "station number"

Pr. 118 "communication speed"

Pr. 119 "stop bit length"

Pr. 120 "parity check presence/absence"

Pr. 121 "number of communication retries"

Pr. 122 "communication check time interval"

Pr. 123 "waiting time setting"

Pr. 124 "CR•LF presence/absence selection"

Pr. 342 "E²PROM write selection"

Used to perform required settings for RS-485 communication between the inverter and personal computer.

- **The motor can be run from the PU connector of the inverter using RS-485 communication.**

Communication specifications

| | | | |
|-------------------------------|------------------|--|--|
| Conforming standard | | RS-485 | |
| Number of inverters connected | | 1:N (maximum 32 inverters) | |
| Communication speed | | Selectable between 19200, 9600 and 4800bps | |
| Control protocol | | Asynchronous | |
| Communication method | | Half-duplex | |
| Communication specifications | Character system | ASCII (7 bits/8 bits) selectable | |
| | Stop bit length | Selectable between 1 bit and 2 bits. | |
| | Terminator | CR/LF (presence/absence selectable) | |
| | Check system | Parity check | Selectable between presence (even/odd) and absence |
| | | Sum check | Present |
| Waiting time setting | | Selectable between presence and absence | |

- **For the data codes of the parameters, refer to Appendix 1 "Data Code List" (page 186).**

REMARKS

For computer link operation, set 65520 (HFFF0) as the value "8888" and 65535 (HFFFF) as the value "9999".

| Parameter Number | Factory Setting | Setting Range | |
|------------------|-----------------|-------------------------|--------|
| 117 | 0 | 0 to 31 | |
| 118 | 192 | 48, 96, 192 | |
| 119 | 1 | Data length 8 | 0, 1 |
| | | Data length 7 | 10, 11 |
| 120 | 2 | 0, 1, 2 | |
| 121 | 1 | 0 to 10, 9999 | |
| 122* | 9999 | 0, 0.1 to 999.8 s, 9999 | |
| 123 | 9999 | 0 to 150, 9999 | |
| 124 | 1 | 0, 1, 2 | |
| 342 | 0 | 0, 1 | |

- * **When making communication, set any value other than 0 in Pr. 122 "communication check time interval".**

<Setting>

To make communication between the personal computer and inverter, the communication specifications must be set to the inverter initially. If initial setting is not made or there is a setting fault, data transfer cannot be made.

Note: After making the initial setting of the parameters, always reset the inverter. After you have changed the communication-related parameters, communication cannot be made until the inverter is reset.

| Parameter Number | Definition | Setting | Description | |
|------------------|------------------------------------|--------------|--|------------------------|
| 117 | Station number | 0 to 31 | Station number specified for communication from the PU connector. Set the inverter station numbers when two or more inverters are connected to one personal computer. | |
| 118 | Communication speed | 48 | 4800 bps | |
| | | 96 | 9600 bps | |
| | | 192 | 19200 bps | |
| 119 | Stop bit length | 8 data bits | 0 | Stop bit length 1 bit |
| | | | 1 | Stop bit length 2 bits |
| | | 7 bits | 10 | Stop bit length 1 bit |
| | | | 11 | Stop bit length 2 bits |
| 120 | Parity check presence/absence | 0 | Absent | |
| | | 1 | Odd parity present | |
| | | 2 | Even parity present | |
| 121 | Number of communication retries | 0 to 10 | Set the permissible number of retries at occurrence of a data receive error. If the number of consecutive errors exceeds the permissible value, the inverter will come to an alarm stop. | |
| | | 9999 (65535) | If a communication error occurs, the inverter will not come to an alarm stop. At this time, the inverter can be coasted to a stop by MRS or RESET input. During a communication error (H0 to H5), the minor fault signal (LF) is switched on. Allocate the used terminal with any of Pr. 190 to Pr. 192 (multi-function outputs). | |
| 122 | Communication check time interval | 0 | No communication | |
| | | 0.1 to 999.8 | Set the communication check time [seconds] interval. If a no-communication state persists for longer than the permissible time, the inverter will come to an alarm stop. | |
| | | 9999 | Communication check suspension | |
| 123 | Waiting time setting | 0 to 150 | Set the waiting time between data transmission to the inverter and response. | |
| | | 9999 | Set with communication data. | |
| 124 | CR•LF instruction presence/absence | 0 | Without CR/LF | |
| | | 1 | With CR, without LF | |
| | | 2 | With CR/LF | |


| Parameter Number | Definition | Setting | Data Definition |
|------------------|-------------------------------------|---------|---|
| 342* | E ² PROM write selection | 0 | When parameter write is performed from the computer, parameters are written to E ² PROM. |
| | | 1 | When parameter write is performed from the computer, parameters are written to RAM. |

* When you have set write to RAM, powering off the inverter clears the parameter values that have been changed. Therefore the parameter values available when power is switched on again are those stored previously in E²PROM.
When the parameter values will be changed frequently, set "1" in Pr. 342 to choose write to RAM.

<Computer programming>

(1) Communication protocol

Data communication between the computer and inverter is performed using the following procedure:



- *1. If a data error is detected and a retry must be made, execute retry operation with the user program. The inverter comes to an alarm stop if the number of consecutive retries exceeds the parameter setting.
- *2. On receipt of a data error occurrence, the inverter returns "reply data 3)" to the computer again. The inverter comes to an alarm stop if the number of consecutive data errors reaches or exceeds the parameter setting.

(2) Communication operation presence/absence and data format types

Communication operation presence/absence and data format types are as follows:

| No. | Operation | Run Command | Running Frequency | Parameter Write | Inverter Reset | Monitoring | Parameter Read | |
|-----|--|--|-------------------|------------------|----------------|------------|----------------------|------------------|
| 1) | Communication request is sent to the inverter in accordance with the user program in the computer. | A' | A (A'') Note1 | A (A'') Note2 | A | B | B | |
| 2) | Inverter data processing time | Present | Present | Present | Absent | Present | Present | |
| 3) | Reply data from the inverter (Data 1) is checked for error. | No error* (Request accepted) | C | C | C | Absent | E, E' (E'') Note1 | E (E'') Note2 |
| | | With error (request rejected) | D | D | D | Absent | F | F |
| 4) | Computer processing delay time | Absent | Absent | Absent | Absent | Absent | Absent | |
| 5) | Answer from computer in response to reply data 3). (Data 3) is checked for error) | No error* (No inverter processing) | Absent | Absent | Absent | Absent | G | G |
| | | With error. Inverter outputs 3) again. | Absent | Absent | Absent | Absent | H | H |

* In the communication request data from the computer to the inverter, 10ms or more is also required after "no data error (ACK)". (Refer to page 121.)

- Note: 1. Setting any of "0.01 to 9998" in Pr. 37 "speed display" and "1" in data code "HFF" changes the data format to A" or E", the output frequency to the speed indication, and the unit to 0.001r/min. If the data code FF is not 1, the unit is 1r/min and the 4-digit data format can be used.
2. The read/write data format of Pr. 37 "speed display" is always E"/A".

(3) Data format




Data used is hexadecimal.

Data is automatically transferred in ASCII between the computer and inverter.


1) Data format types

(1) Communication request data from computer to inverter

[Data write]



[Data read]





- Note: 1. The inverter station numbers may be set between H00 and H1F (stations 0 and 31) in hexadecimal.
2. *3 indicates the control code.
3. *4 indicates the CR or LF code.
- When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer.
- Also, the presence and absence of the CR and LF codes can be selected using Pr. 124.
4. At *5, when Pr. 123 "waiting time setting" ≠ 9999, create the communication request data without "waiting time" in the data format.
(The number of characters is decremented by 1.)

2) Reply data from inverter to computer during data write

[No data error detected]





[Data error detected]



3) Reply data from inverter to computer during data read

[No data error detected]



[Data error detected]



4) Send data from computer to inverter during data read

[No data error detected]

[Data error detected]



(4) Data definitions

1) Control codes

| Signal | ASCII Code | Description |
|--------|------------|--|
| STX | H02 | Start of Text (Start of data) |
| ETX | H03 | End of Text (End of data) |
| ENQ | H05 | Enquiry (Communication request) |
| ACK | H06 | Acknowledge (No data error detected) |
| LF | H0A | Line Feed |
| CR | H0D | Carriage Return |
| NAK | H15 | Negative Acknowledge (Data error detected) |

2) Inverter station number

Specify the station number of the inverter which communicates with the computer.

3) Instruction code


Specify the processing request, e.g. operation, monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code as appropriate. (Refer to page 186.)

4) Data

Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer to page 186.)



5) Waiting time

Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer between 0 and 150ms in 10ms increments (e.g. 1 = 10ms, 2 = 20ms).



Note: If the Pr. 123 "waiting time setting" value is not 9999, create the communication request data with no "waiting time" in the data format. (The number of characters is decremented by 1.)

6) Response time



[Data sending time calculation expression]

$$\frac{1}{\text{Communication speed (bps)}} \times \text{Number of data characters (Refer to page 119)} \times \text{Communication specification (Total number of bits) (See below)} = \text{Data sending time (s)}$$


● Communication specification

| Name | | Number of Bits |
|-----------------|-----|------------------|
| Stop bit length | | 1 bit 2 bits |
| Data length | | 7 bits 8 bits |
| Parity check | Yes | 1 bit |
| | No | 0 bits |

In addition to the bits in the above table, 1 bit is required for the start bit.
 Minimum total number of bits ... 9 bits
 Maximum total number of bits ... 12 bits

7) Sum check code

The sum check code is 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



8) Error code

If any error is found in the data received by the inverter, its definition is sent back to the computer together with the NAK code. (Refer to page 126.)

- Note: 1. When the data from the computer has an error, the inverter will not accept that data.
2. Any data communication, e.g. run command, monitoring, is started when the computer gives a communication request. Without the computer's command, the inverter does not return any data. For monitoring, therefore, design the program to cause the computer to provide a data read request as required.
3. When accessing the parameter settings, data for link parameter expansion setting differs between the parameters as indicated below:

| | | Instruction Code | Data |
|----------------------------------|-------|------------------|--|
| Link parameter expansion setting | Read | H7F | H00: Pr. 0 to Pr. 96 values are accessible. H01: Pr. 100 to Pr. 158 and Pr. 901 to Pr. 905 values are accessible. |
| | Write | HFF | H02: Pr. 160 to Pr. 196 and Pr. 232 to Pr. 251 values are accessible. H03: Pr.338 to Pr. 342 values are accessible. H09: Pr. 990, Pr. 991 values are accessible. |

⚠ CAUTION

- ⚠ When the inverter's permissible communication time interval is not set, interlocks are provided to disable operation to prevent hazardous conditions. Always set the communication check time interval before starting operation.
- ⚠ Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc, the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will come to an alarm stop (E.PUE).
The inverter can be coasted to a stop by switching on its RES signal or by switching power off.
- ⚠ If communication is broken due to signal cable breakage, computer fault etc, the inverter does not detect such a fault. This should be fully noted.

<Setting items and set data>

After completion of parameter settings, set the instruction codes and data then start communication from the computer to allow various types of operation control and monitoring.

| No. | Item | | Instruction Code | Description | Number of Data Digits (Data code FF=1) |
|-----|----------------|--------------------------|------------------|--|--|
| 1 | Operation mode | Read | H7B | H0001: External operation H0002: Communication operation | 4 digits |
| | | Write | HFB | H0001: External operation H0002: Communication operation | |
| 2 | Monitoring | Output frequency [speed] | H6F | H0000 to HFFFF: Output frequency (hexadecimal) in 0.01Hz increments [Speed (hexadecimal) in r/min increments if Pr. 37 = 1 to 9998] | 4 digits (6 digits) |
| | | Output current | H70 | H0000 to HFFFF: Output current (hexadecimal) in 0.01A increments | 4 digits |
| | | Output voltage | H71 | H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments | 4 digits |

| No. | Item | Instruction Code | Description | Number of Data Digits (Data code FF=1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|---|------------------|--|--|-------------|------|-------------|-----|----------|-----|----|-----|-----|-----|----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|-----|-----|-----|------|-----|-----|--|--|----------|
| 2 | Monitoring Alarm definition | H74 to H77 | <p>H0000 to HFFFF: Two most recent alarm definitions Alarm definition display example (instruction code H74)</p> <p style="text-align: center;"> b15 b8b7 b0 </p> <p>Alarm data</p> <table border="1"> <thead> <tr> <th>Data</th> <th>Description</th> <th>Data</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>H00</td><td>No alarm</td><td>H70</td><td>BE</td></tr> <tr><td>H10</td><td>OC1</td><td>H80</td><td>GF</td></tr> <tr><td>H11</td><td>OC2</td><td>H81</td><td>LF</td></tr> <tr><td>H12</td><td>OC3</td><td>H90</td><td>OHT</td></tr> <tr><td>H20</td><td>OV1</td><td>HA0</td><td>OPT</td></tr> <tr><td>H21</td><td>OV2</td><td>HB0</td><td>PE</td></tr> <tr><td>H22</td><td>OV3</td><td>HB1</td><td>PUE</td></tr> <tr><td>H30</td><td>THT</td><td>HB2</td><td>RET</td></tr> <tr><td>H31</td><td>THM</td><td>HF6</td><td>E. 6</td></tr> <tr><td>H40</td><td>FIN</td><td>HF7</td><td>E. 7</td></tr> <tr><td>H60</td><td>OLT</td><td></td><td></td></tr> </tbody> </table> | Data | Description | Data | Description | H00 | No alarm | H70 | BE | H10 | OC1 | H80 | GF | H11 | OC2 | H81 | LF | H12 | OC3 | H90 | OHT | H20 | OV1 | HA0 | OPT | H21 | OV2 | HB0 | PE | H22 | OV3 | HB1 | PUE | H30 | THT | HB2 | RET | H31 | THM | HF6 | E. 6 | H40 | FIN | HF7 | E. 7 | H60 | OLT | | | 4 digits |
| Data | Description | Data | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H00 | No alarm | H70 | BE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H10 | OC1 | H80 | GF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H11 | OC2 | H81 | LF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H12 | OC3 | H90 | OHT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H20 | OV1 | HA0 | OPT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H21 | OV2 | HB0 | PE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H22 | OV3 | HB1 | PUE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H30 | THT | HB2 | RET | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H31 | THM | HF6 | E. 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H40 | FIN | HF7 | E. 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| H60 | OLT | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Run command | HFA | <p style="text-align: center;"> b7 b0 </p> <p>[For example 1] [Example 1] H02 ... Forward rotation [Example 2] H00 ... Stop</p> <p>b0 : _____ b1 : Forward rotation (STF) b2 : Reverse rotation (STR) b3 : _____ b4 : _____ b5 : _____ b6 : _____ b7 : _____</p> | 2 digits | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Inverter status monitor | H7A | <p style="text-align: center;"> b7 b0 </p> <p>(For example 1) [Example 1] H02 ... During forward rotation [Example 2] H80 ... Stop due to alarm</p> <p>b0 : Inverter running (RUN) b1 : Forward rotation b2 : Reverse rotation b3 : Up to frequency (SU) b4 : Overload (OL) b5 : _____ b6 : Frequency detection (FU) b7 : Alarm occurrence</p> | 2 digits | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Set frequency read (E ² PROM) | H6E | Reads the set frequency (RAM or E ² PROM). H0000 to H9C40: 0.01Hz increments (hexadecimal) | 4 digits (6 digits) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Set frequency read (RAM) | H6D | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Set frequency write (E ² PROM) | HEE | H0000 to H9C40: 0.01Hz increments (hexadecimal) (0 to 400.00Hz) | 4 digits (6 digits) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Set frequency write (RAM) | HED | To change the set frequency consecutively, write data to the inverter RAM. (Instruction code: HED) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Item | Instruction Code | Description | Number of Data Digits (Data code FF=1) | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|--|------------------|--|--|-------------------|-------------|------------|---------|-------|---|---|---|---|-------|---|---|---|---|-------|---|---|---|---|-------|---|---|---|---|----------|
| 6 | Inverter reset | HFD | H9696: Resets the inverter. As the inverter is reset on start of communication by the computer, the inverter cannot send reply data back to the computer. | 4 digits | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Alarm definition batch clear | HF4 | H9696: Batch clear of alarm history | 4 digits | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | All parameter clear | HFC | <p>All parameters return to the factory settings. Any of four different all clear operations is performed according to the data.</p> <table border="1"> <thead> <tr> <th>Data \ Pr.</th> <th>Communication Pr.</th> <th>Calibration</th> <th>Other Pr.*</th> <th>HEC HFF</th> </tr> </thead> <tbody> <tr> <td>H9696</td> <td>○</td> <td>×</td> <td>○</td> <td>○</td> </tr> <tr> <td>H9966</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>H5A5A</td> <td>×</td> <td>×</td> <td>○</td> <td>○</td> </tr> <tr> <td>H55AA</td> <td>×</td> <td>○</td> <td>○</td> <td>○</td> </tr> </tbody> </table> <p>When all parameter clear is executed for H9696 or H9966, communication-related parameter settings also return to the factory settings. When resuming operation, set the parameters again. * Pr. 75 is not cleared.</p> | Data \ Pr. | Communication Pr. | Calibration | Other Pr.* | HEC HFF | H9696 | ○ | × | ○ | ○ | H9966 | ○ | ○ | ○ | ○ | H5A5A | × | × | ○ | ○ | H55AA | × | ○ | ○ | ○ | 4 digits |
| Data \ Pr. | Communication Pr. | Calibration | Other Pr.* | HEC HFF | | | | | | | | | | | | | | | | | | | | | | | | | |
| H9696 | ○ | × | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| H9966 | ○ | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| H5A5A | × | × | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| H55AA | × | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Parameter write | H80 to HFD | Refer to the "Data Code List" (page 186) and write and/or read the values as required. | 4 digits | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Parameter read | H00 to H7B | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Link parameter expansion setting | Read | H7F | 2 digits | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Write | HFF | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Second parameter changing (Code HFF=1) | Read | H6C | 2 digits | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Write | HEC | | | | | | | | | | | | | | | | | | | | | | | | | | |

REMARKS

For the instruction codes HFF, HEC, their set values are held once they are written, but changed to 0 when the inverter is reset or all clear is performed.

<Error Code List>

The corresponding error code in the following list is displayed if an error is detected in any communication request data from the computer:

| Error Code | Item | Definition | Inverter Operation |
|-------------------|------------------------|--|--|
| H0 | Computer NAK error | The number of errors consecutively detected in communication request data from the computer is greater than allowed number of retries. | Brought to an alarm stop (E.PUE) if error occurs continuously more than the allowable number of retries. |
| H1 | Parity error | The parity check result does not match the specified parity. | |
| H2 | Sum check error | The sum check code in the computer does not match that of the data received by the inverter. | |
| H3 | Protocol error | Data received by the inverter is in wrong protocol, data receive is not completed within given time, or CR and LF are not as set in the parameter. | |
| H4 | Framing error | The stop bit length is not as specified by initialization. | |
| H5 | Overrun error | New data has been sent by the computer before the inverter completes receiving the preceding data. | |
| H6 | _____ | _____ | _____ |
| H7 | Character error | The character received is invalid (other than 0 to 9, A to F, control code). | Does not accept received data but is not brought to alarm stop. |
| H8 | _____ | _____ | _____ |
| H9 | _____ | _____ | _____ |
| HA | Mode error | Parameter write was attempted in other than the computer link operation mode or during inverter operation. | Does not accept received data but is not brought to alarm stop. |
| HB | Instruction code error | The specified command does not exist. | |
| HC | Data range error | Invalid data has been specified for parameter write, frequency setting, etc. | |
| HD | _____ | _____ | _____ |
| HE | _____ | _____ | _____ |
| HF | _____ | _____ | _____ |

(5) Communication specifications for RS-485 communication

| Operation Location | Item | Operation Mode | |
|--|---------------------------|---|----------------------------------|
| | | Communication Operation from PU Connector | External Operation |
| Computer user program via PU connector | Run command (start) | Enable | Disable |
| | Running frequency setting | Enable | Enable (Combined operation mode) |
| | Monitoring | Enable | Enable |
| | Parameter write | Enable (*2) | Disable (*2) |
| | Parameter read | Enable | Enable |
| | Inverter reset | Enable | Enable |
| | Stop command (*1) | Enable | Enable |
| Control circuit terminal | Inverter reset | Enable | Enable |
| | Run command | Disable | Enable |
| | Running frequency setting | Disable | Enable |

*1 As set in Pr. 75.

*2 As set in Pr. 77.

Note: At occurrence of RS-485 communication fault, the inverter cannot be reset from the computer.

(6) Operation at alarm occurrence

| Fault Location | Description | | Operation Mode | |
|---|--------------------|--------------|--|--------------------|
| | | | Communication Operation (PU connector) | External Operation |
| Inverter fault | Inverter operation | | Stop | Stop |
| | Communication | PU connector | Continued | Continued |
| Communication error (Communication from PU connector) | Inverter operation | | Stop/continued (*3) | Continued |
| | Communication | PU connector | Stop | Stop |

*3: Can be selected using the corresponding parameter (factory-set to stop).

(7) Communication error

| Fault Location | Error Message | Remarks |
|---|---------------|---------------------|
| Communication error (Communication from PU connector) | Not displayed | Error code is E.PUE |

4.2.37 PID control (Pr. 128 to Pr. 134)

Pr. 128 "PID action selection"

Pr. 129 "PID proportional band"

Pr. 130 "PID integral time"

Pr. 131 "upper limit"

Pr. 132 "lower limit"

Pr. 133 "PID action set point for PU operation"

Pr. 134 "PID differential time"

Related parameters

- Pr. 73 "0-5V/0-10V selection"
- Pr. 79 "operation mode selection"
- Pr. 180 to Pr. 183 (input terminal function selection)
- Pr. 191 to Pr. 192 (output terminal function selection)
- Pr. 902 to Pr. 905 (frequency setting voltage (current) biases and gains)


The inverter can be used to exercise process control, e.g. flow rate, air volume or pressure.

- The voltage input signal (0 to ±5V or 0 to ±10V) or Pr. 133 setting is used as a set point and the 4 to 20mA DC current input signal used as a feedback value to constitute a feedback system for PID control.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|----------------------|-------------------------------|
| 128 | 0 | 0, 20, 21 | |
| 129 | 100% | 0.1 to 1000%, 9999 | 9999: No proportional control |
| 130 | 1s | 0.1 to 3600s, 9999 | 9999: No integral control |
| 131 | 9999 | 0 to 100%, 9999 | 9999: Function invalid |
| 132 | 9999 | 0 to 100%, 9999 | 9999: Function invalid |
| 133 | 0% | 0 to 100% | |
| 134 | 9999 | 0.01 to 10.00s, 9999 | 9999: No differential control |

<Setting>

(1) Basic PID control configuration




(2) PID action overview

1) PI action

A combination of proportional control action (P) and integral control action (I) for providing a manipulated variable in response to deviation and changes with time.

[Operation example for stepped changes of process value]

Note: PI action is the sum of P and I actions.




2) PD action

A combination of proportional control action (P) and differential control action (D) for providing a manipulated variable in response to deviation speed to improve the transient characteristic.

[Operation example for proportional changes of process value]

Note: PD action is the sum of P and D actions.




3) PID action

The PI action and PD action are combined to utilize the advantages of both actions for control.

Note: The PID action is the sum of P, I and D actions.


4) Reverse action

Increases the manipulated variable (output frequency) if deviation X (set point - process value) is positive, and decreases the manipulated variable if deviation is negative.



5) Forward action

Increases the manipulated variable (output frequency) if deviation X (set point - process value) is negative, and decreases the manipulated variable if deviation is positive.




Relationships between deviation and manipulated variable (output frequency)

| | Deviation | |
|----------------|------------|------------|
| | Positive | Negative |
| Reverse action | \nearrow | \searrow |
| Forward action | \searrow | \nearrow |

(3) Wiring example

- Pr. 190 = 14
- Pr. 191 = 15
- Pr. 192 = 16



Note: 1. The power supply must be selected in accordance with the power specifications of the detector used.
 2. The output signal terminals used depends on the Pr. 190 to Pr. 192 settings.

(4) I/O signals

| Signal | Terminal Used | Function | Description | |
|--------|---------------|---------------------------------|---|--|
| Input | 2 | 2 | Set point input | Enter the set point for PID control. |
| | 4 | 4 | Process value input | Enter the 4 to 20mADC process value signal from the detector. |
| Output | FUP | Depending on Pr. 190 to Pr. 192 | Upper limit output | Output to indicate that the process value signal exceeded the upper limit value. |
| | FDN | | Lower limit output | Output to indicate that the process value signal exceeded the lower limit value. |
| | RL | | Forward (reverse) rotation direction output | "Hi" is output to indicate that the output indication of the parameter unit is forward rotation (FWD) or "Low" to indicate that it is reverse rotation (REV) or stop (STOP). |


- Enter the set point across inverter terminals 2-5 or in Pr. 133 and enter the process value signal across inverter terminals 4-5.

| Item | Entry | Description | |
|---------------|----------------------|---|--|
| Set point | Across terminals 2-5 | Set 0V as 0% and 5V as 100%. | When "0" is set in Pr. 73 (5V selected for terminal 2). |
| | | Set 0V as 0% and 10V as 100%. | When "1" is set in Pr. 73 (10V selected for terminal 2). |
| Set point | Pr. 133 | Set the set point (%) in Pr. 133. | |
| Process value | Across terminals 4-5 | 4mA DC is equivalent to 0% and 20mA DC to 100%. | |

(5) Parameter setting


| Parameter Number | Setting | Name | Description |
|------------------|-----------------|---------------------------------------|---|
| 128 | 0 | PID action selection | No PID action |
| | 20 | | For heating, pressure control, etc. PID reverse action |
| | 21 | | For cooling, etc. PID forward action |
| 129 | 0.1 to 1000% | PID proportional band | If the proportional band is narrow (parameter setting is small), the manipulated variable varies greatly with a slight change of the process value. Hence, as the proportional band narrows, the response sensitivity (gain) improves but the stability deteriorates, e.g. hunting occurs. Gain $K_p = 1/\text{proportional band}$ |
| | 9999 | | No proportional control |
| 130 | 0.1 to 3600 s | PID integral time | Time required for the integral (I) action to provide the same manipulated variable as that for the proportional (P) action. As the integral time decreases, the set point is reached earlier but hunting occurs more easily. |
| | 9999 | | No integral control. |
| 131 | 0 to 100% | Upper limit | Set the upper limit. If the feedback value exceeds the setting, the FUP signal is output. (Process value of 4mA is equivalent to 0% and 20mA to 100%.) |
| | 9999 | | No function |
| 132 | 0 to 100% | Lower limit | Set the lower limit. (If the process value goes out of the setting range, an alarm can be output. In this case, the process value of 4mA is equivalent to 0% and 20mA to 100%.) |
| | 9999 | | No function |
| 133 | 0 to 100% | PID action set point for PU operation | Only valid for the PU command in the PU operation or PU/external combined operation mode. For external operation, the voltage across 2-5 is the set point. (Pr. 902 value is equivalent to 0% and Pr. 903 value to 100%.) |
| 134 | 0.01 to 10.00 s | PID differential time | Time required for the differential (D) action to provide the same process value as that for the proportional (P) action. As the differential time increases, greater response is made to a deviation change. |
| | 9999 | | No differential control. |

(6) Adjustment procedure



(7) Calibration example

(A detector of 4mA at 0°C and 20mA at 50°C is used to adjust the room temperature to 25°C under PID control. The set point is given to across inverter terminals 2-5 (0-5V).)



* When calibration is required, use Pr. 902 to Pr. 905 to calibrate the detector output and set point setting input in the PU mode during an inverter stop.

<Set point input calibration>


1. Apply the input voltage of 0% set point setting (e.g. 0V) to across terminals 2-5.
2. Make calibration using Pr. 902. At this time, enter the frequency which should be output by the inverter at the deviation of 0% (e.g. 0Hz).
3. Apply the voltage of 100% set point setting (e.g. 5V) to across terminals 2-5.
4. Make calibration using Pr. 903. At this time, enter the frequency which should be output by the inverter at the deviation of 100% (e.g. 50Hz).

<Detector output calibration>

1. Apply the output current of 0% detector setting (e.g. 4mA) across terminals 4-5.
2. Make calibration using Pr. 904.
3. Apply the output current of 100% detector setting (e.g. 20mA) across terminals 4-5.
4. Make calibration using Pr. 905.

Note: The frequencies set in Pr. 904 and Pr. 905 should be the same as set in Pr. 902 and Pr. 903.

The results of the above calibration are as shown below:



- Note: 1. If the multi-speed (RH, RM, RL) signal or jog operation (jog) signal is entered, PID control is stopped and multi-speed or jog operation is started.
2. When the terminal functions are changed using Pr. 190 to Pr. 192, the other functions may be affected. Confirm the functions of the corresponding terminals before making settings.
3. When you have chosen the PID control, the minimum frequency is as set in Pr. 902 and the maximum frequency is as set in Pr. 903.
(The settings of Pr. 1 "maximum frequency" and Pr. 2 "minimum frequency" are also valid.)

4.2.38 Output current detection function (Pr. 150, Pr. 151)


Pr. 150 "output current detection level"

Pr. 151 "output current detection period"

Related parameters
Pr. 190 to Pr. 192
(output terminal function selection)

- If the output current remains higher than the Pr. 150 setting during inverter operation for longer than the time set in Pr. 151, the output current detection signal (Y12) is output from the inverter's open collector output terminal.
(Use any of Pr. 190 to Pr. 192 to assign the terminal used for Y12 signal output.)

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 150 | 150% | 0 to 200.0% |
| 151 | 0 | 0 to 10 s |



<Setting>

Refer to the following list and set the parameters:

| Parameter Number | Description |
|------------------|---|
| 150 | Set the output current detection level. 100% is the rated inverter current. |
| 151 | Set the output current detection time. Set a period of time from when the output current rises to or above the Pr. 150 setting to when the output current detection signal (Y12) is output. |

Note: 1. The output current detection signal is held on for about 100ms (at least) if it switches on once when the output current rises to or above the preset detection level.
2. This function is also valid during execution of offline auto tuning.
3. When the terminal functions are changed using Pr. 190 to Pr. 192, the other functions may be affected. Confirm the functions of the corresponding terminals before making settings.

4.2.39 Zero current detection (Pr. 152, Pr. 153)

Pr. 152 "zero current detection level"

Pr. 153 "zero current detection period"

Related parameters
Pr. 190 to Pr. 192 (output terminal function selection)


When the inverter's output current falls to "0", torque will not be generated. This may cause a gravity drop when the inverter is used in vertical lift application.

To prevent this, the output current "zero" signal can be output from the inverter to close the mechanical brake when the output current has fallen to "zero".

- If the output current remains lower than the Pr. 152 setting during inverter operation for longer than the time set in Pr. 153, the zero current detection (Y13) signal is output from the inverter's open collector output terminal.

(Use any of Pr. 190 to Pr. 192 to assign the terminal used for Y13 signal output.)

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 152 | 5.0% | 0 to 200.0% |
| 153 | 0.5 s | 0.05 to 1 s |



<Setting>

Refer to the following list and set the parameters:

| Parameter Number | Description |
|------------------|--|
| 152 | Set the zero current detection level. Set this parameter to define the percentage of the rated current at which the zero current will be detected. |
| 153 | Set the zero current detection time. Set a period of time from when the output current falls to or below the Pr. 152 setting to when the zero current detection signal (Y13) is output. |

Note: 1. If the current falls below the preset detection level but the timing condition is not satisfied, the zero current detection signal is held on for about 100ms.
2. This function is also valid during execution of offline auto tuning.
3. When the terminal functions are changed using Pr. 190 to Pr. 192, the other functions may be affected. Confirm the functions of the corresponding terminals before making settings.

⚠ CAUTION

- ⚠ The zero current detection level setting should not be too high, and the zero current detection time setting should not be too long. Otherwise, the detection signal may not be output when torque is not generated at a low output current.
- ⚠ To prevent the machine and equipment from resulting in hazardous conditions by use of the zero current detection signal, install a safety backup such as an emergency brake.

4.2.40 Stall prevention function and current limit function (Pr. 156)**Pr. 156 "stall prevention operation selection"****Related parameters**

- Pr. 22 "stall prevention operation level"
- Pr. 23 "stall prevention operation level compensation factor at double speed"

You can make settings to disable stall prevention caused by overcurrent and to disable the inverter from an overcurrent trip if an excessive current occurs due to sudden load variation or turning the inverter's output side ON-OFF (to disable the fast-response current limit which limits the current).

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 156 | 0 | 0 to 31, 100 |


<Setting>


Refer to the following tables and set the parameter as required.

| Pr. 156 Setting | Fast-Response Current Limit ○: Activated ●: Not activated | Stall Prevention Operation Selection ○: Activated ●: Not activated | | | OL Signal Output ○: Operation continued ●: Operation not continued (Note 1) |
|-----------------|---|--|----------------|--------------|---|
| | | Acceleration | Constant speed | Deceleration | |
| 0 | ○ | ○ | ○ | ○ | ○ |
| 1 | ● | ○ | ○ | ○ | ○ |
| 2 | ○ | ● | ○ | ○ | ○ |
| 3 | ● | ● | ○ | ○ | ○ |
| 4 | ○ | ○ | ● | ○ | ○ |
| 5 | ● | ○ | ● | ○ | ○ |
| 6 | ○ | ● | ● | ○ | ○ |
| 7 | ● | ● | ● | ○ | ○ |
| 8 | ○ | ○ | ○ | ● | ○ |
| 9 | ● | ○ | ○ | ● | ○ |
| 10 | ○ | ● | ○ | ● | ○ |
| 11 | ● | ● | ○ | ● | ○ |
| 12 | ○ | ○ | ● | ● | ○ |
| 13 | ● | ○ | ● | ● | ○ |
| 14 | ○ | ● | ● | ● | ○ |
| 15 | ● | ● | ● | ● | ○ |

| Pr. 156 Setting | Fast-Response Current Limit ○: Activated ●: Not activated | Stall Prevention Operation Selection ○: Activated ●: Not activated | | | OL Signal Output ○: Operation continued ●: Operation not continued (Note 1) |
|-----------------|---|--|----------------|--------------|---|
| | | Acceleration | Constant speed | Deceleration | |
| 16 | ○ | ○ | ○ | ○ | ● |
| 17 | ● | ○ | ○ | ○ | ● |
| 18 | ○ | ● | ○ | ○ | ● |
| 19 | ● | ● | ○ | ○ | ● |
| 20 | ○ | ○ | ● | ○ | ● |
| 21 | ● | ○ | ● | ○ | ● |
| 22 | ○ | ● | ● | ○ | ● |
| 23 | ● | ● | ● | ○ | ● |
| 24 | ○ | ○ | ○ | ● | ● |
| 25 | ● | ○ | ○ | ● | ● |
| 26 | ○ | ● | ○ | ● | ● |
| 27 | ● | ● | ○ | ● | ● |
| 28 | ○ | ○ | ● | ● | ● |
| 29 | ● | ○ | ● | ● | ● |
| 30 | ○ | ● | ● | ● | ● |
| 31 | ● | ● | ● | ● | ● |
| 100 | Driving | ○ | ○ | ○ | ○ |
| | Regenerative | ● | ● | ● | ○ |

Note 1: When "Operation not continued for OL signal output" is selected, the "E.OLT" alarm code (stopped by stall prevention) is displayed and operation stopped. (Alarm stop display "E.OLT")
 2: If the load is heavy, the lift is predetermined, or the acceleration/deceleration time is short, the stall prevention may be activated and the motor not stopped in the preset acceleration/deceleration time. Therefore, set optimum values to the Pr. 156 and stall prevention operation level.

 **CAUTION**

 **Always perform test operation.**
 Stall prevention operation performed during acceleration may increase the acceleration time.
 Stall prevention operation performed during constant speed may cause sudden speed changes.
 Stall prevention operation performed during deceleration may increase the deceleration time, increasing the deceleration distance.

Pr. 158 → Refer to Pr. 52.

4.2.41 User group selection (Pr. 160, Pr. 173 to Pr. 176)

Pr. 160 "user group read selection"

Pr. 173 "user group 1 registration"

Pr. 174 "user group 1 deletion"

Pr. 175 "user group 2 registration"


Pr. 176 "user group 2 deletion"

Among all parameters, a total of 32 parameters can be registered to two different user groups. The registered parameters may only be accessed. The other parameters cannot be read.


| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|----------------|----------------------|
| 160 | 0 | 0, 1, 10, 11 | |
| 173 | 0 | 0 to 999 | |
| 174 | 0 | 0 to 999, 9999 | 9999: Batch deletion |
| 175 | 0 | 0 to 999 | |
| 176 | 0 | 0 to 999, 9999 | 9999: Batch deletion |

<Setting examples show the use of the control panel (FR-PA02-02)>

(1) Registration of parameter to user group (when registering Pr. 3 to user group 1)



(2) Deletion of parameter from the user group (when Pr. 5 is deleted from user group 1)



(3) Set the required value in Pr. 160 to make the user group or groups valid or invalid.

| Pr. 160 Setting | Description |
|-----------------|------------------------------------|
| 0 | Previous parameters read |
| 1 | User group 1's parameters read |
| 10 | User group 2's parameters read |
| 11 | User group 1 and 2 parameters read |

- Note: 1. The Pr. 77, Pr. 160 and Pr. 991 values may always be read independently of the user group setting.
2. The Pr. 173 or Pr. 174 value read indicates the number of parameters registered to group 1, and the Pr. 175 or Pr. 176 value read indicates the number of parameters registered to group 2.
3. If "0" is set in the second digit of two-digit Pr. 160, it is not displayed. However, "0" is displayed when it is set in the first digit only.
4. When "9999" is set in Pr. 174 or Pr. 176, the parameters registered to the corresponding user group are batch-deleted.

4.2.42 Actual operation hour meter clear (Pr. 171)

Pr. 171 "actual operation hour meter clear"

Related parameter

Pr. 52 "control panel/PU main display data selection"

You can clear the monitor (actual operation hour) value which is selected when Pr. 52 is "23".

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 171 | 0 | 0 |

<Setting>

Write "0" in the parameter to clear the actual operation hour.

Pr. 173 to Pr. 176 → Refer to Pr. 160.

4.2.43 Input terminal function selection (Pr. 180 to Pr. 183)

Pr. 180 "RL terminal function selection"

Pr. 181 "RM terminal function selection"

Pr. 182 "RH terminal function selection"

Pr. 183 "MRS terminal function selection"

Use these parameters to select/change the input terminal functions.

| Parameter Number | Terminal Symbol | Factory Setting | Factory-Set Terminal Function | Setting Range |
|------------------|-----------------|-----------------|-------------------------------------|----------------|
| 180 | RL | 0 | Low-speed operation command (RL) | 0 to 8, 16, 18 |
| 181 | RM | 1 | Middle-speed operation command (RM) | 0 to 8, 16, 18 |
| 182 | RH | 2 | High-speed operation command (RH) | 0 to 8, 16, 18 |
| 183 | MRS | 6 | Output shut-off (MRS) | 0 to 8, 16, 18 |

<Setting>

Refer to the following list and set the parameters.

| Setting | Signal Name | Function | | Related Parameters |
|---------|-------------|--|--------------------------------|--|
| 0 | RL | Pr. 59 = 0 | Low-speed operation command | Pr. 4 to Pr. 6 Pr. 24 to Pr. 27 Pr. 232 to Pr. 239 |
| | | Pr. 59 = 1, 2 * | Remote setting (setting clear) | Pr. 59 |
| 1 | RM | Pr. 59 = 0 | Middle-speed operation command | Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239 |
| | | Pr. 59 = 1, 2 * | Remote setting (deceleration) | Pr. 59 |
| 2 | RH | Pr. 59 = 0 | High-speed operation command | Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239 |
| | | Pr. 59 = 1, 2 * | Remote setting (acceleration) | Pr. 59 |
| 3 | RT | Second function selection | | Pr. 44 to Pr. 48 |
| 4 | AU | Current input selection | | |
| 5 | STOP | Start self-holding terminal | | |
| 6 | MRS | Output shut-off terminal | | |
| 7 | OH | External thermal relay input ** The external thermal relay provided for overheat protection or the embedded temperature relay within the motor is activated to stop the inverter. | | Refer to page 157. |
| 8 | REX | 15-speed selection (combination with three speeds of RL, RM, RH) | | Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239 |
| 16 | X16 | PU operation-external operation switch-over | | Pr. 79 |
| 18 | X18 | General-purpose magnetic flux vector-V/F switch-over (OFF: general-purpose magnetic flux vector control, ON: V/F control) (Note 3) | | Pr. 80 |

* : When Pr. 59 = "1" or "2", the functions of the RL, RM and RH signals change as listed above.

** : Activated when the relay contact "opens".

- Note: 1. One function can be assigned to two or more terminals. In this case, the terminal inputs are OR' ed.
2. The speed command priorities are higher in order of multi-speed setting (RH, RM, RL, REX) and AU.
3. When V/F control is selected using the V/F-general-purpose magnetic flux switch-over function, the secondary functions are also selected. During operation, you cannot switch between V/F and general-purpose magnetic flux. Should you switch between V/F and general-purpose magnetic flux, only the secondary functions are selected.
4. Use common terminals to assign multi-speeds (7 speeds) and remote setting. They cannot be set individually. (Common terminals are used since these functions are designed for multiple speed setting and need not be set at the same time.)
5. Functions are invalid if values other than the above are set to Pr. 180 to Pr. 183 (input terminal function selection).

4.2.44 Output terminal function selection (Pr. 190 to Pr. 192)

Pr. 190 "RUN terminal function selection"

Pr. 191 "FU terminal function selection"

Pr. 192 "A, B, C terminal function selection"

You can change the functions of the open collector and contact output terminals.

| Parameter Number | Terminal Symbol | Factory Setting | Factory-Set Terminal Function | Setting Range |
|------------------|-----------------|-----------------|-------------------------------|---------------|
| 190 | RUN | 0 | Inverter running | 0 to 99 |
| 191 | FU | 4 | Output frequency detection | 0 to 99 |
| 192 | ABC | 99 | Alarm output | 0 to 99 |

<Setting>

Refer to the following table and set the parameters:

| Setting | Signal Name | Function | Operation | Related Parameters |
|---------|-------------|-------------------------------------|--|------------------------|
| 0 | RUN | Inverter running | Output during operation when the inverter output frequency rises to or above the starting frequency. | — |
| 1 | SU | Up to frequency | Refer to Pr. 41 "up-to-frequency sensitivity". (Note 1) | Pr. 41 |
| 3 | OL | Overload alarm | Output while stall prevention function is activated. | Pr. 22, Pr. 23, Pr. 66 |
| 4 | FU | Output frequency detection | Refer to Pr. 42, Pr. 43 (output frequency detection). | Pr. 42, Pr. 43 |
| 11 | RY | Inverter operation ready | Output when the inverter is ready to be started by switching the start signal on. | — |
| 12 | Y12 | Output current detection | Refer to Pr. 150 and Pr. 151 (output current detection). | Pr. 150, Pr. 151 |
| 13 | Y13 | Zero current detection | Refer to Pr. 152 and Pr. 153 (zero current detection). | Pr. 152, Pr. 153 |
| 14 | FDN | PID lower limit | Refer to Pr. 128 to Pr. 134 (PID control). | Pr. 128 to Pr. 134 |
| 15 | FUP | PID upper limit | | |
| 16 | RL | PID forward-reverse rotation output | | |
| 98 | LF | Minor fault output | Output when a minor fault (fan failure or communication error warning) occurs. | Pr. 122, Pr. 244 |
| 99 | ABC | Alarm output | Output when the inverter's protective function is activated to stop the output (major fault). | — |

Note: 1. The same function may be set to more than one terminal.
 2. Pr. 190 to Pr. 192 do not function if the values set are other than the above.

Pr. 232 to Pr. 239 → Refer to Pr. 4.

Pr. 240 → Refer to Pr. 72.

4.2.45 Cooling fan operation selection (Pr. 244)

Pr. 244 "cooling fan operation selection"

You can control the operation of the cooling fan built in the inverter 0.75K or more.

(whether there is a cooling fan or not depends on the models. Refer to the outline dimensional drawings (Refer to page 184).

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|---------------|
| 244 | 0 | 0, 1 |

<Setting>

| Setting | Description |
|---------|---|
| 0 | Operated at power on (independent of whether the inverter is running or at a stop). |
| 1 | Cooling fan on-off control valid (The cooling fan is always on while the inverter is running. During a stop, the inverter status is monitored and the fan switches on-off according to temperature.) |

<Reference>

In either of the following cases, fan operation is regarded as faulty, [FN] is shown on the control panel, and the minor fault (LF) signal is output. Use any of Pr. 190 to Pr. 192 (output terminal function selection) to allocate the terminal used to output the LF signal.

1) Pr. 244 = "0"

When the fan comes to a stop with power on.

2) Pr. 244 = "1"

When the inverter is running and the fan stops during fan ON command or the fan starts during fan OFF command.

Note: When the terminal assignment is changed using Pr. 190 to Pr. 192, the other functions may be affected. Confirm the functions of the corresponding terminals before making settings.

4.2.46 Slip compensation (Pr. 245 to Pr. 247)

Pr. 245 "rated motor slip"

Pr. 246 "slip compensation response time"

Pr. 247 "constant-output region slip compensation selection"

The inverter output current may be used to assume motor slip to keep the motor speed constant.

| Parameter Number | Factory Setting | Setting Range | Remarks |
|------------------|-----------------|----------------|------------------------------|
| 245 | 9999 | 0 to 50%, 9999 | 9999: No slip compensation |
| 246 | 0.5 | 0.01 to 10 s | |
| 247 | 9999 | 0, 9999 | 9999: Slip compensation made |

<Setting>

$$\text{Rated slip} = \frac{\text{Synchronous speed at base frequency} - \text{rated speed}}{\text{Synchronous speed at base frequency}} \times 100[\%]$$

| Parameter Number | Setting | Function |
|------------------|--------------|--|
| 245 | 0 to 50% | Used to set the rated motor slip. |
| | 9999 | Slip compensation is not made. |
| 246 | 0.01 to 10 s | Used to set the slip compensation response time. (Note) |
| 247 | 0 | Slip compensation is not made in the constant output range (frequency range above the frequency set in Pr. 3). |
| | 9999 | Slip compensation is made in the constant output range. |

Note: When this value is made smaller, response will be faster.
However, as load inertia is greater, a regenerative overvoltage (OVT) error is more liable to occur.

4.2.47 Stop selection (Pr. 250)

Pr. 250 "stop selection"

Related parameters


- Pr. 7 "acceleration time"
- Pr. 8 "deceleration time"
- Pr. 44 "second acceleration/ deceleration time"
- Pr. 45 "second deceleration time"

Used to select the stopping method (deceleration to a stop or coasting) when the start signal (STF/STR) switches off.

| Parameter Number | Factory Setting | Setting Range |
|------------------|-----------------|--|
| 250 | 9999 | 0 to 100 s, 1000 to 1100 s, 8888, 9999 |


(1) Pr. 250 = "9999"

When the start signal switches off, the motor is decelerated to a stop.



(2) Pr. 250 = 0 to 100 seconds (output is shut off after preset time)

The output is shut off when the time set in Pr. 250 has elapsed after the start signal was switched off. The motor coasts to a stop.



When the Pr. 250 value is 8888, the functions of terminals STF and STR change as shown below:

STF = start signal, STR = rotation direction signal

| STF | STR | Inverter Operating Status |
|-----|-----|---------------------------|
| OFF | OFF | Stop |
| OFF | ON | |
| ON | OFF | Forward rotation |
| ON | ON | Reverse rotation |

When the Pr. 250 value is any of 1000 to 1100s, the functions of terminals STF and STR are the same as when the Pr. 250 value is 8888.

Also, for the stopping method used when the start signal switches off, the output is shut off (the motor coasts to a stop) after the period set in Pr. 250 (i.e. 1000s) have elapsed.

- Note: 1. The RUN signal switches off when the output stops.
 2. When the start signal is switched on again during motor coasting, the motor starts at 0Hz.
 3. When the Pr. 250 value is 0, the output is shut off within the shortest time.

4.2.48 Output phase failure protection selection (Pr. 251)

Pr. 251 "Output phase failure protection selection"

You can make invalid the output phase failure protection (E.LF) function which stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) becomes open.

Choose "without output phase failure protection" when the motor capacity is smaller than the inverter capacity (when the output current is less than approximately 25% of the rated inverter current value as a guideline), since performing operation in such a case may activate output phase failure protection.

| Parameter Number | Setting Range | Minimum Setting Increments | Factory Setting | Description |
|------------------|---------------|----------------------------|-----------------|---|
| 251 | 0, 1 | 1 | 1 | 0: Without output phase failure protection 1: With output phase failure protection |


4.2.49 Meter (frequency meter) calibration (Pr. 901)

Pr. 901 "AM terminal calibration"

Related parameters

- Pr. 55 "frequency monitoring reference"
- Pr. 56 "current monitoring reference"
- Pr. 158 "AM terminal function selection"

- By using the control panel or parameter unit, you can calibrate a meter connected to terminal AM to full scale deflection.
- Terminal AM is factory-set to provide a 10VDC output in the full-scale state of each monitored data. Pr. 901 allows the output voltage ratio (gain) to be adjusted according to the meter reading. Note that the maximum output voltage is 10VDC.



(1) Calibration of terminal AM

- 1) Connect a 0-10VDC meter (frequency meter) across inverter terminals AM-5. (Note the polarity. AM is the positive terminal.)
- 2) Set any of "0, 1, 2" in Pr. 158.
When the running frequency or inverter output current has been selected as the output signal, preset in Pr. 55 or Pr. 56 the running frequency or current at which the output signal is 10V.

<Operation procedure>

- When using the control panel (FR-PA02-02)

1) Select the PU operation mode.

2) Set the running frequency.

3) Press the **SET** key.

4) Read Pr. 901 "AM terminal calibration".

5) Press the **FWD** key to run the inverter. (Motor need not be connected.)

6) Hold down the **▲**/**▼** key to adjust the meter pointer to a required position.
(Depending on the setting, it may take some time until the pointer moves.)

7) Press the **SET** key for about 1.5 s.

8) Press the **STOP
RESET** key to stop the inverter.

REMARKS

Calibration can also be made for external operation. Set the frequency in the external mode and make calibration in the steps 4) to 8).

Note: It is possible to calibrate even during operation.

4.2.50 Biases and gains of the frequency setting voltage (current) (Pr. 902 to Pr. 905)

Pr. 902 "frequency setting voltage bias"

Pr. 903 "frequency setting voltage gain"

Pr. 904 "frequency setting current bias"


Pr. 905 "frequency setting current gain"

Related parameters
 Pr. 38 "frequency at 5V (10V) input"
 Pr. 39 "frequency at 20mA input"
 Pr. 73 "0-5/0-10V selection"
 Pr. 79 "operation mode selection"

The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter (to set the output frequency), i.e. 0 to 5VDC, 0 to 10VDC or 4 to 20mADC, and the output frequency.

- Use Pr. 902 to set the bias of the voltage signal and use Pr. 903 to set its gain.
- Use Pr. 904 to set the bias of the current signal and use Pr. 905 to set its gain.

| Parameter Number | Factory Setting | | Setting Range | |
|------------------|-----------------|-------|---------------|------------|
| | Setting | Value | Setting | Value |
| 902 | 0V | 0Hz | 0 to 10V | 0 to 60Hz |
| 903 | 5V | 50Hz | 0 to 10V | 1 to 400Hz |
| 904 | 4mA | 0Hz | 0 to 20mA | 0 to 60Hz |
| 905 | 20mA | 50Hz | 0 to 20mA | 1 to 400Hz |



<Setting>


- (1) The frequency setting voltage (current) biases and gains may be adjusted by any of the three following ways:
- 1) Any point can be adjusted with a voltage applied across terminals 2-5 (with a current flowing across terminals 4-5).
 - 2) Any point can be adjusted with no voltage applied across terminals 2-5 (with no current flowing across terminals 4-5).
 - 3) Only the bias and gain frequencies are adjusted and the voltage (current) is not adjusted.

Pr. 903 "frequency setting voltage gain"

(Pr. 902, Pr. 904, Pr. 905 can also be adjusted similarly.)


<Adjustment procedure> When using an external frequency setting signal to set the frequency.

(1) Power-on (monitoring mode)



(2) Choose the PU operation mode.

1) Using the **MODE** key, make sure that the PU operation mode has been selected.



●Monitoring mode

●Frequency setting mode

●Parameter setting mode

●Operation mode (PU operation mode)

●Help mode




Confirm that the PU operation mode (**PU**) has been chosen.
 In the JOG operation mode (**JOG**) or external operation mode (**OPNd**), press the **▲/▼** key to display **PU**.
 If **PU** cannot be displayed by pressing the **▲/▼** key in the external operation mode (**OPNd**).
 (if Pr. 79 "operation mode selection" ≠ "0"), refer to 2) and set "1" (PU operation mode) in Pr. 79 "operation mode selection".

2) Set "1" (PU operation mode) in Pr. 79 "operation mode selection".

Example: To change the external operation mode (Pr. 79=2) to the PU operation mode (Pr. 79=1)

Using the **MODE** key, choose the "parameter setting mode" as in 1).

●Parameter setting mode





---If **Err** appears, make sure that the forward rotation (STF) or reverse rotation (STR) signal connected to the control terminal is not on. If it is on, turn it off.

---"1" (PU operation mode) has been set in Pr. 79. If **P. 80** appears, you did not press the **SET** key for 1.5 seconds when writing the setting. Press the **▲** key once, press the **SET** key, and restart the setting from the beginning.


(3) Read Pr. 903 and show the current setting of the gain frequency.
 (Pr. 902, Pr. 904 and Pr. 905 can also be adjusted similarly.)

●Parameter setting mode

Using the **MODE** key, choose the "parameter setting mode" as in (2)-1).



(4) Set a gain frequency in Pr. 903 and show the analog voltage A/D value across terminals 2-5 in %.
 (when the frequency is set to 80Hz)



In any of the methods in (5) to (7) on the following page, continue the setting until the analog voltage A/D value flickers. If you end the setting here, the gain frequency change will not be reflected.

- 1) When not adjusting the gain voltage → To (5)
- 2) When adjusting any point by applying a voltage → To (6)
- 3) When adjusting any point without applying a voltage → To (7)

(5) How to adjust the gain frequency only without the voltage being adjusted

● Analog voltage A/D value (%) across terminals 2-5




● Press the ▲ or ▼ key once to display the current analog voltage adjustment.



Example: When analog voltage adjustment value is 100% (5V)

Press for 1.5 s




Flicker



(6) How to adjust any point by applying a voltage across terminals 2-5 (e.g. from the external potentiometer) (current: across terminals 4-5) (when applying 5V)


● Analog voltage A/D value (%) across terminals 2-5



● Apply a 5V voltage. (Turn the external potentiometer connected across terminals 2-5 to maximum.)



Press for 1.5 s




Flicker



When the potentiometer is at the maximum position, the value is nearly 100 (%).

(7) How to adjust any point without applying a voltage across terminals 2-5
 (without a current flowing across terminals 4-5)
 (when changing from 4V (80%) to 5V (100%))



(8) Press the **SET** key to shift to the next parameter.

(9) Re-set Pr. 79 "operation mode selection" according to the operation mode to be used.

Note: 1. If the Pr. 903 or Pr. 905 (gain adjustment) value is changed, the Pr. 20 value does not change.
 2. When the Pr. 903 or Pr. 905 value is set, the value of Pr. 38 "frequency at 5V (10V) input" or Pr. 39 "frequency at 20mA input" changes automatically.

! CAUTION

! Be careful when setting the bias frequency at 0V to any value other than "0". Even without the speed command, the motor will start running at the set frequency by merely switching on the start signal.

CHAPTER 5

PROTECTIVE FUNCTIONS

This chapter explains the "protective functions" of this product.

Always read the instructions before using the equipment.

| | |
|--|-----|
| 5.1 Errors (Alarms) | 157 |
| 5.2 Troubleshooting | 166 |
| 5.3 Precautions for Maintenance and Inspection | 169 |

Chapter 1

Chapter 2

Chapter 3

Chapter 4

Chapter 5

Chapter 6

5.1 Errors (Alarms)

PROTECTIVE FUNCTIONS

If any fault has occurred in the inverter, the corresponding protective function is activated to bring the inverter to an alarm stop and automatically give the corresponding error (alarm) indication on the optional control panel or the parameter unit display.


If your fault does not correspond to any of the following errors or if you have any other problem, please contact your sales representative.


- Retention of alarm output signal When the magnetic contactor (MC) provided on the power supply side of the inverter is opened at the activation of the protective function, the inverter's control power will be lost and the alarm output will not be held.
- Alarm indication When the protective function is activated, the operation panel display automatically switches to the above indication.
- Resetting method When the protective function is activated, the inverter output is kept stopped. Unless reset, therefore, the inverter cannot restart. Switch power off once, then on again; or apply RES signal for more than 0.1 seconds. Kept on, "Err." appears (flickers) to indicate that the inverter is being reset.
- When the protective function is activated, take the corresponding corrective action, then reset the inverter, and resume operation.

5.1.1 Error (alarm) definitions

(1) Major faults

When the protective function is activated, the inverter output is shut off and the alarm is output.

| | | | | |
|-----------------------------------|---|---|---------|---------------|
| Operation Panel Indication | E. OC1 |  | FR-PU04 | OC During Acc |
| Name | Overcurrent shut-off during acceleration | | | |
| Description | When the inverter output current reaches or exceeds approximately 200% of the rated current during acceleration, the protective circuit is activated to stop the inverter output. | | | |
| Check point | Check for sudden acceleration. Check for output short-circuit/ground fault. | | | |
| Corrective action | Increase the acceleration time. | | | |

| | | | | |
|-----------------------------------|---|---|---------|--------------|
| Operation Panel Indication | E. OC2 |  | FR-PU04 | Stedy Spd OC |
| Name | Overcurrent shut-off during constant speed | | | |
| Description | When the inverter output current reaches or exceeds approximately 200% of the rated current during constant speed, the protective circuit is activated to stop the inverter output. | | | |
| Check point | Check for sudden load change. Check for output short-circuit/ground fault. | | | |
| Corrective action | Keep load stable. | | | |

PROTECTIVE FUNCTIONS

| | | | | |
|-----------------------------------|---|---------------|----------------|---------------|
| Operation Panel Indication | E. OC3 | E.O.C3 | FR-PU04 | OC During Dec |
| Name | Overcurrent shut-off during deceleration | | | |
| Description | When the inverter output current reaches or exceeds approximately 200% of the rated current during deceleration (other than acceleration or constant speed), the protective circuit is activated to stop the inverter output. | | | |
| Check point | Check for sudden speed reduction. Check for output short-circuit/ground fault. Check for too fast operation of motor's mechanical brake. | | | |
| Corrective action | Increase the deceleration time. Adjust brake operation. | | | |

| | | | | |
|-----------------------------------|--|---------------|----------------|---------------|
| Operation Panel Indication | E. OV1 | E.O.V1 | FR-PU04 | OV During Acc |
| Name | Regenerative overvoltage shut-off during acceleration | | | |
| Description | If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. It may also be activated by a surge voltage generated in the power supply system. | | | |
| Check point | Check for too slow acceleration. | | | |
| Corrective action | Decrease the acceleration time. | | | |

| | | | | |
|-----------------------------------|--|---------------|----------------|--------------|
| Operation Panel Indication | E. OV2 | E.O.V2 | FR-PU04 | Stedy Spd OV |
| Name | Regenerative overvoltage shut-off during constant speed | | | |
| Description | If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. It may also be activated by a surge voltage generated in the power supply system. | | | |
| Check point | Check for sudden load change. | | | |
| Corrective action | <ul style="list-style-type: none"> • Keep load stable. • Use the brake unit or high power factor converter (FR-HC) as required. | | | |

| | | | | |
|-----------------------------------|---|---------------|----------------|---------------|
| Operation Panel Indication | E. OV3 | E.O.V3 | FR-PU04 | OV During Dec |
| Name | Regenerative overvoltage shut-off during deceleration or stop | | | |
| Description | If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. It may also be activated by a surge voltage generated in the power supply system. | | | |
| Check point | Check for sudden speed reduction. | | | |
| Corrective action | <ul style="list-style-type: none"> • Increase the deceleration time. (Set the deceleration time which matches the inertia moment of the load.) • Decrease the braking duty. • Use the brake unit or high power factor converter (FR-HC) as required. | | | |

PROTECTIVE FUNCTIONS

| | | | | |
|-----------------------------------|--|---------------|----------------|----------------|
| Operation Panel Indication | E. THM | E. THM | FR-PU04 | Motor Overload |
| Name | Motor overload shut-off (electronic overcurrent protection) (Note 1) | | | |
| Description | The electronic overcurrent protection in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation to stop the inverter output. When a multi-pole motor or two or more motors are run, provide a thermal relay in the output side of the inverter. | | | |
| Check point | Check the motor for use under overload. | | | |
| Corrective action | <ul style="list-style-type: none"> • Reduce the load weight. • For the constant-torque motor, change the Pr. 71 setting to the constant-torque motor setting. | | | |

| | | | | |
|-----------------------------------|---|---------------|----------------|---------------|
| Operation Panel Indication | E. THT | E. THT | FR-PU04 | Inv. Overload |
| Name | Inverter overload shut-off (electronic overcurrent protection) (Note 1) | | | |
| Description | If a current of more than 150% of the rated output current flows and overcurrent shut-off does not occur (200% or less), inverse-time characteristics cause the electronic overcurrent protection to be activated to stop the inverter output in order to protect the output transistors. | | | |
| Check point | Check the motor for use under overload. | | | |
| Corrective action | Reduce the load weight. | | | |

Note:1 Resetting the inverter initializes the internal heat integrating data of the electronic overcurrent protection.

| | | | | |
|-----------------------------------|--|---------------|----------------|---------------|
| Operation Panel Indication | E. FIN | E. FIN | FR-PU04 | H/Sink O/Temp |
| Name | Fin overheat | | | |
| Description | If the cooling fin overheats, the overheat sensor is actuated to stop the inverter output. | | | |
| Check point | <ul style="list-style-type: none"> • Check for too high ambient temperature. • Check for cooling fin clogging. | | | |
| Corrective action | Set the ambient temperature to within the specifications. | | | |

| | | | | |
|-----------------------------------|--|--------------|----------------|-----------------------|
| Operation Panel Indication | E. BE | E. bE | FR-PU04 | Br. Cct. Fault (Note) |
| Name | Brake transistor alarm detection (Note 2) | | | |
| Description | If a brake transistor fault occurs due to excessively large regenerative energy from the motor, for example, that fault is detected to stop the inverter output. <u>In this case, the inverter power must be switched off immediately.</u> | | | |
| Check point | Check for improper braking duty. | | | |
| Corrective action | Change the inverter. Please contact your sales representative. | | | |

Note:2 This function is activated only when the optional brake resistor is connected.

| | | | | |
|-----------------------------------|--|--------------|----------------|--------------|
| Operation Panel Indication | E. GF | E. GF | FR-PU04 | Ground Fault |
| Name | Output side ground fault overcurrent protection | | | |
| Description | This function stops the inverter output if a ground fault overcurrent flows due to a ground fault which occurred in the inverter's output (load) side. | | | |
| Check point | Check for a ground fault in the motor and connection cable. | | | |
| Corrective action | Remedy the ground fault portion. | | | |

| | | | | |
|-----------------------------------|---|--------------|----------------|----------|
| Operation Panel Indication | E. OHT | E.OHT | FR-PU04 | OH Fault |
| Name | External thermal relay operation (Note 3) | | | |
| Description | If the external thermal relay designed for motor overheat protection or the internally mounted temperature relay in the motor switches on (contacts open), the inverter output is stopped. If the relay contacts are reset automatically, the inverter will not restart unless it is reset. | | | |
| Check point | <ul style="list-style-type: none"> • Check for motor overheating. • Check that the value of 7 (OH signal) is set correctly in any of Pr. 180 to Pr. 183 (input terminal function selection). | | | |
| Corrective action | Reduce the load and operating duty. | | | |

Note:3 This function is activated only when OH has been set to any of Pr. 180 to Pr. 183 (input terminal function selection).

| | | | | |
|-----------------------------------|--|--------------|----------------|----------------|
| Operation Panel Indication | E. OLT | E.OLT | FR-PU04 | Still Prev STP |
| Name | Stall prevention | | | |
| Description | The running frequency has fallen to 0 by stall prevention activated. (OL while stall prevention is being activated.) | | | |
| Check point | Check the motor for use under overload. | | | |
| Corrective action | Reduce the load weight. | | | |

PROTECTIVE FUNCTIONS

| | | | | |
|-----------------------------------|--|--------------|---------|--------------|
| Operation Panel Indication | E.OPT | E.OPT | FR-PU04 | Option Fault |
| Name | Option alarm | | | |
| Description | Stops the inverter output if the inverter station is disconnected from the system in the NET mode. Also stops the inverter output if the dedicated option used in the inverter results in setting error or connection (connector) fault. | | | |
| Check point | Check that the plug-in option connector is plugged securely. | | | |
| Corrective action | Connect the plug-in option securely. Please contact your sales representative. | | | |

| | | | | |
|-----------------------------------|---|--------------|---------|---------------|
| Operation Panel Indication | E. PE | E. PE | FR-PU04 | Corrupt Memry |
| Name | Parameter storage device alarm | | | |
| Description | A fault occurred in parameters stored (example: E ² PROM fault). | | | |
| Check point | Check for too many number of parameter write times. | | | |
| Corrective action | Please contact your sales representative. | | | |

| | | | | |
|-----------------------------------|--|--------------|---------|--------------|
| Operation Panel Indication | E. PUE | E.PUE | FR-PU04 | PU Leave Out |
| Name | Parameter unit disconnection | | | |
| Description | This function stops the inverter output if communication between the inverter and PU is suspended, e.g. the PU is disconnected, when "2", "3", "16" or "17" was set in Pr. 75. This function stops the inverter output if the number of successive communication errors is greater than the number of permissible retries when the Pr. 121 value is "9999" for RS-485 communication from the PU connector. | | | |
| Check point | <ul style="list-style-type: none"> • Check for loose fitting of the control panel (FR-PA02-02) or FR-PU04. • Check the Pr. 75 setting. | | | |
| Corrective action | Fit the control panel (FR-PA02-02) and FR-PU04 securely. | | | |

| | | | | |
|-----------------------------------|--|---------------|---------|---------------|
| Operation Panel Indication | E. RET | E.r ET | FR-PU04 | Retry No Over |
| Name | Retry count exceeded | | | |
| Description | If operation cannot be resumed properly within the number of retries set, this function stops the inverter output. | | | |
| Check point | Find the cause of alarm occurrence. | | | |
| Corrective action | Eliminate the cause of the error preceding this error indication. | | | |

| | | | | |
|-----------------------------------|---|--------------|---------|-----------|
| Operation Panel Indication | E. CPU | E.CPU | FR-PU04 | CPU Fault |
| Name | CPU error | | | |
| Description | If the arithmetic operation of the built-in CPU does not end within a predetermined period, the inverter self-determines it as an alarm and stops the output. | | | |
| Check point | _____ | | | |
| Corrective action | Please contact your sales representative. | | | |

| | | | | |
|-----------------------------------|--|-------------|---------|---------|
| Operation Panel Indication | E. 6 | <i>E. 6</i> | FR-PU04 | Fault 6 |
| | E. 7 | <i>E. 7</i> | | Fault 7 |
| Name | CPU error | | | |
| Description | This function stops the inverter output if a communication error occurs in the built-in CPU. | | | |
| Check point | _____ | | | |
| Corrective action | Please contact your sales representative. | | | |


| | | | | |
|-----------------------------------|---|------------|---------|-------|
| Operation Panel Indication | E. LF | <i>ELF</i> | FR-PU04 | E. LF |
| Name | Output phase failure protection | | | |
| Description | This function stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) results in open phase. | | | |
| Check point | <ul style="list-style-type: none"> • Check the wiring (Check the motor for a fault.) • Check that the capacity of the used motor is not smaller than the inverter capacity. | | | |
| Corrective action | <ul style="list-style-type: none"> • Wire the cables properly. • Check the setting of Pr. 251 "output phase failure protection selection". | | | |

(2) Minor fault

The output is not shut off when the protective function is activated. You can make parameter setting to output the minor fault signal. (Set "98" in any of Pr. 190 to Pr. 192 (output terminal function selection). Refer to page 144.)



| | | | | |
|-----------------------------------|---|----------------------|---------|-------------|
| Operation Panel Indication | FN | <i>F_n</i> | FR-PU04 | Fan Failure |
| Name | Fan fault | | | |
| Description | For the inverter which contains a cooling fan, FN appears on the operation panel when the cooling fan stops due to a fault or operates differently from the setting of Pr. 244 "cooling fan operation selection". | | | |
| Check point | Check the cooling fan for a fault. | | | |
| Corrective action | Change the fan. | | | |

(3) Warnings

| | | | | |
|-----------------------------------|--|--|---------|----|
| Operation Panel Indication | OL |  | FR-PU04 | OL |
| Name | Stall prevention (over current) | | | |
| Description | During acceleration | If a current of more than 150% (Note 4) of the rated inverter current flows in the motor, this function stops the increase in frequency until the overload current reduces to prevent the inverter from resulting in over current shut-off. When the overload current has reduced below 150%, this function increases the frequency again. | | |
| | During constant-speed operation | If a current of more than 150% (Note 4) of the rated inverter current flows in the motor, this function lowers the frequency until the overload current reduces to prevent overcurrent shut-off. When the overload current has reduced below 150%, this function increases the frequency up to the set value. | | |
| | During deceleration | If a current of more than 150% (Note 4) of the rated inverter current flows in the motor, this function stops the decrease in frequency until the overload current reduces to prevent the inverter from resulting in overcurrent shut-off. When the overload current has reduced below 150%, this function decreases the frequency again. | | |
| Check point | Check the motor for use under overload. | | | |
| Corrective action | The acceleration/deceleration time may change. Increase the stall prevention operation level with Pr. 22 "stall prevention operation level", or disable stall prevention with Pr. 156 "stall prevention operation selection". | | | |

Note:4 The stall prevention operation current can be set as desired. It is factory-set to 150%.

| | | | | |
|-----------------------------------|---|---|---------|----|
| Operation Panel Indication | oL | <i>oL</i> | FR-PU04 | oL |
| Name | Stall prevention (overvoltage) | | | |
| Description | During deceleration | If the regenerative energy of the motor increases too much to exceed the brake capability, this function stops the decrease in frequency to prevent overvoltage shut-off. As soon as the regenerative energy has reduced, deceleration resumes. | | |
| Check point | Check for sudden speed reduction. | | | |
| Corrective action | The deceleration time may change. Increase the deceleration time using Pr. 8 "deceleration time". | | | |

| | | | | |
|-----------------------------------|---|-----------|---------|----|
| Operation Panel Indication | PS | <i>PS</i> | FR-PU04 | PS |
| Name | PU stop | | | |
| Description | A stop made by pressing the  key of the PU has been set in Pr. 75 "PU stop selection". | | | |
| Check point | Check for a stop made by pressing the  key of the operation panel during external operation. | | | |
| Corrective action | Refer to page 101. | | | |

| | | | | |
|-----------------------------------|--|-------------|--|--|
| Operation Panel Indication | Err. | <i>Err.</i> | | |
| Description | <p>This alarm appears if:</p> <ul style="list-style-type: none"> • The RES signal is on; • You attempted to set any parameter value in the external operation mode; • You attempted to change the operation mode during operation; • You attempted to set any parameter value outside its setting range. • You attempted to set any parameter value during operation (while signal STF or STR is ON). • You attempted to set any parameter value while parameter write is being inhibited in Pr. 77 "parameter write inhibit selection". | | | |
| Corrective action | Perform operation correctly. | | | |

5.1.2 To know the operating status at the occurrence of alarm

When any alarm has occurred, the display automatically switches to the indication of the corresponding protective function (error). By pressing the **MODE** key at this point without resetting the inverter, the display shows the output frequency. In this way, it is possible to know the running frequency at the occurrence of the alarm. This also applies to the current. After resetting, you can confirm the data in the alarm history (refer to page 54).

5.1.3 Correspondence between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the control panel (FR-PA02-02):

| Actual | Display | Actual | Display | Actual | Display |
|--------|---------|--------|---------|--------|---------|
| 0 | 0 | A | A | M | 7 |
| 1 | 1 | B | b | N | 7 |
| 2 | 2 | C | C | O | 0 |
| 3 | 3 | D | d | o | 0 |
| 4 | 4 | E | E | P | P |
| 5 | 5 | F | F | S | S |
| 6 | 6 | G | G | T | T |
| 7 | 7 | H | H | U | U |
| 8 | 8 | I | I | V | V |
| 9 | 9 | J | J | r | r |
| | | L | L | - | - |

5.1.4 Resetting the inverter

The inverter can be reset by performing any of the following operations. Note that the electronic overcurrent protection's internal heat calculation value and the number of retries are cleared (erased) by resetting the inverter.

Operation 1: Using the control panel (FR-PA02-02), press the **STOP RESET** key to reset the inverter.

(This may only be performed when the inverter protective function (major fault) is activated.)

Operation 2: Switch power off once, then switch it on again.

Operation 3: Switch on the reset signal (RES).

5.2 Troubleshooting

PROTECTIVE FUNCTIONS

POINT: Check the corresponding areas. If the cause is still unknown, it is recommended to initialize the parameters (return to factory settings), re-set the required parameter values, and check again.

5.2.1 Motor remains stopped

(1) Check the main circuit

- Check that a proper power supply voltage is applied (control panel display is provided).
- Check that the motor is connected properly.
- Check that the conductor across P1-+ is connected.

(2) Check the input signals

- Check that the start signal is input.
- Check that both the forward and reverse rotation start signals are not input.
- Check that the frequency setting signal is not zero.
- Check that the AU signal is on when the frequency setting signal is 4 to 20mA.
- Check that the output stop signal (MRS) or reset signal (RES) is not on.
- Check that the sink/source connector is fitted securely.

(3) Check the parameter settings

- Check that the reverse rotation prevention (Pr. 78) is not selected.
- Check that the operation mode (Pr. 79) setting is correct.
- Check that the bias and gain (Pr. 902 to Pr. 905) settings are correct.
- Check that the starting frequency (Pr. 13) setting is not greater than the running frequency.
- Check that various operational functions (such as three-speed operation), especially the maximum frequency (Pr. 1), are not zero.
- Check that the manufacturer setting parameter Pr. 146 = 1.

(4) Check the load

- Check that the load is not too heavy.
- Check that the shaft is not locked.

(5) Others

- Check that the ALARM lamp is off.
- Check that the control panel display does not show an error (e.g. E.OC1).
- Check that the Pr. 15 "jog frequency" setting is not lower than the Pr. 13 "starting frequency" value.

5.2.2 Motor rotates in opposite direction

- Check that the phase sequence of output terminals U, V and W is correct.
- Check that the start signals (forward rotation, reverse rotation) are connected properly.

5.2.3 Speed greatly differs from the setting

- Check that the frequency setting signal is correct. (Measure the input signal level.)
- Check that the following parameter settings are correct (Pr. 1, Pr. 2, Pr. 19, Pr. 38, Pr. 39, Pr. 245, Pr. 902 to Pr. 905).
- Check that the input signal lines are not affected by external noise. (Use shielded cables)
- Check that the load is not too heavy.

5.2.4 Acceleration/deceleration is not smooth

- Check that the acceleration and deceleration time settings are not too short.
- Check that the load is not too heavy.
- Check that the torque boost setting is not too large to activate the stall prevention function.

5.2.5 Motor current is large

- Check that the load is not too heavy.
- Check that the torque boost setting is not too large.

5.2.6 Speed does not increase

- Check that the maximum frequency setting is correct.
- Check that the load is not too heavy. (In agitators, etc., load may become heavier in winter.)
- Check that the torque boost setting is not too large to activate the stall prevention function.
- Check that the brake resistor is not connected to terminals + - P1 accidentally.

5.2.7 Speed varies during operation

When slip compensation is selected, the output frequency varies with load fluctuation between 0 and 2Hz. This is a normal operation and is not a fault.

(1) Inspection of load

- Check that the load is not varying.

(2) Inspection of input signal

- Check that the frequency setting signal is not varying.
- Check that the frequency setting signal is not affected by noise.
- Check that a malfunction does not occur due to an undesirable current when the transistor output unit is connected, for example. (Refer to page 23.)

3) Others

- Check that the setting of the applied motor capacity (Pr. 80) is correct for the inverter capacities in general-purpose magnetic flux vector control.
- Check that the wiring length is within 30m in general-purpose magnetic flux vector control.
- Check that the wiring length is correct in V/F control.

5.2.8 Operation mode is not changed properly

If the operation mode does not change correctly, check the following:

1. External input signal Check that the STF or STR signal is off.
When it is on, the operation mode cannot be changed.

2. Parameter setting Check the Pr. 79 setting.
When the setting of Pr. 79 "operation mode selection" is "0", switching input power on places the inverter in the external operation mode. By pressing the **MODE** key twice and pressing the **▲** key, the external operation mode changes to the PU operation mode.
For any other setting (1 to 8), the operation mode is limited according to the setting.
(For details of Pr. 79, refer to page 105.)

5.2.9 Control panel display is not operating

- Make sure that the control panel is connected securely with the inverter.
- Check for a short circuit across terminals PC-SD.
- Check that the jumper across terminals + - P1 is fitted securely.

5.2.10 POWER lamp is not lit

- Make sure that the wiring and installation are correct.

5.2.11 Parameter write cannot be performed

- Make sure that operation is not being performed (signal STF or STR is not ON).
- Make sure that you pressed the **SET** key (**WRITE** key) for longer than 1.5 seconds.
- Make sure that you are not attempting to set the parameter outside the setting range.
- Make sure that you are not attempting to set the parameter in the external operation mode.
- Check Pr. 77 "parameter write inhibit selection".

5.3 Precautions for Maintenance and Inspection

PROTECTIVE FUNCTIONS

The transistorized inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to adverse influence by the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

5.3.1 Precautions for maintenance and inspection

For some short time after the power is switched off, a high voltage remains in the smoothing capacitor. Therefore, when more than 10 minutes have elapsed after power-off, make sure that the voltage across the main circuit terminals + - - of the inverter is 30VDC or less using a meter, etc. Then, access the inverter for inspection.

5.3.2 Check items

(1) Daily inspection

- Check the following:
 - 1) Motor operation fault
 - 2) Improper installation environment
 - 3) Cooling system fault
 - 4) Unusual vibration and noise
 - 5) Unusual overheating and discoloration
- During operation, check the inverter input voltages using a meter.

(2) Cleaning

Always run the inverter in a clean state.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.

Note: Do not use solvent, such as acetone, benzene, toluene and alcohol, as they will cause the inverter surface paint to peel off.

Do not use detergent or alcohol to clean the display and other sections of the control panel as these sections may deform.


5.3.3 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

- (1) Cooling system:Clean the air filter, etc.
- (2) Screws and bolts: ...These parts may become loose due to vibration, temperature changes, etc. Check that they are tightened securely and retighten as necessary.
- (3) Conductors and insulating materials: Check for corrosion and damage.
- (4) Insulation resistance: Measure.
- (5) Cooling fan, smoothing capacitor: Check and change if necessary.

5.3.4 Insulation resistance test using megger

- (1) Before performing the insulation resistance test using a megger on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.
- (2) For the continuity test of the control circuit, use a meter (high resistance range) and do not use the megger or buzzer.
- (3) For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500VDC megger.)



5.3.5 Pressure test

Do not conduct a pressure test. The inverter's main circuit uses semiconductors, which may deteriorate if a pressure test is made.

5.3.6 Daily and Periodic Inspection

| Area of Inspection | Inspection Item | Description | Interval | | | Method | Criterion | Instrument |
|--------------------|----------------------------------|---|----------|-----------|---------|--|---|-----------------------------------|
| | | | Daily | Periodic* | | | | |
| | | | | 1 year | 2 years | | | |
| General | Surrounding environment | Check ambient temperature, humidity, dust, dirt, etc. | ○ | | | Refer to page 11. | Ambient temperature: -10°C to +50°C, non-freezing. Ambient humidity: 90% or less, non-condensing. | Thermometer, hygrometer, recorder |
| | Overall unit | Check for unusual vibration and noise. | ○ | | | Visual and auditory checks. | No fault. | |
| | Power supply voltage | Check that main circuit voltage is normal. | ○ | | | Measure voltage across inverter terminals L1-L2-L3. | Within permissible AC voltage fluctuation (see page 180) | Meter, digital multimeter |
| Main circuit | General | (1) Check with megger (across main circuit terminals and ground terminal). (2) Check for loose screws and bolts. (3) Check for overheat on each part. (4) Clean. | | | ○ | (1) Disconnect all cables from inverter and measure across terminals L1, L2, L3, U, V, W and ground terminal with megger. (2) Retighten. (3) Visual check. | (1) 5MΩ or more. (2), (3) No fault. | 500VDC class megger |
| | Conductors, cables | (1) Check conductors for distortion. (2) Check cable sheaths for breakage. | | ○ | | (1), (2) Visual check. | (1), (2) No fault. | |
| | Terminal block | Check for damage. | | ○ | | Visual check | No fault | |
| | Inverter module Converter module | Check resistance across terminals. | | | ○ | Disconnect cables from inverter and measure across terminals L1, L2, L3 ↔ +, -, and across U, V, W ↔ +, - with a meter with a 100Ω range. | Refer to page 173. | Analog meter |
| | Smoothing capacitor | (1) Check for liquid leakage. (2) Check for safety valve projection and bulge. (3) Measure electrostatic capacity. | ○ | | | (1), (2) Visual check. (3) Measure with capacity meter. | (1), (2) No fault. (3) 85% or more of rated capacity. | Capacity meter |

PROTECTIVE FUNCTIONS

| Area of Inspection | Inspection Item | Description | Interval | | Method | Criterion | Instrument | |
|---------------------------------------|-----------------------|--|----------|-----------|---|---|--|---------|
| | | | Daily | Periodic* | | | | |
| | | | | 1 year | | | | 2 years |
| Main circuit | Relay | (1) Check for chatter during operation. (2) Check for rough surface on contacts. | ○ | ○ | (1) Auditory check. (2) Visual check. | (1) No fault. (2) No fault. | | |
| Control circuit Protective circuit | Operation check | (1) Check balance of output voltages across phases with inverter operated independently. (2) Perform sequence protective operation test to make sure there is no fault in protective or display circuits. | ○ | ○ | (1) Measure voltage across inverter output terminals U-V-W. (2) Simulate connection of inverter protective circuit output terminals. | (1) Phase-to-phase voltage balance within 8V (4V) for 400V (200V). (2) Fault must occur because of sequence. | Digital multimeter, rectifier type voltmeter | |
| Cooling system | Cooling fan | (1) Check for unusual vibration and noise. (2) Check for loose connection. | ○ | ○ | (1) Turn by hand with power off. (2) Visual check. | No unusual vibration and unusual noise. | | |
| Display | Display | (1) Check for LED lamp blown. (2) Clean. | ○ | ○ | (1) Lamps indicate indicator lamps on panel. (2) Clean with rag. | (1) Check that lamps are lit. | | |
| | Meter | Check that reading is normal. | ○ | ○ | Check reading of meters on panel. | Must satisfy specified and management values. | Voltmeter, ammeter, etc. | |
| Motor | General | (1) Check for unusual vibration and noise. (2) Check for unusual odor. | ○ | ○ | (1) Auditory, sensory, visual checks. (2) Check for unusual odor due to overheat, damage, etc. | (1), (2) No fault. | | |
| | Insulation resistance | Check with megger (across terminals and ground terminal). | ○ | ○ | Disconnect cables from U, V, W, including motor cables. | 5MΩ or more. | 500V megger | |

Note: The values within the parentheses are for the 200V class.

* For periodic inspection, contact you nearest Mitsubishi sales representative.

● **Checking the inverter and converter modules**

<Preparation>

- (1) Disconnect the external power supply cables (L1, L2, L3) and motor cables (U, V, W).
- (2) Prepare a meter. (Use 100Ω range.)

<Checking method>


Change the polarity of the meter alternately at the inverter terminals L1, L2, L3, U, V, W, + and –, and check for continuity.

Note: 1. Before measurement, check that the smoothing capacitor is discharged.
 2. At the time of continuity, the measured value is several to several ten's-of ohms depending on the number of modules, number of parallel modules, circuit tester type, etc. If all measured values are almost the same, the modules are without fault.

<Module device numbers and terminals to be checked>

| | | Tester Polarity | | Measured Value | | | Tester Polarity | | Measured Value |
|------------------|-----|-----------------|----|----------------|-----|----|-----------------|---------------|----------------|
| | | ⊕ | ⊖ | | | | ⊕ | ⊖ | |
| Converter module | D1 | L1 | + | Discontinuity | D4 | L1 | – | Continuity | |
| | | + | L1 | Continuity | | – | L1 | Discontinuity | |
| | D2 | L2 | + | Discontinuity | D5 | L2 | – | Continuity | |
| | | + | L2 | Continuity | | – | L2 | Discontinuity | |
| | D3 | L3 | + | Discontinuity | D6 | L3 | – | Continuity | |
| | | + | L3 | Continuity | | – | L3 | Discontinuity | |
| Inverter module | TR1 | U | + | Discontinuity | TR4 | U | – | Continuity | |
| | | + | U | Continuity | | – | U | Discontinuity | |
| | TR3 | V | + | Discontinuity | TR6 | V | – | Continuity | |
| | | + | V | Continuity | | – | V | Discontinuity | |
| | TR5 | W | + | Discontinuity | TR2 | W | – | Continuity | |
| | | + | W | Continuity | | – | W | Discontinuity | |

(Assumes the use of an analog meter.)



Note: The FR-E520S-0.4K to 2.2K do not have L3, D3 and D6.

5.3.7 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices. The following parts may deteriorate with age because of their structural or physical characteristics, leading to reduced performance or failure of the inverter. For preventive maintenance, the parts must be changed periodically.

| Part Name | Standard Replacement Interval | Description |
|--------------------------------------|--------------------------------------|---------------------------------|
| Cooling fan | 2 to 3 years | Change (as required) |
| Smoothing capacitor in main circuit | 5 years | Change (as required) |
| Smoothing capacitor on control board | 5 years | Change the board (as required). |

Note: For part replacement, contact the nearest Mitsubishi FA center.


(1) Cooling fan

The cooling fan cools heat-generating parts such as the main circuit semiconductor devices. The life of the cooling fan bearing is usually 10,000 to 35,000 hours. Hence, the cooling fan must be changed every 2 to 3 years if the inverter is run continuously. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be changed immediately.

| Inverter Model No. | Fan Type |
|---|-------------------------------|
| FR-E540-1.5K to 3.7K-EC FR-E520S-1.5K, 2.2K-EC | MMF-06D24ES-FC4 BKO-CA1027H09 |
| FR-E540-5.5K, 7.5K-EC | MMF-06D24ES-FC5 BKO-CA1027H10 |


● **Removal**

- 1) Remove the front cover (refer to page 5).
- 2) Unplug the fan connector.
The cooling fan is connected to the cooling fan connector beside the main circuit terminal block of the inverter.
Unplug the connector.




Fan connector

- 3) Remove the inverter and cooling fan.
Push in the direction of arrow A and pull out in the direction of arrow B.



- 4) Remove the cooling fan and cooling fan cover.
The cooling fan is secured by the fixing catches.
You can remove the cooling fan and cooling fan cover by disengaging the fixing catches.




Cooling fan

Cooling fan cover


● **Reinstallation**

- 1) After confirming the orientation of the fan, reinstall the fan to the cover so that the arrow on the left of "AIR FLOW" faces in the opposite direction of the fan cover.


Note: If the air flow is set in the wrong direction, the inverter life can be shorter.



- 2) Reinstall the fan cover to the inverter. Run the cable through the wiring groove to prevent it from being caught between the chassis and cover.



- 3) Reconnect the cable to the connector.



- 4) Reinstall the inverter front cover.

(2) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing the DC in the main circuit, and an aluminum electrolytic capacitor is also used for stabilizing the control power in the control circuit.

Their characteristics are adversely affected by ripple current, etc. When the inverter is operated in an ordinary, air-conditioned environment, change the capacitors about every 5 years. When 5 years have elapsed, the capacitors will deteriorate more rapidly. Check the capacitors at least every year (less than six months if the life will be expired soon). Check the following:


- 1) Case (side faces and bottom face for expansion)
- 2) Sealing plate (for remarkable warp and extreme crack)
- 3) Appearance, external cracks, discoloration, leakage.

When the measured capacitance of the capacitor has reduced below 85% of the rating, change the capacitor.

5.3.8 Measurement of main circuit voltages, currents and powers

● Measurement of voltages and currents

Since the voltages and currents on the inverter power supply and output sides include harmonics, accurate measurement depends on the instruments used and circuits measured. When instruments for commercial frequency are used for measurement, measure the following circuits using the instruments given on the next page.



Typical Measuring Points and Instruments

- Note: 1. Use FFT (Fast Fourier Transforms) to measure the output voltage accurately.
It cannot be measured accurately with a meter or general instrument.
2. For FR-E520S-0.4K to 2.2K do not use At, As, Vt, Vs, W12 and W13.

Measuring Points and Instruments

| Item | Measuring Point | Measuring Instrument | Remarks (Reference Measured Value) |
|--------------------------------------|--|---|--|
| Power supply voltage (V1) | Across L1-L2, L2-L3, L3-L1 | Moving-iron type AC voltmeter | Is the commercial power supply within permissible variation of AC voltage (Refer to page 180) |
| Power supply side current (I1) | L1, L2 and L3 line currents | Moving-iron type AC ammeter | |
| Power supply side power (P1) | At L1, L2 and L3, and across L1-L2, L2-L3 and L3-L1 | Electrodynamic type single-phase wattmeter | P1 = W11 + W12 + W13 (3-wattmeter method) |
| Power supply side power factor (Pf1) | Calculate after measuring power supply voltage, power supply side current and power supply side power. [For three-phase power supply] $Pf1 = \frac{P1}{\sqrt{3}V1 \times I1} \times 100\%$ | | [For single-phase power supply] $Pf1 = \frac{P1}{V1 \times I1} \times 100\%$ |
| Output side voltage (V2) | Across U-V, V-W and W-U | (Note 1) (Cannot be measured by moving-iron type) | Difference between phases is within ±1% of maximum output voltage. |
| Output side current (I2) | U, V and W line currents | Moving-iron type AC ammeter (Note 2) | Current should be equal to or less than rated inverter current. Difference between phases is 10% or lower. |
| Output side power (P2) | At U, V and W, and across U-V and V-W | Electrodynamic type single-phase wattmeter | P2 = W21 + W22 2-wattmeter method (or 3-wattmeter method) |
| Output side power factor (Pf2) | Calculate in similar manner to power supply side power factor. $Pf2 = \frac{P2}{\sqrt{3}V2 \times I2} \times 100\%$ | | |
| Converter output | Across + - - | Moving-coil type (such as tester) | Inverter LED display is lit. $1.35 \times V1$ Maximum 760V (380V) during regenerative operation |
| Frequency setting signal | Across 2 (positive)-5 Across 4 (positive)-5 | Moving-coil type (Meter, etc. may be used) (Internal resistance: 50kΩ or larger) | 0 to 5V/0 to 10VDC 4 to 20mADC |
| Frequency setting power supply | Across 10 (positive)-5 | | 5VDC |
| Frequency meter signal | Across AM (positive)-5 | | Approximately 10VDC at maximum frequency (without frequency meter) |
| Start signal Select signal | Across STF, STR, RH, RM, RL, MRS, RES-SD | | Moving-coil type (Meter, etc. may be used) (Internal resistance: 50kΩ or larger) |
| Reset | Across RES (positive)-SD | | |
| Output stop | Across MRS (positive)-SD | | |
| Alarm signal | Across A-C Across B-C | Moving-coil type (such as a meter) | Continuity check <Normal> <Fault> Across A-C: Discontinuity Continuity Across B-C: Continuity Discontinuity |

Note: 1. Use FFT to measure the output voltage accurately. It can not be measured accurately with a meter or general instrumentation.

2. If the carrier frequency exceeds 5kHz, do not use this instrument since using it may increase eddy-current loss produced in metal parts inside the instrument, leading to burnout.
In this case, use an approximate effective value type instrument.

*The value within the parentheses is for the 200V class.

CHAPTER 6

SPECIFICATIONS

This chapter provides the "specifications" of this product.
Always read the instructions before using the equipment

6.1 Standard Specifications 180

Chapter 1

Chapter 2

Chapter 3

Chapter 4

Chapter 5

Chapter 6

6.1 Standard Specifications

SPECIFICATIONS

6.1.1 Model specifications

(1) 3-phase 400V power supply

| | | | | | | | | |
|--|--|--|----------|--------|--------------------|----------|-----|------|
| Type FR-E540-□□ K-EC | | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 |
| Applicable motor capacity (kW) (Note 1) | | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 |
| Output | Rated capacity (kVA) (Note 2) | 1.2 | 2.0 | 3.0 | 4.6 | 7.2 | 9.1 | 13.0 |
| | Rated current (A) (Note 6) | 1.6(1.4) | 2.6(2.2) | 4(3.8) | 6(5.4) | 9.5(8.7) | 12 | 17 |
| | Overload capacity (Note 3) | 150% 60 s 200% 0.5 s (inverse-time characteristics) | | | | | | |
| | Voltage (Note 4) | Three phase, 380V to 480V 50Hz/60Hz | | | | | | |
| Power supply | Rated input AC voltage, frequency | Three phase, 380V to 480V 50Hz/60Hz | | | | | | |
| | Permissible AC voltage fluctuation | 325 to 528V 50Hz/60Hz | | | | | | |
| | Permissible frequency fluctuation | ±5% | | | | | | |
| | Power supply system capacity (kVA) (Note 5) | 1.5 | 2.5 | 4.5 | 5.5 | 9.5 | 12 | 17 |
| Protective structure (JEM1030) | | Enclosed type (IP20) | | | | | | |
| Cooling system | | Self-cooling | | | Forced air cooling | | | |
| Approximate weight (kg) | | 1.9 | 1.9 | 2.0 | 2.1 | 2.1 | 3.8 | 3.8 |

- Note: 1. The applicable motor capacity indicated is the maximum capacity applicable when a Mitsubishi 4-pole standard motor is used.
2. The rated output capacity indicated assumes that the output voltage is 440V.
3. The overload capacity indicated in % is the ratio of the overload current to the inverter's rated current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
4. The maximum output voltage cannot exceed the power supply voltage. The maximum output voltage may be set as desired below the power supply voltage. However, the crest value of the inverter output voltage remains unchanged from the DC bus voltage.
5. The power supply capacity changes with the values of the power supply side inverter impedances (including those of the input reactor and cables).
6. The rated output current in the parentheses applies when low acoustic noise operation is to be performed at the ambient temperature higher than 40°C with the Pr. 72 (PWM frequency selection) value set to 2kHz or higher.

(2) Single-phase 200V power supply

| | | | | | |
|--|---|---|------|--------------------|-----|
| Type FR-E520S-□□ K-EC | | 0.4 | 0.75 | 1.5 | 2.2 |
| Applicable motor capacity (kW) (Note 1) | | 0.4 | 0.75 | 1.5 | 2.2 |
| Output | Rated capacity (kVA) (Note 2) | 0.95 | 1.5 | 2.7 | 3.8 |
| | Rated output current (A) | 2.5 | 4 | 7 | 10 |
| | Overload capacity (Note 3) | 150% 60 s 200% 0.5 s (inverse-time characteristics) | | | |
| | Rated output voltage (Note 4) | Three phase, 200V to 240V 50Hz/60Hz | | | |
| Power supply | Rated input AC voltage, frequency | Single phase, 200V to 240V 50Hz/60Hz | | | |
| | Permissible AC voltage fluctuation | Single phase, 170 to 264V 50Hz/60Hz | | | |
| | Permissible frequency fluctuation | Within ±5% | | | |
| | Power supply capacity (kVA) (Note 5) | 1.5 | 2.3 | 4.0 | 5.2 |
| Protective structure (JEM1030) | | Enclosed type (IP20) | | | |
| Cooling system | | Self-cooling | | Forced air cooling | |
| Approximate weight (kg) | | 1.9 | 1.9 | 2.0 | 2.0 |

Note: 1. The applicable motor capacity indicated is the maximum capacity applicable when a Mitsubishi 4-pole standard motor is used.

Normally, the rated current (at 50Hz) of the motor applied should not exceed the rated current.

2. The rated output capacity indicated assumes that the output voltage is 220V.
3. The overload capacity indicated in % is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
4. The maximum output voltage does not exceed the power supply voltage. The maximum output voltage may be set as desired below the power supply voltage. However, the crest value of the inverter output voltage remains unchanged from the DC bus voltage.
5. The power supply capacity changes with the values of the power supply side inverter impedances (including those of the input reactor and cables). Use the power supply capacity larger than the indicated.

6.1.2 Common specifications

| | | | |
|---|---|--|---|
| Control specifications | Control system | | Soft-PWM control/high carrier frequency PWM control can be selected. V/F control or general-purpose magnetic flux vector control can be selected. |
| | Output frequency range | | 0.2 to 400Hz (starting frequency variable between 0 and 60Hz) |
| | Frequency setting resolution | Analog input | Across terminals 2-5: 1/500 of maximum set frequency (5VDC input), 1/1000 (10VDC, 4-20mADC input). |
| | | Digital input | 0.01Hz (less than 100Hz), 0.1Hz (100Hz or more) when digital setting is made using the control panel. |
| | Frequency accuracy | Analog input | Within $\pm 0.5\%$ of maximum output frequency ($25^{\circ}\text{C} \pm 10^{\circ}\text{C}$). |
| | | Digital input | Within 0.01% of set output frequency when setting is made from control panel. |
| | Voltage/frequency characteristic | | Base frequency set as required between 0 and 400Hz. Constant torque or variable torque pattern can be selected. |
| | Starting torque | | 150% or more (at 1Hz), 200% or more (at 3Hz) when general-purpose magnetic flux vector control or slip compensation is selected. |
| | Torque boost | | Manual torque boost, 0 to 30% may be set. |
| | Acceleration/deceleration time setting | | 0.01, 0.1 to 3600 s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode can be selected. |
| | Braking torque | Regenerative (Note 3) | 0.4K, 0.75K... 100%, 1.5K....50%, 2.2K, 3.7K, 5.5K, 7.5K.... 20% |
| | | DC injection brake | Operation frequency (0 to 120Hz), operation time (0 to 10 s), operation voltage (0 to 30%) variable. |
| | Current stall prevention operation level | | Operation current level can be set (0 to 200% variable), presence or absence can be selected. |
| | Voltage stall prevention operation level | | Operation level is fixed, presence or absence can be selected. |
| | Fast-response current limit level | | Operation level is fixed, presence or absence can be selected. |
| Input signals | Frequency setting signal | Analog input | 0 to 5VDC, 0 to 10VDC, 4 to 20mADC. |
| | | Digital input | Entered from control panel (optional FR-PA02-02). |
| | Start signal | | Forward rotation and reverse rotation, start signal automatic self-holding input (3-wire input) selectable. |
| | Alarm reset | | Used to reset alarm output provided when protective function is activated. |
| | Multi-speed selection | | Up to 15 speeds can be selected. (Each speed can be set between 0 and 400Hz, running speed can be changed during operation from the control panel.) |
| | Second function selection | | Used to select second functions (acceleration time, deceleration time, torque boost, base frequency, electronic overcurrent protection). |
| | Output stop | | Instantaneous shut-off of inverter output (frequency, voltage). |
| | Current input selection | | Used to select input of frequency setting signal 4 to 20mADC (terminal 4). |
| | External thermal relay input | | Thermal relay contact input for use when the inverter is stopped by the external thermal relay. |
| | PU operation-external operation switching | | Used to switch between PU operation and external operation from outside the inverter. |
| V/F-general-purpose magnetic flux switching | | Used to switch between V/F control and general-purpose magnetic flux vector control from outside the inverter. | |

Use Pr. 180 to Pr. 183 for selection.

| | | | |
|----------------------------|------------------------------|------------------|--|
| Control specifications | Operation functions | | Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection, automatic restart operation after instantaneous power failure, forward/reverse rotation prevention, slip compensation, operation mode selection, offline auto tuning function, PID control, computer link operation (RS-485). |
| | Output signals | Operating status | 2 open collector output signals can be selected from inverter running, up to frequency, frequency detection, overload alarm, zero current detection, output current detection, PID upper limit, PID lower limit, PID forward/reverse rotation, operation ready, minor fault and alarm, and 1 contact output (230VAC 0.3A, 30VDC 0.3A) can be selected. |
| | | For meter | 1 signal can be selected from output frequency, output current and output voltage. Analog output (0 to 10VDC). |
| Display | Control panel display | Operating status | Output voltage, output current, set frequency, running. |
| | | Alarm definition | Alarm definition is displayed when protective function is activated. 4 alarm definitions are stored. |
| | LED display | | Power application (POWER), Alarm (ALARM). |
| Protective/alarm functions | | | Overcurrent shut-off (during acceleration, deceleration, constant speed), regenerative overvoltage shut-off, undervoltage (Note 1), instantaneous power failure (Note 1), overload shut-off (electronic overcurrent protection), brake transistor alarm, output short circuit, stall prevention, brake resistor overheat protection, fin overheat, fan failure (Note 4), parameter error, PU disconnection, output phase failure protection, ground fault over current protection. |
| Environment | Ambient temperature | | -10°C to +50°C (non-freezing) |
| | Ambient humidity | | 90%RH or less (non-condensing) |
| | Storage temperature (Note 2) | | -20°C to +65°C |
| | Ambience | | Indoors (No corrosive and flammable gases, oil mist, dust and dirt.) |
| | Altitude, vibration | | Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (91%). 5.9m/s ² or less (conforming to JIS C 0911) |

Note: 1. When undervoltage or instantaneous power failure has occurred, alarm display or alarm output is not provided but the inverter itself is protected. Overcurrent, regenerative overvoltage or other protection may be activated at power restoration according to the operating status (load size, etc.)


2. Temperature applicable for a short period in transit, etc.

3. The braking torque indicated is a short-duration average torque (which varies with motor loss) when the motor alone is decelerated from 50Hz in the shortest time and is not a continuous regenerative torque. When the motor is decelerated from the frequency higher than the base frequency, the average deceleration torque will reduce. Since the inverter does not contain a brake resistor, use the optional brake resistor when regenerative energy is large. A brake unit (BU) may also be used.


4. Not provided for the FR-E540-0.4K, 0.75K-EC, FR-E520S-0.1K to 0.4K-EC which are not equipped with a cooling fan.

6.1.3 Outline drawings

- FR-E540-0.4K, 0.75K, 1.5K, 2.2K, 3.7K-EC
- FR-E520S-0.4K, 0.75K, 1.5K, 2.2K-EC



● **FR-E540-5.5K, 7.5K-EC**



APPENDIX

This chapter provides "supplementary information" for use of this product.

Always read the instructions before using the equipment.

| | |
|---------------------------------|-----|
| Appendix 1 Data Code List | 186 |
|---------------------------------|-----|

Appendix 1 Data Code List

APPENDIX

| Function | Parameter Number | Name | Data Code | | Link Parameter Extension Setting (Data Code 7F/FF) |
|------------------------------|------------------|--|-----------|-------|---|
| | | | Read | Write | |
| Basic functions | 0 | Torque boost | 00 | 80 | 0 |
| | 1 | Maximum frequency | 01 | 81 | 0 |
| | 2 | Minimum frequency | 02 | 82 | 0 |
| | 3 | Base frequency | 03 | 83 | 0 |
| | 4 | Multi-speed setting (high speed) | 04 | 84 | 0 |
| | 5 | Multi-speed setting (middle speed) | 05 | 85 | 0 |
| | 6 | Multi-speed setting (low speed) | 06 | 86 | 0 |
| | 7 | Acceleration time | 07 | 87 | 0 |
| | 8 | Deceleration time | 08 | 88 | 0 |
| Standard operation functions | 9 | Electronic thermal O/L relay | 09 | 89 | 0 |
| | 10 | DC injection brake operation frequency | 0A | 8A | 0 |
| | 11 | DC injection brake operation time | 0B | 8B | 0 |
| | 12 | DC injection brake voltage | 0C | 8C | 0 |
| | 13 | Starting frequency | 0D | 8D | 0 |
| | 14 | Load pattern selection | 0E | 8E | 0 |
| | 15 | Jog frequency | 0F | 8F | 0 |
| | 16 | Jog acceleration/deceleration time | 10 | 90 | 0 |
| | 18 | High-speed maximum frequency | 12 | 92 | 0 |
| | 19 | Base frequency voltage | 13 | 93 | 0 |
| | 20 | Acceleration/deceleration reference frequency | 14 | 94 | 0 |
| | 21 | Acceleration/deceleration time increments | 15 | 95 | 0 |
| | 22 | Stall prevention operation level | 16 | 96 | 0 |
| | 23 | Stall prevention operation level compensation factor at double speed | 17 | 97 | 0 |
| | 24 | Multi-speed setting (speed 4) | 18 | 98 | 0 |
| | 25 | Multi-speed setting (speed 5) | 19 | 99 | 0 |
| | 26 | Multi-speed setting (speed 6) | 1A | 9A | 0 |
| | 27 | Multi-speed setting (speed 7) | 1B | 9B | 0 |
| | 29 | Acceleration/deceleration pattern | 1D | 9D | 0 |
| | 30 | Regenerative function selection | 1E | 9E | 0 |
| | 31 | Frequency jump 1A | 1F | 9F | 0 |
| | 32 | Frequency jump 1B | 20 | A0 | 0 |
| | 33 | Frequency jump 2A | 21 | A1 | 0 |
| | 34 | Frequency jump 2B | 22 | A2 | 0 |
| | 35 | Frequency jump 3A | 23 | A3 | 0 |
| | 36 | Frequency jump 3B | 24 | A4 | 0 |
| | 37 | Speed display | 25 | A5 | 0 |
| | 38 | Frequency at 5V (10V) input | 26 | A6 | 0 |
| | 39 | Frequency at 20mA input | 27 | A7 | 0 |

| Function | Parameter Number | Name | Data Code | | Link Parameter Extension Setting (Data Code 7F/FF) |
|-------------------------------|--------------------------|---|-----------|-------|---|
| | | | Read | Write | |
| Output terminal functions | 41 | Up-to-frequency sensitivity | 29 | A9 | 0 |
| | 42 | Output frequency detection | 2A | AA | 0 |
| | 43 | Output frequency detection for reverse rotation | 2B | AB | 0 |
| Second functions | 44 | Second acceleration/deceleration time | 2C | AC | 0 |
| | 45 | Second deceleration time | 2D | AD | 0 |
| | 46 | Second torque boost | 2E | AE | 0 |
| | 47 | Second V/F (base frequency) | 2F | AF | 0 |
| | 48 | Second electronic overcurrent protection | 30 | B0 | 0 |
| Display functions | 52 | Control panel/PU main display data selection | 34 | B4 | 0 |
| | 55 | Frequency monitoring reference | 37 | B7 | 0 |
| | 56 | Current monitoring reference | 38 | B8 | 0 |
| Automatic restart functions | 57 | Restart coasting time | 39 | B9 | 0 |
| | 58 | Restart cushion time | 3A | BA | 0 |
| Additional function | 59 | Remote setting function selection | 3B | BB | 0 |
| Operation selection functions | 60 | Shortest acceleration/deceleration mode | 3C | BC | 0 |
| | 61 | Reference I for intelligent mode | 3D | BD | 0 |
| | 62 | ref. I for intelligent mode accel | 3E | BE | 0 |
| | 63 | ref. I for intelligent mode decel | 3F | BF | 0 |
| | 65 | Retry selection | 41 | C1 | 0 |
| | 66 | Stall prevention operation level reduction starting frequency | 42 | C2 | 0 |
| | 67 | Number of retries at alarm occurrence | 43 | C3 | 0 |
| | 68 | Retry waiting time | 44 | C4 | 0 |
| | 69 | Retry count display erasure | 45 | C5 | 0 |
| | 70 | Special regenerative brake duty | 46 | C6 | 0 |
| | 71 | Applied motor | 47 | C7 | 0 |
| | 72 | PWM frequency selection | 48 | C8 | 0 |
| | 73 | 0-5V/0-10V selection | 49 | C9 | 0 |
| | 74 | Filter time constant | 4A | CA | 0 |
| | 75 | Reset selection/disconnected PU detection/PU stop selection | 4B | CB | 0 |
| | 77 | Parameter write disable selection | 4D | CD | 0 |
| | 78 | Reverse rotation prevention selection | 4E | CE | 0 |
| 79 | Operation mode selection | 4F | CF | 0 | |

| Function | Parameter Number | Name | Data Code | | Link Parameter Extension Setting (Data Code 7F/FF) |
|--|------------------|--|-----------|-------|---|
| | | | Read | Write | |
| General-purpose magnetic flux vector control | 80 | Motor capacity | 50 | D0 | 0 |
| | 82 | Motor exciting current | 52 | D2 | 0 |
| | 83 | Rated motor voltage | 53 | D3 | 0 |
| | 84 | Rated motor frequency | 54 | D4 | 0 |
| | 90 | Motor constant (R1) | 5A | DA | 0 |
| | 96 | Auto-tuning setting/status | 60 | E0 | 0 |
| Communication functions | 117 | Station number | 11 | 91 | 1 |
| | 118 | Communication speed | 12 | 92 | 1 |
| | 119 | Stop bit length | 13 | 93 | 1 |
| | 120 | Parity check presence/absence | 14 | 94 | 1 |
| | 121 | Number of communication retries | 15 | 95 | 1 |
| | 122 | Communication check time interval | 16 | 96 | 1 |
| | 123 | Waiting time setting | 17 | 97 | 1 |
| PID control | 124 | CR·LF presence/absence selection | 18 | 98 | 1 |
| | 128 | PID action selection | 1C | 9C | 1 |
| | 129 | PID proportional band | 1D | 9D | 1 |
| | 130 | PID integral time | 1E | 9E | 1 |
| | 131 | Upper limit | 1F | 9F | 1 |
| | 132 | Lower limit | 20 | A0 | 1 |
| | 133 | PID action set point for PU operation | 21 | A1 | 1 |
| Additional function | 134 | PID differential time | 22 | A2 | 1 |
| | 145 | Parameter unit language switch-over | 2D | AD | 1 |
| Current detection | 146 | Parameter set by manufacturer. Do not set. | | | |
| | 150 | Output current detection level | 32 | B2 | 1 |
| | 151 | Output current detection period | 33 | B3 | 1 |
| | 152 | Zero current detection level | 34 | B4 | 1 |
| Sub function | 153 | Zero current detection period | 35 | B5 | 1 |
| | 156 | Stall prevention operation selection | 38 | B8 | 1 |
| Additional function | 158 | AM terminal function selection | 3A | BA | 1 |
| | 160 | User group read selection | 00 | 80 | 2 |
| Initial monitor | 171 | Actual operation hour meter clear | 0B | 8B | 2 |
| User functions | 173 | User group 1 registration | 0D | 8D | 2 |
| | 174 | User group 1 deletion | 0E | 8E | 2 |
| | 175 | User group 2 registration | 0F | 8F | 2 |
| | 176 | User group 2 deletion | 10 | 90 | 2 |

| Function | Parameter Number | Name | Data Code | | Link Parameter Extension Setting (Data Code 7F/FF) |
|-------------------------------|------------------|--|-----------|-------|---|
| | | | Read | Write | |
| Terminal assignment functions | 180 | RL terminal function selection | 14 | 94 | 2 |
| | 181 | RM terminal function selection | 15 | 95 | 2 |
| | 182 | RH terminal function selection | 16 | 96 | 2 |
| | 183 | MRS terminal function selection | 17 | 97 | 2 |
| | 190 | RUN terminal function selection | 1E | 9E | 2 |
| | 191 | FU terminal function selection | 1F | 9F | 2 |
| | 192 | A, B, C terminal function selection | 20 | A0 | 2 |
| Multi-speed operation | 232 | Multi-speed setting (speed 8) | 28 | A8 | 2 |
| | 233 | Multi-speed setting (speed 9) | 29 | A9 | 2 |
| | 234 | Multi-speed setting (speed 10) | 2A | AA | 2 |
| | 235 | Multi-speed setting (speed 11) | 2B | AB | 2 |
| | 236 | Multi-speed setting (speed 12) | 2C | AC | 2 |
| | 237 | Multi-speed setting (speed 13) | 2D | AD | 2 |
| | 238 | Multi-speed setting (speed 14) | 2E | AE | 2 |
| Sub functions | 239 | Multi-speed setting (speed 15) | 2F | AF | 2 |
| | 240 | Soft-PWM setting | 30 | B0 | 2 |
| | 244 | Cooling fan operation selection | 34 | B4 | 2 |
| | 245 | Rated motor slip | 35 | B5 | 2 |
| | 246 | Slip compensation response time | 36 | B6 | 2 |
| Stop selection function | 247 | Constant-output region slip compensation selection | 37 | B7 | 2 |
| | 250 | Stop selection | 3A | BA | 2 |
| Additional function | 251 | Output phase failure protection selection | 3B | BB | 2 |
| Computer link function | 338* | Operation command right | 26 | A6 | 3 |
| | 339* | Speed command right | 27 | A7 | 3 |
| | 340* | Link start mode selection | 28 | A8 | 3 |
| | 342 | E ² PROM write selection | 2A | AA | 3 |
| Calibration functions | 901 | AM terminal calibration | 5D | DD | 1 |
| | 902 | Frequency setting voltage bias | 5E | DE | 1 |
| | 903 | Frequency setting voltage gain | 5F | DF | 1 |
| | 904 | Frequency setting current bias | 60 | E0 | 1 |
| | 905 | Frequency setting current gain | 61 | E1 | 1 |
| | 990 | Buzzer control | 5A | DA | 9 |
| | 991 | LCD contrast | 5B | DB | 9 |

* Fitted with FR-E5NC.

REVISIONS

*The manual number is given on the bottom left of the back cover.

| Print Date | *Manual Number | Revision |
|------------|------------------|--|
| Mar., 1999 | IB(NA)-0600002-A | First edition |
| Apr., 1999 | IB(NA)-0600002-B | <p>Modifications</p> <ul style="list-style-type: none"> •Instructions for compliance with the UL and CSA standards Factory setting of Pr. 4 "Multi-speed setting (high speed)" |
| Jun., 1999 | IB(NA)-0600002-C | <p>Modifications</p> <p>Pr. 73 "0-5V/0-10V selection" = "10", "11" setting method</p> |
| Mar., 2000 | IB(NA)-0600002-D | <p>Modifications</p> <ul style="list-style-type: none"> •Alarm indications (E. 6, E. 7) •Control circuit terminal screw tightening torque •Instructions for compliance with U.S. and Canadian Electrical Codes <p>Partial additions</p> <p>Pr. 12 "DC injection brake voltage"</p> <p>Pr. 73 "0-5V/0-10V selection"</p> |
| Nov., 2000 | IB(NA)-0600002-E | <p>Additions</p> <ul style="list-style-type: none"> •Pr. 251 "output phase failure protection selection" •Pr. 342 "E²PROM write selection" <p>Modifications</p> <ul style="list-style-type: none"> •Instructions for compliance with U.S. and Canadian Electrical Codes |
| | | |

| Headquarters | | European Representatives | |
|--|--|--|--|
| <p>EUROPE</p> <p>MITSUBISHI ELECTRIC EUROPE B.V. Gothaer Str. 8 D-40880 Ratingen GERMANY Phone: +49 (0) 2102 / 486 0 Fax: +49 (0) 2102 / 486 112</p> | | <p>AUSTRIA</p> <p>GEVA Wiener Straße 89 A-2500 Baden Phone: +43 (0) 2252 / 85 55 20 Fax: +43 (0) 2252 / 488 60</p> | |
| <p>ITALY</p> <p>MITSUBISHI ELECTRIC EUROPE B.V. C.D. Colleoni - P. Perseo Ing. 2, Via Paracelso 12 I-20041 Agrate Brianza (MI) ITALY Phone: +39 039 6053 1 Fax: +39 039 6053 312</p> | | <p>BELGIUM</p> <p>N.V. GETRONICS Belgium S.A. Pontbeeklaan 43 B-1731 Asse-Zellik Phone: +32 (0) 2 / 467 17 51 Fax: +32 (0) 2 / 467 17 45</p> | |
| <p>JAPAN</p> <p>MITSUBISHI ELECTRIC CORPORATION 2-2-3 Marunouchi Chiyoda-Ku Tokyo 100-8310 JAPAN Phone: +81 (0) 3 / 32 18 31 76 Fax: +81 (0) 3 / 32 18 24 22</p> | | <p>BULGARIA</p> <p>TELECON CO. 4, A. Ljapchev Blvd. BG-1756 Sofia Phone: +359 92 97 44 05 8 Fax: +359 92 97 44 06 1</p> | |
| <p>SPAIN</p> <p>MITSUBISHI ELECTRIC EUROPE B.V. Pol. Ind. Can Magi-C. Joan Buscallá, 2-4 AC 420 E-08190 Sant Cugat del Vallés (Barcelona) SPAIN Phone: +34 (9) 3 / 565 31 60 Fax: +34 (9) 3 / 589 15 79</p> | | <p>CZECHIA</p> <p>AutoCont Control Systems s.r.o. Nemocnicni 12 CZ-702 00 Ostrava 2 Phone: +420 (0) 69 / 615 21 11 Fax: +420 (0) 69 / 615 21 12</p> | |
| <p>UK</p> <p>MITSUBISHI ELECTRIC EUROPE B.V. Travellers Lane GB-Hatfield Herts. AL10 8 XB UK Phone: +44 (0) 1707 / 27 61 00 Fax: +44 (0) 1707 / 27 86 95</p> | | <p>DENMARK</p> <p>louis poulsen Geminivej 32 DK-2670 Greve Phone: +45 (0) 43 / 95 95 95 Fax: +45 (0) 43 / 95 95 91</p> | |
| <p>USA</p> <p>MITSUBISHI ELECTRIC AUTOMATION, INC. 500 Corporate Woods Parkway Vernon Hills, Illinois 60061 USA Phone: +1 / 847 / 478 21 00 Fax: +1 / 847 / 478 22 83</p> | | <p>ESTONIA</p> <p>UTU ELEKTROTEHNIKA AS Laki 12E EE-10621 Tallinn Phone: +372 6 / 51 72 80 Fax: +372 6 / 51 72 88</p> | |
| | | <p>FINLAND</p> <p>URHO TUOMINEN OY Hevoshaankatu 3 FIN-28600 Pori Phone: +358 (0) 2 / 550 800 Fax: +358 (0) 2 / 550 8841</p> | |
| | | <p>FRANCE</p> <p>Delta Résistances S.A. 208, Avenue du 8 Mai 1945 F-69165 Rillieux la Pape Cedex Phone: +33 (0) 4 / 72 01 46 00 Fax: +33 (0) 4 / 78 88 20 21</p> | |
| | | <p>GREECE</p> <p>UTEKO A.B.E.E. 5, Mavrogenous Str. GR-18542 Piraeus Phone: +30 (0) 1 / 42 10 050 Fax: +30 (0) 1 / 42 12 033</p> | |
| | | <p>IRELAND</p> <p>MITSUBISHI ELECTRIC EUROPE B.V. Westgate Business Park, Ballymount IRL-Dublin 24 Phone: +353 (0) 1 / 419 88 00 Fax: +353 (0) 1 / 419 88 90</p> | |
| | | <p>ISRAEL</p> <p>SHERF Motion Techn. LTD Rehov Hamerkava 19 IL-Holon 58851 Phone: +972 (0) 3 / 559 54 62 Fax: +972 (0) 3 / 556 01 82</p> | |
| | | <p>NETHERLANDS</p> <p>Getronics Industrial Automation bv Donauweg 10 NL-1043 AJ Amsterdam Phone: +31 (0) 20 / 586 15 92 Fax: +31 (0) 20 / 586 19 27</p> | |
| | | <p>NORWAY</p> <p>Beijer Electronics AS Teglverksveien 1 N-3002 Drammen Phone: +47 (0) 32 / 24 30 00 Fax: +47 (0) 32 / 84 85 77</p> | |
| | | <p>POLAND</p> <p>MPL Technology Sp. z o.o. ul. Wroclawska 53 PL-30011 Kraków Phone: +48 (0) 12 / 632 28 85 Fax: +48 (0) 12 / 632 47 82</p> | |
| | | <p>ROMANIA</p> <p>Sirius Trading & Services srl Bd. Ghica nr. 112, Bl. 41, Sc.2, ap. 98 RO-72335 Bucuresti 2 Phone: +40 (0) 1 / 210 55 11 Fax: +40 (0) 1 / 210 55 11</p> | |
| | | <p>RUSSIA</p> <p>Mitsubishi Electric Europe B.V. 12/1 Gonchamaya St, suite 3C RUS-109240 Moscow Phone: +7 (0) 95 / 915-8624/02 Fax: +7 (0) 95 / 915-8603</p> | |
| | | <p>RUSSIA</p> <p>STC Drive Technique Poslannikov per., 9, str.1 RUS-107005 Moscow Phone: +7 (0) 95 / 786 21 00 Fax: +7 (0) 95 / 786 21 01</p> | |
| | | <p>SLOVAKIA</p> <p>ACP AUTOCOMP a.s. Chalupkova 7 SK-81109 Bratislava Phone: +421 (0) 7 592 2248 Fax: +421 (0) 7 592 2254</p> | |
| | | <p>SLOVENIA</p> <p>INEA d.o.o. Ljubljanska 80 SI-61230 Domzale Phone: +386 (0) 17 21 80 00 Fax: +386 (0) 17 24 16 72</p> | |
| | | <p>SWEDEN</p> <p>Beijer Electronics AB Box 325 S-20123 Malmö Phone: +46 (0) 40 / 35 86 00 Fax: +46 (0) 40 / 93 23 01</p> | |
| | | <p>SWITZERLAND</p> <p>ECONOTEC AG Postfach 282 CH-8309 Nürensdorf Phone: +41 (0) 1 / 838 48 11 Fax: +41 (0) 1 / 838 48 12</p> | |
| | | <p>TURKEY</p> <p>GTS Darülaceze Cad. No. 43A KAT: 2 TR-80270 Okmeydani-Istanbul Phone: +90 (0) 212 / 320 1640 Fax: +90 (0) 212 / 320 1649</p> | |
| | | <p>UKRAINE</p> <p>JV-CSC Automation 15, M. Raskovoyi St., Floor 10, Office 1010 U-02002 Kiev Phone: +380 (4) 4 / 238 83 16 Fax: +380 (4) 4 / 238 83 17</p> | |