

TENMA®  
AN ANALOG WORLD TO LIVE BY

72-7925

H  
- 000 ⚡

POWER

OLD



A

CE

COM



mA

VΩHz°C



20A MAX  
MAX 10sec  
EACH 15mA  
UNFUSED

200mA MAX  
FUSED

CATE 600V  
CAT I 1000V  
1000V MAX

**TABLE OF CONTENTS**

<b>TITLE</b>	<b>PAGE</b>
Overview	3
Inspection	3
Safety Information	4
Safe Operation	5
International Electrical Symbols	7
The Meter Structure	7
Functional Buttons	8
Display Symbols	8
Measurement Operation	9
A. DC Voltage Measurement	9
B. AC Voltage Measurement	10
C. DC Current Measurement	11
D. AC Current Measurement	13
E. Measuring Resistance	14
F. Frequency Measurement	15
G. Temperature Measurement	16
H. Capacitance Measurement	17
I. Measuring Diodes & Continuity	18
J. Measuring Transistor	19
Sleep Mode	20
General Specifications	20
Accuracy Specifications	21
A. DC Voltage	21
B. AC Voltage	21
C. DC Current	22
D. AC Current	22
E. Resistance Test	23
F. Frequency	23
G. Temperature	23
H. Capacitance	24



**Model 72-7925: OPERATING MANUAL**

	<b>PAGE</b>
I. Diodes and Continuity Test —————	24
J. Transistor Test —————	24
Maintenance —————	25
A. General Service —————	25
B. Replacing the Battery —————	25
C. Replacing the Fuses —————	26

## Overview

### Warning

To avoid risk of injury from electric shock, read the “Safety Information” and “Rules For Safe Operation” carefully before using the meter.

The Digital Multimeter model 72-7925 (hereafter referred to as The Meter), is a highly reliable handheld measuring instrument featuring a highly readable LCD 3-1/2 Digit display and full range overload protection. It is capable of measuring AC/DC voltage, AC/DC current, resistance, capacitance, temperature, transistor hFE, frequency, diode and continuity check. It also features data hold and sleep mode.

## Inspection

This meter includes the following items:

Item	Description	Qty
1	Operating Manual	1 piece
2	Test Leads	1 pair
3	Point Contact Temperature Probe	1 piece
4	Holster	1 piece
5	9V Battery (NEDA 1604 or 6F22 or 006P)	1 piece

In the event items are missing or damaged, please contact your dealer immediately.



## Model 72-7925: OPERATING MANUAL

### Safety Information

This Meter complies with the standards IEC61010: in pollution degree 2, overvoltage category (CAT. I 1000V, CAT. II 600V) and double insulation.

CAT. I: Signal level, special equipment or parts of equipment, telecommunication, electronic, etc., with smaller transient overvoltages than overvoltages CAT. II.

CAT. II: Local level, appliance, PORTABLE EQUIPMENT etc., with smaller transient voltage overvoltages than CAT. III

Use the Meter only as specified in this operating manual, otherwise the protection provided by the Meter may be impaired.

In this manual, a **Warning** identifies conditions and actions that pose hazards to the user, or may damage the Meter or the equipment under test.

A **Note** identifies the information that user should pay attention on.

International electrical symbols used on the Meter and in this Operating Manual are explained on page 7.


## Safe Operation

### Warning












To avoid possible electric shock or personal injury, and to avoid possible damage to the Meter or to the equipment under test, adhere to the following rules:

- 1 Before using the Meter inspect the case. Do not use the Meter if it is damaged or the case (or part of the case) is removed. Look for cracks or missing plastic. Pay attention to the insulation around the connectors.
- 1 Inspect the test leads for damaged insulation or exposed metal. Check the test leads for continuity. Replace damaged test leads with identical model number or electrical specifications before using the Meter.
- 1 Do not apply more than the rated voltage, as marked on the Meter, between the terminals or between any terminal and grounding.
- 1 The rotary switch should be placed in the desired position prior to connecting leads. This position should not be changed while leads are connected.
- 1 When using the Meter at an effective voltage over 60V DC or 30V rms AC, special care should be taken for there is danger of electric shock.
- 1 Use the proper terminals, function, and range for your measurements.
- 1 Do not use or store the Meter in an environment of high temperature, humidity, explosive, inflammable and strong magnetic field. The performance of the Meter may deteriorate after dampened.
- 1 When using the test leads, keep your fingers behind the finger guards.
- 1 Disconnect circuit power and discharge all high-voltage capacitors before testing resistance,

continuity, diodes, capacitance or current.


- 1 Before measuring current, check the Meter's fuses and turn off power to the circuit before connecting the Meter to the circuit.
- 1 Replace the battery as soon as the battery indicator  appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- 1 Remove test leads and temperature probe from the Meter and turn the Meter power off before opening the Meter case.
- 1 When servicing the Meter, use only the same model number or identical electrical specifications replacement parts.
- 1 The internal circuit of the Meter shall not be altered at will to avoid damage of the Meter and any accident.
- 1 Soft cloth and mild detergent should be used to clean the surface of the Meter when servicing. No abrasive and solvent should be used to prevent the surface of the Meter from corrosion, damage and accident.
- 1 The Meter is suitable for indoor use.
- 1 Turn the Meter power off when it is not in use and take out the battery when not using for a long time.
- 1 Periodically check the battery for leaks. A leaking battery will damage the Meter.

## International Electrical Symbols

	Low Battery
	AC (Alternating Current)
	AC or DC
	Double Insulated
	Warning. Refer to the Operating Manual
	Conforms to Standards of European Union
	Ground
	DC (Direct Current)
	Diode
	Continuity Test
	Fuse

## The Meter Structure (see figure 1)

1. LCD Display
2. Data Hold Button
3. Transistor Jack
4. **COM** Input Terminal
5. Other Input Terminals
6. **mA** Input Terminal
7. **20A/10A** Input Terminal
8. Capacitance Jack
9. Rotary Switch
10. Power






## Functional Buttons


Button	Operation Performed
<b>POWER</b> (Yellow Button)	Turn the Meter on and off. 1 Press down the <b>POWER</b> to turn on the Meter. 1 Press up the <b>POWER</b> to turn off the Meter.
<b>HOLD</b> (Blue Button)	1 Press <b>HOLD</b> once to enter hold mode. 1 Press <b>HOLD</b> again to exit hold mode. 1 In Hold mode, <b>H</b> is displayed and the present value is shown.

## Display Symbols (see figure 2)




No.	Symbol	Meaning
1	<b>H</b>	Data hold is active.
2	<b>-</b>	Indicates negative reading.
3		The battery is low. <b>⚠ Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.</b>
4	<b>hFE</b>	Unit of Transistor
5	<b>°F</b>	Fahrenheit temperature
6		Test of diode.
7		The continuity buzzer is on.
8		Dangerous Voltages.

## Measurement Operation

- 1 Make sure the Sleep Mode is not on if you found there is no display on the LCD after turning on the Meter.
- 1 Make sure the Low Battery Display  is not on, otherwise false readings may be provided.
- 1 Pay extra attention to the  $\Delta$  symbol which is located besides the input terminals of the Meter before carrying out measurement.

### A. DC Voltage Measurement (see figure 3)



#### Warning

To avoid harm to you or damage to the Meter from electric shock, please do not attempt to measure voltages higher than 1000V or 750V rms although readings may be obtained.

Take extra attention when measuring high voltages to avoid electric shock.

To measure DC voltage, connect the Meter as follows:

1. Insert the red test lead into the  $V\Omega$  input terminal and the black test lead into the COM input terminal.
2. Set the rotary switch to an appropriate measurement position in  $V_{\text{DC}}$  range.
3. Connect the test leads across with the object being measured.

The measured value shows on the display.

## Note

- 1 If the value of voltage to be measured is unknown, use the maximum measurement position (1000V) and reduce the range step by step until a satisfactory reading is obtained.
- 1 The LCD displays "1" indicating the existing selected range is overloaded, it is required to select a higher range in order to obtain a correct reading.
- 1 In each range, the Meter has an input impedance of approx.  $10M\Omega$ . This loading effect can cause measurement errors in high impedance circuits. If the circuit impedance is less than or equal to  $10k\Omega$ , the error is negligible (0.1% or less).
- 1 When DC voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

## B. AC Voltage Measurement (see figure 3 with dotted line)

### Warning

To avoid harm to you or damage to the Meter from electric shock, please do not attempt to measure voltages higher than 1000V or 750V rms although readings may be obtained.

Take extra attention when measuring high voltages to avoid electric shock.

To measure AC Voltage, connect the Meter as follows:


1. Insert the red test lead into the  $V\Omega$  terminal and the black test lead into the COM terminal.
2. Set the rotary switch to an appropriate measurement position in  $V\sim$  range.
3. Connect the test leads across with the object being measured.

The measured value shows on the display, which is effective value of sine wave (mean value response).

## Note

- 1 If the value of voltage to be measured is unknown, use the maximum measurement position (750V) and reduce the range step by step until a satisfactory reading is obtained.
- 1 The LCD displays "1" indicating the existing selected range is overloaded, it is required to select a higher range in order to obtain a correct reading.
- 1 In each range, the Meter has an input impedance of approx.  $10M\Omega$ . This loading effect can cause measurement errors in high impedance circuits. If the circuit impedance is less than or equal to  $10k\Omega$ , the error is negligible (0.1% or less).
- 1 When AC voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

## C. DC Current Measurement (see figure 4)



### **⚠ Warning**

Never attempt an in-circuit current measurement where the open circuit voltage between terminals and ground is greater than 60V DC or 30V rms.

If the fuse burns out during measurement, the Meter may be damaged or the operator may be hurt. Disconnect power supply before making measurement. Use proper terminals, function, and range for the measurement. When the test leads are connected to the current terminals, do not parallel them across any circuit.

To measure current, do the following:

1. Turn off power to the circuit. Discharge all high-voltage capacitors.
2. Insert the red test lead into the mA or 20A or 10A terminal and the black test lead into the COM terminal. When measuring current at 200mA below, insert the red test lead into mA terminal while measuring current 200mA or above, insert the red test lead into 10A or 20A terminal
3. Set the rotary switch to an appropriate measurement position in A $\overline{\dots}$  range.
4. Break the current path to be tested. Connect the red test lead to the more positive side of the break and the black test lead to the more negative side of the break.
5. Turn on power to the circuit.  
The measured value shows on the display.

#### Note

- 1 If the value of current to be measured is unknown, use the maximum measurement position (20A) and 20A terminal or (10A) and 10A terminal, and reduce the range step by step until a satisfactory reading is obtained.
- 1 Replace appropriate rating fuse when the fuse is burnt.  
Fuse specification: 0.315A. 250V fast type fuse,  $\phi$  5 x 20mm
- 1 20A Range: For continuous measurement  $\leq$  10 seconds and interval not less than 15 minutes
- 1 When current measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

## D. AC Current Measurement (see figure 4 with dotted line)

### Warning

Never attempt an in-circuit current measurement where the voltage between terminals and ground is greater than 60V or 30V rms

If the fuse burns out during measurement, the Meter may be damaged or the operator may be hurt. Disconnect power supply before making measurement. Use proper terminals, function, and range for the measurement. When the test leads are connected to the current terminals, do not parallel them across any circuit.

To measure current, do the following:


1. Turn off power to the circuit. Discharge all high-voltage capacitors.
2. Insert the red test lead into the mA or 20A terminal or 10A terminal and the black test lead into the COM terminal. When measuring current at 200mA below, insert the red test lead into mA terminal while measuring current 200mA or above, insert the red test lead into 10A or 20A terminal
3. Set the rotary switch to an appropriate measurement position in A $\sim$  range.
4. Break the current path to be tested. Connect the red test lead to the more positive side of the break and the black test lead to the more negative side of the break.
5. Turn on power to the circuit.  
The measured value shows on the display.

### Note

- 1 If the value of current to be measured is unknown, use the maximum measurement position (20A) and 20A terminal or (10A) and 10A terminal, and reduce the range step by step until a satisfactory reading is obtained.
- 1 Replace appropriate rating fuse when the fuse is burnt.  
Fuse specification: 0.315A. 250V fast type fuse,  
 $\phi 5 \times 20\text{mm}$

- 1 20A Range: For continuous measurement  $\leq 10$  seconds and interval not less than 15 minutes
- 1 When current measurement has been completed, disconnect the connection between the test leads and the circuit under test.

### E. Measuring Resistance (see figure 5)



#### Warning

To avoid damage to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before measuring resistance.

To measure resistance, connect the Meter as follows:

1. Insert the red test lead into the  $V\Omega$  terminal and the black test lead into the COM terminal.
2. Set the rotary switch to an appropriate measurement position in  $\Omega$  range.
3. Connect the test leads across with the object being measured.


The measured value shows on the display.

#### Note

- 1 The test leads can add  $0.1\Omega$  to  $0.3\Omega$  of error to the resistance measurement. To obtain precision readings in low-resistance, that is the range of  $200\Omega$ , short-circuit the red and black test leads beforehand and record the reading obtained (called this reading as X). Then use the equation:  
measured resistance value (Y) – (X) = precision readings of resistance.
- 1 For high resistance ( $>1M\Omega$ ), it is normal taking several seconds to obtain a stable reading.

- 1 When there is no input, for example in open circuit condition, the Meter displays "1".
- 1 When resistance measurement has been completed, disconnect the connection between the test leads and the circuit under test.

## F. Frequency Measurement (see figure 6)



### Warning

To avoid harm to you or damage to the Meter, do not attempt to measure voltages higher than 60V in DC or 30V rms in AC although readings may be obtained. When the frequency signal to be tested is higher than 30V rms, the Meter cannot guarantee accuracy of the measurement.

To measure frequency, connect the Meter as follows:


1. Insert the red test lead into the  $V\Omega$  terminal and the black test lead into the COM terminal.
2. Set the rotary switch to an appropriate measurement position in kHz range.
3. Connect the test leads across with the object being measured.  
The measured value shows on the display.

### Note

- 1 When Hz measurement has been completed, disconnect the connection between the testing leads and the circuit under test.



## G. Temperature Measurement (see figure 7)




To measure temperature, connect the Meter as follows:

1. Insert the red temperature probe into the  $V\Omega$  terminal and the black temperature probe into the COM terminal.
2. Set the rotary switch to  $^{\circ}F$ .
3. Place the temperature probe to the object being measured.

The measured value shows on the display.

### Note

- 1 The Meter displays "1" when there is no temperature probe connection.
- 1 The included probe can only be used up to  $480^{\circ}F$ . For any measurement higher than that, the rod type temperature probe must be used instead.
- 1 When temperature measurement has been completed, disconnect the temperature probe from the meter.

**H. Capacitance Measurement (see figure 8)****⚠ Warning**

To avoid damage to the Meter or to the equipment under test, disconnect the tested circuit power when measuring on line capacitors and discharge all high-voltage capacitors before measuring capacitance. Use the DC voltage function to confirm that the capacitor is discharged.

To measure capacitance, connect the Meter as follows:

1. Insert the capacitor to be tested into the capacitance jack.
2. Set the rotary switch to an appropriate measurement position in  $\text{C}$  range.
3. Connect the test leads across with the object being measured.

The measured value shows on the display.

**Note**

- 1 For testing the capacitor with polarity, connect the red test lead to anode & black test lead to cathode
- 1 When the tested capacitor is shorted or the value is overloaded, the LCD display "1".
- 1 To minimize the measurement error caused by the distributed capacitor, the connection should be as short as possible.
- 1 It is normal to take a while for zeroing when changing over the measurement range. This process will not affect the accuracy of the final readings obtained.

## I. Measuring Diodes & Continuity


### Warning

To avoid damage to the Meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring diodes and continuity.

### Testing Diodes

Use the diode test to check diodes, transistors, and other semiconductor devices. The diode test sends a current through the semiconductor junction, and then measures the voltage drop across the junction. A good silicon junction drops between 0.5V and 0.8V.

To test out a diode out of a circuit, connect the Meter as follows:

1. Insert the red test lead into the  $V\Omega$  terminal and the black test lead into the COM terminal.
2. Set the rotary switch to .
3. For forward voltage drop readings on any semiconductor component, place the red test lead on the component's anode and place the black test lead on the component's cathode.

The LCD displays the nearest value of diode forward voltage drop.

### Note

- 1 In a circuit, a good diode should still produce a forward voltage drop reading of 0.5V to 0.8V; however, the reverse voltage drop reading can vary depending on the resistance of other pathways between the probe tips.
- 1 Connect the test leads to the proper terminals as said above to avoid error display. The LCD displays "1" indicating open-circuit for wrong connection. The unit of diode is Volt (V), displaying the positive-connection voltage-drop value.
- 1 When diode testing has been completed, disconnect the connection between the testing leads and the circuit under test.

## Testing for Continuity

To test for continuity, connect the Meter as follow:

1. Insert the red test lead into  $V\Omega$  terminal and the black test lead into the COM terminal.
2. Set the rotary switch to  $\rightarrow \text{---} \cdot \text{---} \rightarrow$  .

1. Connect the test leads across with the object being measured.
4. The buzzer sounds continuously if the resistance of a circuit under test is  $\leq 10\Omega$ , it indicates the circuit is in good connection.

The buzzer does not sound if the resistance of a circuit under test is  $> 100\Omega$ , it indicates broken circuit.


The buzzer may or may not sound if the resistance of a circuit under test is between  $10\Omega$  to  $100\Omega$ .

The LCD displays the resistance value of a circuit under test.

### Note

- 1 The LCD displays "1" indicating the circuit being tested is open.
- 1 When continuity testing has been completed, disconnect the connection between the testing leads and the circuit under test.

## J. Measuring Transistor (see figure 9)



( figure 9)

To measure transistor, connect the Meter as follows:

1. Set the rotary switch to hFE.
2. Insert the NPN or PNP type transistor to be tested into the transistor jack
3. The measured nearest transistor value shows on the display

## Note





- 1 When transistor measurement has been completed, remove the transistor from the transistor jack.

## Sleep Mode

To preserve battery life, the Meter automatically enters sleep mode after 15 minutes of inactivity. In this mode, the current draw is approximately 10  $\mu$ A.

The Meter can be activated by pressing the POWER two times.

## General Specifications

- 1 Maximum voltage between any Terminals and Grounding: 1000V.
- 1  $\Delta$ Fused Protection for mA Input Terminal: 0.315A, 250V fast type,  $\phi$  5 x 20mm.
- 1  $\Delta$ Fused Protection for 10A or 20A Input Terminal: Un-fused.
- 1 Range: Manual ranging.
- 1 Maximum Display: 1999.
- 1 Measurement Speed: Updates 2~3 times/second.
- 1 Temperature:
  - Operating: 0°C~40°C (32°F~104°F);
  - Storage: -10°C~50°C ( 14°F~122°F).
- 1 Relative Humidity:  $\leq$ 75% @ 0°C~30°C;  $\leq$ 50% @ 31°C~40°C
- 1 Altitude: Operating: 2000m; Storage: 10000m.
- 1 Battery Type: 9V NEDA1604 or 6F22 or 006P.
- 1 Battery Deficiency: Display “”.
- 1 Data Holding: Display “”
- 1 Negative reading: Display “”
- 1 Overloading: Display “1”.
- 1 Dimensions (HxWxL): 6.8” x 3.3” x 1.5”
- 1 Weight: Approx.310g (battery included).
- 1 Safety/Compliances: IEC61010 CAT I 1000V, CATII 600V overvoltage and double insulation standard.
- 1 Certificate: 

## Accuracy Specifications

Accuracy:  $\pm(a\% \text{ reading} + b \text{ digits})$ , guarantee for 1 year.

Operating temperature:  $23^{\circ}\text{C} \pm 5^{\circ}\text{C}$ .

Relative humidity:  $<75\%$ .

Temperature coefficient:  $0.1 \times (\text{specified accuracy}) / 1^{\circ}\text{C}$

### A. DC Voltage

Range	Resolution	Accuracy	Overload Protection
200mV	100 $\mu$ V	$\pm(0.5\%+1)$	250V DC or AC rms.
2V	1mV		
20V	10mV		
200V	100mV		
1000V	1V	$\pm(0.8\%+2)$	1000V DC or 750V AC.

Remark:

1 Input impedance:  $10\text{M}\Omega$ .

### B. AC Voltage

Range	Resolution	Accuracy	Overload Protection
2V	1mV	$\pm(0.8\%+3)$	1000V DC or 750V AC
20V	10mV		
200V	100mV		
750V	1V	$\pm(1.2\%+3)$	

Remark:

1 Input impedance:  $10\text{M}\Omega$ .

1 Frequency response: 40Hz~400Hz.

1 Display effective value of sine wave (mean value response).

**C. DC Current**

Range	Resolution	Accuracy	Overload Protection
2mA	1 $\mu$ A	$\pm(0.8\%+1)$	0.315A. 250V fast type fuse, $\phi$ 5 x 20mm
200mA	100 $\mu$ A	$\pm(1.5\%+1)$	
10A/20A	10mA	$\pm(2\%+5)$	Un-Fused

**Remark:**

- 1 20A Range: For continuous measurement  $\leq 10$  seconds and interval not less than 15 minutes
- 1 Measurement voltage drop: Full range at 200mV.

**D. AC Current**

Range	Resolution	Accuracy	Overload Protection
2mA	1 $\mu$ A	$\pm(1\%+3)$	0.315A. 250V fast type fuse, $\phi$ 5 x 20mm
200mA	100 $\mu$ A	$\pm(1.8\%+3)$	
10A/20A	10mA	$\pm(3\%+5)$	Un-Fused

**Remark:**

- 1 20A Range: For continuous measurement  $\leq 10$  seconds and interval not less than 15 minutes
- 1 Measurement voltage drop: Full range at 200mV.
- 1 Frequency response: 40Hz~400Hz
- 1 Display effective value of sine wave (mean value response).

**E. Resistance Test**

Range	Resolution	Accuracy	Overload Protection
200Ω	0.1Ω	$\pm(0.8\%+3)$	250V DC or AC rms
2kΩ	1Ω	$\pm(0.8\%+1)$	
20kΩ	10Ω		
2MΩ	1kΩ		
20MΩ	10kΩ	$\pm(1\%+2)$	

Remark:

- 1 Open circuit voltage:  
At 200MΩ range: approx. 3V  
Other ranges:  $\leq 700\text{mV}$

**F. Frequency**

Range	Resolution	Accuracy	Overload Protection
2kHz	1Hz	$\pm(2\%+5)$	250V AC
20kHz	10Hz	$\pm(1.5\%+5)$	

Remark:

- 1 Input Sensitivity:  $\leq 200\text{mV}$ .
- 1 When the input voltage is  $\geq 30\text{V rms}$ , no guaranteed accuracy.

**G. Temperature**

Range	Resolution	Accuracy	Overload Protection
-40°F~32°F	1°F	$\pm(4\%+4)$	250V AC
33°F~750°F		$\pm(2\%+8)$	
751°F~1800°F		$\pm(3\%+10)$	





## H. Capacitance

Range	Resolution	Accuracy	Overload Protection
2nF	1pF	±(4%+3)	250V AC
200nF	0.1nF		
20μF	10nF		

Remark:

1 Test signal: approx. 400Hz, 40mV rms.

## I. Diodes and Continuity Test

Function	Range	Resolution	Input Protection	Remark
Diode		1mV	250V DC or AC	Open circuit voltage approx. 2.8V
Continuity Buzzer		1Ω		Approx. <100Ω buzzer beeps continuously

## J. Transistor Test

Range	Remarks	Testing Conditions
hFE	Can measure NPN or PNP transistor. Display range: 0-1000β	Vce ≈ 2.8V I <sub>bo</sub> ≈ 10μA

## Maintenance

This section provides basic maintenance information including battery and fuse replacement instruction.


### Warning

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information. To avoid electrical shock or damage to the Meter, do not get water inside the case.

#### A. General Service


- 1 Periodically wipe the case with damp cloth and mild detergent. Do not use chemical solvent.
- 1 To clean the terminals with cotton bar with detergent, as dirt or moisture in the terminals can affect readings.
- 1 Press the Meter power off when it is not in use and take out the battery when not using for a long time.
- 1 Do not store the Meter in place of humidity, high temperature, explosive, inflammable and strong magnetic field

#### B. Replacing the Battery (see figure 10)



( figure 10)


### Warning

To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator  appears.

To replace battery:

1. Disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.
2. Press the Meter power off
3. Remove the screw from the battery compartment, and then take out the battery door from the battery compartment.
4. Remove the battery from the battery compartment.
5. Replace the battery with a new 9V battery (NEDA 1604 or 6F22 or 006P).
6. Rejoin the battery door and the battery compartment, and install the screw

C. Replacing the Fuses (see figure 11)



### ⚠ Warning

To avoid electrical shock or arc blast, or personal injury or damage to the Meter, use specified fuses ONLY in accordance with the following procedure.

To replace the Meter's fuse:

1. Disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.
2. Press the Meter power off.
3. Remove the holster from the Meter.
4. Remove the screw from the battery compartment, and then take out the battery door.
5. Remove the screw inside the battery compartment and also the other two screws from the case bottom, and then separate the case bottom from the case top.

6. Remove the fuse by gently prying one end loose, and then take out the fuse from its bracket.
7. Install ONLY replacement fuses with the identical type and specification as follows and make sure the fuse is fixed firmly in the bracket.  
0.315A. 250V fast type fuse,  $\phi$  5 x 20mm.
8. Rejoin the case bottom and the case top, and install the screw.
9. Rejoin the battery door from the battery compartment, and install the screw
10. Rejoin the holster and the Meter.

An open fuse is always the result of improper operation.

**\*\* END \*\***

This operating manual is subject to change without notice.



Model 72-7925: OPERATING MANUAL

©Copyright 2005 Tenma Test Equipment.  
All rights reserved.

Tenma Test Equipment  
405 S. Pioneer Blvd.  
Springboro, Ohio 45066  
[www.tenma.com](http://www.tenma.com)