CSM_H5F_DS_E_2_1

Daily Time Control with Simple Operations (Operation Day Selection Possible)

- Up to 12 ON/OFF operations (24 for pulse-output operation).
- Special holidays can be handled easily with the holiday setting function.
- Adjustments for sudden schedule changes can be made easily using output override and automatic return operation.
- The operation program can be checked easily with the program check function.
- Enables pulse output operation and summer time setting.
- Incorporates finger-safe terminals.
- Conforms to UL, CSA, and CE marking.
- Meets a variety of mounting requirements: flush mounting, surface mounting, and DIN track mounting.



Model Number Structure

■ Model Number Legend



- 1. Mounting method
 - None: Flush mounting
 - F: Surface mounting
 - K: Surface mounting/track mounting
- 2. Language
 - B: English

Ordering Information

■ List of Models

Wiring	Mounting method	Model
Screw terminals	Flush mounting	H5F-B
	Surface mounting	H5F-FB
	Surface mounting/track mounting	H5F-KB

■ Accessories (Order Separately)

Name		Models	
Soft cover		Y92A-48F1	
Hard cover	For H5F-B	Y92A-48	
	For H5F-FB/-KB	Y92A-48E (See note 1.)	
Flush Mounting Adapter (See note 2.)		Y92F-30	
Mounting Track	50 cm (l) × 7.3 mm (t)	PFP-50N	
	1 m (l) × 7.3 mm (t)	PFP-100N	
	1 m (l) × 16 mm (t)	PFP-100N2	
End Plate		PFP-M	
Spacer		PFP-S	

Note: 1. Supplied with H5F-KB model.

2. Supplied with H5F-B (flush-mounting) model.

Specifications

Ratings

Rated supply voltage	100 to 240 VAC (50/60 Hz)	
Operating voltage range	85% to 110% of rated supply voltage	
Power consumption	Approx. 2.4 VA at 264 VAC	
Control outputs	Contact output: SPST-NO, 15 A at 250 VAC, resistive load, 10 A at 24 VDC, resistive load Minimum applied load: 100 mA at 5 VDC (failure level: P, reference value)	
	NEMA A300 Pilot Duty, 1/3 HP at 120 VAC	
External connections	Screw terminals (M3.5 screw)	
Terminal screw tightening torque	0.98 to 1.17 N · m	

■ Characteristics

Accuracy of operating time	±0.01% ±0.05 s max. (see note 1)			
Setting error				
Influence of voltage				
Influence of temperature				
Time accuracy	±15 s per month (at 25°C)			
Memory protection	Continuous use: 5 years min. (at 25°C (lithium battery)	C); Power-interrupt	ion rate of 50%: 10 years min. (at 25°C) (see note 2)	
Insulation resistance	100 M Ω min. (between current-carryin power supply circuit and control output	ng terminals and e ut circuit and betwe	xposed non-current-carrying metal parts, between operating een non-continuous contacts)	
Dielectric strength	2,000 VAC, 50/60 Hz for 1 min (between current-carrying terminals and exposed non-current-carrying metal parts and between operating power supply circuit and control output circuit) 1,000 VAC, 50/60 Hz for 1 min (between non-continuous contacts)			
Noise immunity	1.5 kV (between power terminals) Square-wave noise by noise simulato	r (pulse width: 100) ns/1 μs, 1-ns rise)	
Vibration resistance	Destruction:10 to 55 Hz with 0.375-m Malfunction:10 to 55 Hz with 0.25-mn	m single amplitude n single amplitude	e, four cycles each in three directions (8 minutes per cycle) for 10 minutes each in three directions	
Shock resistance	Destruction:300 m/s ² 3 times each in 6 directions Malfunction:100 m/s ² 3 times each in 6 directions			
Ambient temperature	Operating:-10°C to 55°C (with no icing) Storage: -25°C to 65°C (with no icing)			
Ambient humidity	Operating: 35% to 85%			
Life expectancy	Mechanical (at 20°C): 100,000 operations min. Electrical (at 20°C): 50,000 operations min. (15 A, 250 VA 50,000 operations min. (10 A, 250 VA 50,000 operations min. (10 A, 250 VA 50,000 operations min. (100 W, 100 V 10,000 operations min. (300 W, 100 V	IC, resistive load) IC, motor load) IC, inductive load (/AC, lamp load) /AC, lamp load)	cosφ = 0.7))	
Approved safety standards	UL508/Listing, CSA C22.2 No. 14, conforms to EN61010-1 (Pollution degree 2/overvoltage category II) Conforms to VDE0106/P100 (finger protection). Conforms to Electrical Appliance and Material Safety Law (for Japan)			
EMC	(EMI) Emission Enclosure: Emission AC mains: (EMS) Immunity ESD: Immunity RF-interference: Immunity Conducted Disturbance: Immunity Burst: Immunity Surge: Immunity Surge: Immunity Voltage Dip/Interruption: Immunity Magnetic Power Field:	EN61326 EN55011 Group EN55011 Group EN61326 EN61000-4-2: EN61000-4-3: EN61000-4-6: EN61000-4-4: EN61000-4-5: EN61000-4-11: EN61000-4-8:	 1 class A 4 kV contact discharge (level 2) 8 kV air discharge (level 3) 10 V/m (Amplitude-modulated, 80 MHz to 1 GHz, 1.4 to 2 GHz) (level 3) 10 V (0.15 to 80 MHz) (according to EN61000-6-2) 2 kV power-line (level 3) 1 kV I/O signal-line (level 4) 1 kV V line to lines (power and output lines) (level 2); 2 kV line to ground (power and output lines) (level 3) 0.5 cycle, 100% (rated voltage) 30 A/m 	
Case color	Light gray (Munsell 5Y7/1)			
Weight	H5F-B; approx, 115 g; H5F-KB; appro	ox. 160 a: H5F-FB:	approx, 130 g	

Note: 1. The total error including the repeat accuracy, setting error, variation due to voltage change, and variation due to temperature change is $\pm 0.01\% \pm 0.05$ s max. $\pm 0.01\%$ also indicates an error in the time interval of a set time.

2. The total time when power is not being supplied.

Connections

Terminal Arrangement



- Note: 1. The Time Switch uses M3.5 terminals.
 - 2. The Time Switch output is no-voltage contact output. An external power supply is required to drive the load.
 - 3. Applicable wire: 600-V vinyl-insulated wire (solid wire or twisted wire, copper), 14 to 24 AWG, 2 wires max. per terminal.
 - 4. Applicable tightening torque: 0.98 to 1.17 N·m.
 - 5. Recommended fuse: T2A, 250 VAC, time delay, low breaking capacity.

Operation

■ Operation

Operation method	Digital quartz		
Time range	24 h \times 7 days (Operation days can be specified.)		
Operation	1. Daily operation (Multiple-day operation possible.)		
	2. Pulse-output operation (Pulse width can be set in units of 1 s from 1 to 59 s and in units of 1 min from 1 to 60 min.)		
	3. Partial operation on specified day (One or some of the operations for certain days can also be executed on other days.)		
	4. Forced ON/OFF operation		
	5. Holiday operation		
	6. Output override and automatic return operation		
Display	1. Day, hours (12-hour (am/pm) or 24-hour clock), minutes (0:00 to 11:59 a.m./ 0:00 to 11:59 p.m., 0:00 to 23:59)		
	2. Digital display by LCD. Character height: 8 mm		
	3. Digital display of present time and time schedules for operation		
	4. Timing chart display of present time and time schedules for operation		
Other functions	Program check function, summer time function		
Number of circuits	1 independent circuit		
Minimum setting unit	1 min		
Minimum set interval	1 min		
Number of operations that can be set	24 (see note)		

Note: Up to 12 ON/OFF operations are possible per day. (For pulse-output operation, the number is 24.)

H5F

■ Operation Functions

Timer operation (ON/OEE operation)	Controls the output according to preset of ON and OEE times
	• Minimum setting unit: 1 min
	• Up to 12 UN/OFF operations are possible per day.
ON time OFF time	
Pulse-output operation	Output turns ON for a fixed period (pulse width) at the set time.
Pulse width	 Pulse width: 1 to 59 s, or 1 to 60 min. (The same pulse width setting is used for all types of output operation.)
	 The pulse width can be set in units of 1 s or 1 min.
ON time	 Up to 24 pulse-output operations are possible per day.
Forced ON/OFF operation	Forcibly turns ON/OFF the output by the output ON/OFF switch.
Override and automatic return operation	Using the output ON/OFF switch and the Write Key, control output is held in the ON state until the next OFF time
Regular program	 It is also possible to hold the control output in the OEE state until the next ON time
	• Operation after the output turns OFF (or ON) will be based on the regular program
operation	This function can be used with pulse output exerction
Start of override and	• This function can be used with pulse-output operation.
automatic return operation	
Partial operation on specified day	The Time Switch operates according to only some of the programs on a user-specified day.
Program 1 Program 2 (special)	 It is not possible to set operation to be executed only on the specified day.
Regular	This function can be used with pulse output operation
program	This function can be used with pulse-output operation.
operation day	
Operation on	
specified day	
Holiday setting	It is possible to set a day in the present week as a holiday (i.e., a non-operation day: output
Operation on Operation	OFF regardless of the settings). When that day has passed, operation will continue according to the regular program, and operation will be executed as normal on that day from the follow.
Regular	ing week
program	This function can be used with pulse-output operation.
Operation in present week	· · · · · · · · · · · · · · · · · · ·
Operation from next week	
	1

Note: Both the timer operation and the pulse-output operation cannot be programmed together.

■ Operation When Power Turns OFF

- 1. The time and settings are backed up using a lithium battery.
- 2. The display stays ON but the output turns OFF.
- **3.** Settings for all types of operation except override and automatic return operation are possible.

Nomenclature

Front Panel



No.	Name	Function
0	Mode Key	Switches between time adjustment mode, the operation setting modes, and run mode.
0	h (Hour) Key	Sets hours or switches between 12-hour (am/pm) and 24-hour display.
8	m/ PWD (Minute/Pulse Time Width) Key	Sets minutes or a pulse time width.
4	Write Key	Writes the set data to memory or confirms settings with the program check function.
6	d/Test (Day Shift/Program Test) Key	Moves the cursor to specify a day or starts the program check function.
6	Select/Holiday Key	Specifies or cancels a specified day or switches to holiday setting mode.
0	CLR/+1h (Clear/Summer Time) Key	Erases the set data and initializes the day of operation or sets/clears summer time.
8	Output ON/OFF switch	ON:Turns on the output regardless of the setting.AUTO:Turns on/off the output according to the setting.OFF:Turns off the output regardless of the setting.
		Override and automatic return operation can be executed by using this key in combina- tion with the Write Key.
9	TMR/(P) (Timer/Pulse output) Key	Selects timer operation or pulse-output operation.

Display



Dimensions

Note: All units are in millimeters unless otherwise indicated.

H5F-B (provided with Y92F-30 Flush Mounting Adapter) (Flush Mounting)



H5F-KB (Surface/Track Mounting)



Wiring cutout sections: Cut out as required for wiring.

Mounting Hole Cutout Dimensions



M4 tapping screws provided. Approximate pilot hole dimensions: Panel thickness of 0.8 to 1.2 mm: 3.6-mm dia. Panel thickness of 1.6 to 4.0 mm: 3.7-mm dia.

SU MO

194 1950 -

Accessories (Order Separately)

Note: Depending on the operating environment, resin products may deteriorate, contract, or harden. They must be replaced on a regular basis.

Soft Cover

Y92A-48F1



Settings can be changed by pressing on the front of the Cover. The settings are harder to change, however, with the Cover mounted. Confirm that this does not hamper operation. Although the Soft Cover provides protection equivalent to IP54F, do not use the Time Switch in locations where it may be directly subject to splashes of oil.

Flush Mounting Adapter (provided with H5F-B)

Y92F-30



The Flush Mounting Adapter can be purchased individually if it is lost or damaged.

Mounting Track



Note: The values shown in parentheses are for the PFP-50N.



Hard Cover (provided with H5F-KB)

Y92F-48 (for H5F-B) Y92A-48E (for H5F-FB/-KB)



Precautions

Refer to Safety Precautions for All Timers.

∕!∖ CAUTION

Do not touch any of the terminals while power is being supplied. Doing so may result in electric shock. Be sure to mount the terminal cover after wiring.

Do not use the Time Switch in locations subject to flammable or explosive gases. Doing so may result in explosion.

Do not disassemble, repair, or modify the Time Switch. Doing so may result in electric shock, fire, or malfunction.

Tighten terminal screws to the specified torque (approx. 0.98 N·m). Loose screws may occasionally cause fires or malfunction. (Maximum torque: 1.17 N·m)

Before changing times or other settings while power is being supplied, either turn OFF the power on the load side or set the output ON/OFF switch to OFF and confirm the safety of the system.

The life expectancy of the output relays depends on the switching capacity and switching conditions. Consider the actual application conditions and use the Time Switch within the rated load and electrical service life. If using the Time Switch beyond its ratings is unavoidable, use it together with an electromagnetic switch or contactor as shown in the following diagram.



Using the Time Switch beyond its life expectancy may result in contact deposition or burning.

Do not disassemble the Time Switch, deform the Time Switch by applying pressure, heat the Time Switch to temperatures above 100°C, or incinerate the Time Switch. Doing any of these may cause the built-in lithium battery to ignite or rupture.

Wiring

- Be sure to wire the terminals correctly.
- Do not connect more than two crimp terminals to each Time Switch terminal. Faulty contact may result in burn injury or fire.
- Perform wiring using appropriate wires of the type specified in this document. Using a different type of wire may result in burn injury or fire due to abnormal heat generation.

Power Supplies

- Make sure that the fluctuation of the supply voltage is within the permissible range.
- Make sure that the voltage applied is within the specified range, otherwise the internal elements of the Time Switch may be damaged.
- Apply the power supply voltage through a breaker, relay or switch in such a way that the voltage reaches a fixed value immediately, otherwise they may not be reset or a Time Switch error may result.
- When the power is turned ON, an inrush current will flow for a short time (approx. 2 A for 0.3 ms at 264 VAC). Depending on the power supply capacity, operation may not start. Be sure to use a power supply with a sufficient capacity and a breaker.

Operating Environment

- Do not use the Time Switch in locations where condensation may occur due to high humidity or where temperature changes are severe.
- Do not leave the Time Switch for long periods (i.e., one month or longer) at a high temperature with output current in the ON state. Doing so may result in the premature deterioration of internal components (e.g., electrolytic capacitors).
- Separate the Time Switch from any potential sources of noise, such as high-voltage lines. When using inductive loads (e.g., electro-magnetic relays), connect noise-absorbing elements (resistor and capacitor) to both ends of the coil.
- Separate the Time Switch from the source of static electricity when using the Time Switch in an environment where a large amount of static electricity is produced (e.g., forming compounds, powders, or fluid materials being transported by pipe).
- Use the Time Switch within the ratings specified for temperature and humidity.
- Do not use the Time Switch in environments subject to shocks or vibration beyond the ranges specified in this document.
- Do not use the Time Switch in locations subject to dust, corrosive gases, or direct sunlight.
- Store at the specified temperature. If the H5F has been stored at a temperature of less than -10° C, allow the H5F to stand at room temperature for at least 3 hours before use.
- This Time Switch is not waterproof or oil-proof. Do not use it in locations where water or oil may enter the Time Switch interior.
- Organic solvents (such as paint thinner), as well as very acidic or basic solutions might damage the outer casing of the H5F.

Installation

- Mounting the Time Switches side-by-side may reduce the life expectancies of internal components.
- When using heaters, be sure to use a thermal switch for the load circuit.
- When driving an inductive load (e.g., coil), a surge voltage is generated when the contacts (i.e., Time Switch output) are switched, and in some cases this may damage other devices connected to the Time Switch or the same line. Absorb the surge with a capacitor and resistor as shown in the following diagram.



As a rough guide, the capacitor (C) and resistor (R) should have the following specifications:

C: 0.5 to 1 μF for a switching current of 1 A R: 0.5 to 1 Ω for a switching voltage of 1 V

Use a capacitor with a dielectric strength appropriate for the power supply voltage. Use an AC-type capacitor with AC circuits. There may be cases where, due to inconsistencies in the nature and characteristics of the load, delays in restoring the load may cause problems. Be sure to confirm that correct operation is possible under the actual operating conditions.

Precautions for EN61010-1 Conformance

The H5F Time Switch conforms to EN61010-1 provided that the following conditions are satisfied:

Basic insulation is provided between the power supply and output terminals of the H5F.

- Output terminals are connected to devices without exposed charged parts.
- Output terminals are connected to devices with basic insulation that is suitable for the maximum operating voltage.

Others

None of the Time Switch components are user-replaceable, including the battery.

Operating Method

Operating Method

Selecting the Mode

All of the modes can be selected using $\fbox{MODE},$ $\fbox{HOLIDAY},$ and \fbox{TEST} Keys.



- Note: 1. After the last item is displayed, the mode automatically returns to run mode.
 - 2. At the time of delivery, the mode is the run mode.

Setting the Time

Example: Changing the current time setting from Wednesday 10:30 am to Monday 4:00 am.

 Press the MODE Key for 1 s min. to enter time adjustment mode. The Symbol flashes.

2. Move the - symbol to Monday

and [m/@WD] Keys.

using the d Key. Change the

time to 4:00 am using the h



The color indicates flashing



- **3.** Press the WRITE Key. The colon will flash and the clock will start (from 0 s).
- 4. Press the MODE Key 3 times to return to the run mode.

Factory Setting

At the time of delivery, the mode is run mode and there is no current time setting. Before making any other settings, press the $\boxed{\text{MODE}}$ Key for 1 s min. to enter time adjustment mode and set the current time using the above procedure.



SU MO TU WE TH FR SA

SU MO TU WE TH FR SA

ĂM

PW

1

Note: 1. The set time is enabled when the WRITE Key is pressed.
2. The time can be displayed in either 12-hour (am/pm) or 24-hour display. (Refer to page 14.)

Setting Timer Operation

Example: Setting the Time Switch to operate from Monday to Friday between 8:30 am and 5:15 pm

Non-operation Operation Operation Operation Operation Non-operation

Sunday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday
8:3	0 am 5:1	5 pm				

1. Enter operation time setting mode using the MODE Key. The P symbol flashes.

(If only the hour or the minute (but

not both) is set, the operation set-

ting time display will flash to indi-

4. Set the OFF time to 5:15 pm using

the h and m/®WD Keys.

3. Press the WRITE Key.

cate an error.)



2. Set the ON time to 8:30 am using the h and m/@WD Keys. SU MO TU WE TH FR SA



SU MO TU WE TH FR SA

- SU MO TU WE TH FR SA





SU MO TU WE TH FR SA

SU MO TU WE TH FR SA



The color indicates flashing

PW

PW

PW

PW

AN

SU MO TU WE TH FR SA

7 P

Ρ

 Set the ON time (the time when pulse-output operation starts) to 8:25 am using the <u>h</u> and m/@WD Keys.

3. Set the pulse width to 30 s using

1 to 60 min.)

4. Press the WRITE Key.

the m/eWD Key. (The pulse width

can be set in the range 1 to 59 s or

- Press the WRITE Key. (Repeat steps 5 and 6 to make other settings if necessary.)
- 7. Press the MODE Key to enter the operation date setting mode.

WRITE Lit (operation day)



9. Press the MODE Key. The Time Switch will enter run mode and operation based on the settings will start.



Note: 1. Up to 24 sets of settings are possible.

- 2. Switching between timer operation and pulse-output operation will clear the operation start time, operation day, and pulse width settings.
- 3. Both the timer operation and pulse-output operation cannot be programmed together.

- Press the WRITE Key. (Repeat steps 2 to 5 to make other settings if necessary.)
- 6. Press the MODE Key to enter operation date setting mode.

(-) by pressing the WRITE Key.



PW



SU MO TU WE TH FR SA

SU MO TU WE TH FR SA

7 P



8. Press the MODE Key. The Time Switch will enter run mode and operation based on the settings will start.



- Note: 1. Up to 12 sets of ON-OFF settings are possible.
 - 2. Be sure to set both ON and OFF times. If only the ON time is set, the setting will be invalid.
 - 3. At the time of delivery, all days are set as operation days.
 - 4. Multiple-day operation is possible.
 - Continuous operation for more than 24 hours is possible by combining 2 or more sets of settings. (Refer to page 16.)
 Both the timer operation and the pulse-output operation
 - Both the timer operation and the pulse-output operation cannot be programmed together.

Setting Pulse-output Operation

Using pulse-output operation, the Time Switch can be set to operate at the same time every day for a fixed period.

Example: Setting the Time Switch to turn ON for 30 s from 8:25 am, Monday to Friday

Non-operation	Operation	Operation	Operation	Operation	Operation	Non-operatio	r
Sunday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	
	30 s						
8:	25 am						

- Enter operation time setting mode using the MODE Key. The P symbol flashes.
- Press the TMR® Key to set the Time Switch for pulse-output operation. The P symbol flashes. (The Time Switch is set for timer operation at the time of delivery.)



SU MO TU WE TH FR SA



H5F

0:30

Setting Partial Operation on Specified Day

The Time Switch can be set to operate according to only some of the settings on a user-specified day.

Example: Monday to Friday: ON at 8:30 am; OFF at 0:30 pm ON at 1:15 pm; OFF at 5:15 pm ON at 8:30 am; OFF at 0:30 pm Saturday: Non-operation Operation Operation Operation Operation Operation Specified day Saturday Friday Sundav Mondav Wednesday Thursday Tuesday . . e Ó • • 8:30 am to 0:30 pm (Specified Day Operation) ▲ 1:15 pm to 5:15 pm 1. Enter operation time setting mode The color indicates flashing using the [MODE] Key. SU MO TU WE TH FR SA P PW 2. Press the SELECT Key. The S symbol will be displayed. Set the SU MO TU WE TH FR SA ON time for the specified day to 8:30 am using the h and s ΑN m/@WD Keys. PW 7 3. Press the WRITE Key. SU MO TU WE TH FR SA S P PW 4. Set the OFF time for the specified SU MO TU WE TH FR SA day to 0:30 pm using the h and m/@WD Keys. 7 S PM PW The color indicates flashing 5. Press the WRITE Key. SU MO TU WE TH FR SA Set the time to 1:15 pm using the h and m/@WD Keys. РM 7 P PW Ť 7 6. Press the WRITE Key. SU MO TU WE TH FR SA Set the time to 5:15 pm using the h and m/@WD Keys. PM PW 7. Press the WRITE Key. SU MO TU WE TH FR SA Press the MODE Key to enter operation date setting mode.

8. Move the - symbol to Saturday using the d Key. Make the operation day indicator flash by pressing the WRITE Key. Move the present day indicator to Sunday using the d Key. Clear the operation day indicator by pressing the WRITE Key.

PW	P
_	

WRITE

SU MO TU WE TH FR SA

*** * * * * *** *



- 9. Press the MODE Key. SU MO TU WE TH FR SA The Time Switch will enter run mode and operation based on the settings will start. The operation AN day indicator (----) of the specified ON day will flash. PW
- Note: 1. Partial operation on specified day can be set for two or more programs. For each program, however, the S must be displayed by pressing the SELECT Key.
 - 2. Two or more days can be specified as specified days.
 - 3. Partial operation on specified day can also be set for pulseoutput operation.

Changing Timer Operation Settings

Example: Changing the ON time for program 1 from 8:30 am to 7:45 am The color indicates flashing

- 1. Enter operation time setting mode using the MODE Key. The ON time for program 1 will be displayed.
- 2. Change the ON time to 7:45 am using the h and m/@WD Keys.
- 3. Press the WRITE Key. The OFF time for program 1 will be displayed. (Make changes, if necessary, using the same procedure as for ON time.)
- 4. Press the MODE Key to enter operation date setting mode. The operation dates will be displayed. (Make changes, if necessary, using the d and WRITE Keys.)
- 5. Press the MODE Key. The Time Switch will enter run mode and operation will start.

Ρ

PW

Note: Operation based on the changed settings will start as soon as the Time Switch returns to run mode.



SU MO TU WE TH FR SA



Ρ

Changing Pulse-output Operation Settings

Example: Changing the pulse width from 30 s to 20 s

- 1. Enter operation time setting mode using MODE Key. The pulse width is displayed.
- 2. Change the pulse width to 20 s using [m/@WD] Kev.





- 3. Press the WRITE Key. The ON time for program 1 will be displayed. (Make changes, if necessary, using the h, m/@WD and WRITE Key.)
- 4. Press the MODE Key to enter operation date setting mode. The operation dates will be displayed. (Make changes, if necessary, using the d and WRITE Keys.)
- 5. Press the MODE Key. The Time Switch will enter run mode and operation will start.
- Note: Operation based on the changed settings will start as soon as the Time Switch returns to run mode.



SU MO TU WE TH FR SA











4. Press the MODE Key twice. The Time Switch will enter run mode and operation based on the new

programs) will start.



Note: Settings for pulse-output operation can be cleared for individual programs in the same way.

Clearing all Settings

- 1. Enter operation time setting mode or operation date setting mode using the MODE Key.
- 2. Press the CLR Key for <u>3 s min.</u> The clearing process will be completed 3 s has elapsed. Output will turn OFF immediately.
- 3. When all the settings have been cleared, the operation time, operation day, pulse width, holiday, partial operation on specified day, and override and automatic return operation settings will be returned to their factory settings.

Note: The clearing process will be canceled if the CLR Key is released while **[L** is still flashing and only the settings for the display program will be cleared.



SU MO TU WE TH FR SA

2. Press the WRITE Key twice. The ON time for program 2 will be displayed.

and OFF settings are cleared with

just one operation. If this operation

is performed while output is ON,

output stays ON until the Time

settings (i.e. without the cleared

Switch returns to run mode.)

Individual Programs

1. Enter operation time setting mode

program 1 will be displayed.

using MODE Key. The ON time for

Clearing the ON/OFF Settings for

Example: Clearing the settings for program 2

РM ON PW 3. Press the CLR Key. (Both the ON





The color indicates flashing SU MO TU WE TH FR SA

SU MO TU WE TH FR SA

SU MO TU WE TH FR SA

AM ON

PW

ON PW

PW

n s

P

P

Switch

OFF 🗌

Holiday Setting Function

The following example shows how to stop operation for a certain day in the present week and restore normal operation from the following week using the holiday setting function.

Example: Stopping operation for Friday and Saturday in the current week and resuming normal operation from the following week

- **1.** Press the $\overline{\text{HOLIDAY}}$ Key for 2 s min. in run mode to enter holiday setting mode. Hand will flash and the operation day indicator (-) will light under the days set for operation day.
- Move the v symbol to Friday using d Key. Clear the operation day indicator (-) by pressing the WRITE Key. Repeat the procedure for Saturday. (Press the WRITE Key again to clear the holiday setting.)
- 3. Press the [HOLIDAY] Key. The Time Switch will enter run mode and the operation day indicator under the days set as holidays will turn OFF. (When a day set as a holiday has passed, the (-) indicator under that day will automatically turn ON again.)



The color indicates flashi SU MO TU WE TH FR SA





- Note: 1. Any day in the 7-day period starting from the present day can be set as a holiday.
 - 2. Operation based on the new settings (i.e., including the holiday setting) will start as soon as the Time Switch returns to run mode.
 - 3. Holiday setting mode can be entered from run mode only.
 - 4. If the present day setting in time adjustment mode is changed, all holiday settings will be cleared.
 - 5. If a day set as a holiday is changed in operation date setting mode, the holiday setting for that day will be cleared.

Summer Time (DST) Function

The summer time function allows the Time Switch to be used in regions that observe daylight saving time during the summer.

Each time the +1h Key is pressed in run mode, the present time will switch between the (standard) present time and the present time + 1 hour (summer time).



- summer time is set.
 - 2. The contents of the programs are not changed.
 - 3. The summer time setting can only be set or cleared in run mode

Switching between 12-hour (am/pm) and 24-hour Display

Each time the h Key is pressed for 2 s min. in run mode, the time display switches between 12-hour (am/pm) and 24-hour display.



Note: 1. Switching is possible only in run mode. 2. The factory setting is 12-hour (am/pm) display.

Override and Automatic Return Operation

Override and automatic return operation can be used to handle sudden schedule changes without making changes to the program. The output status can be set to ON or OFF directly using the output ON/ OFF switch. This output status is then held until the next ON/OFF operation time.

Example 1: Starting operation earlier than the scheduled time on the present day only

Regular setting:

ON at 8:30 am; OFF at 5:15 pm

Use the following procedure to start operation at 7:00 am for the present day only.



- 1. Change the setting of the output ON/OFF switch from AUTO to ON.
- 2. Return the setting of the output ON/OFF switch from ON to AUTO while holding down the WRITE Key. The ON state will be held from the point at which this operation is performed (indicated by the arrow) until the next (regular) OFF time.

Example 2: Stopping operation earlier than the scheduled time on the present day only

Regular setting: ON at 8:30 am; OFF at 5:15 pm

Use the following procedure to stop operation at 3:00 pm for the present day only.



1. Change the setting of the output ON/OFF switch from AUTO to OFF.

2. Return the setting of the output ON/OFF switch from OFF to AUTO while holding down the WRITE Key. The OFF state will be held from the point at which this operation is performed (indicated by the arrow) until the next (regular) ON time.

Switch **ON** AUTO off 🗗

Note: 1. This operation is possible in run mode only.

- 2. Override and automatic return operation can be cleared by setting the output ON/OFF switch to the opposite of the present status. For example, if the output is ON, override and automatic return operation can be cleared by setting the output ON/OFF switch to OFF
 - Override and automatic return operation cannot be set or cleared if power is not being supplied to the Time Switch.
- 4. Override and automatic return operation is cleared if any of the settings are changed.

Using Override and Automatic Return Operation for **Pulse-output Operation**

Override and automatic return operation proceeds in the following way when used for pulse-output operation.

- If override and automatic return operation starts with a forced ON, output is turned ON for the time corresponding to the set pulse width
- · If override and automatic return operation starts from a forced OFF, output remains OFF until the pulse output ends.

The operation method is the same as for timer operation.

Example 1: Override and automatic return operation starting with a forced ON while output is ON (pulse width: 30 min)



- △ Point at which the Output ON/OFF Key changes from AUTO to ON.
- Point at which the Output ON/OFF Key changes from ▼ ON to AUTO with the WRITE Key held down.

Example 2: Override and automatic return operation starting with a forced ON while output is OFF (pulse width: 30 min)



 $^{\bigtriangleup}$ Point at which the Output ON/OFF Key changes from AUTO to ON.

Point at which the Output ON/OFF Key changes from ON to AUTO with the WRITE Key held down.

Example 3: Override and automatic return operation starting from a forced OFF while output is ON (pulse width: 30 min)



- $^{\bigtriangleup}$ Point at which the Output ON/OFF Key changes from AUTO to OFF.
- Point at which the Output ON/OFF Key changes from OFF to AUTO with the WRITE Key held down.

Program Check Function

The days and times at which output turns ON or OFF over the course of one week can be displayed continuously in the actual order in which they will occur.

1. Press the TEST Key for 2 s min. in run mode to start the program check. The display will flash **E5E** and the day and time of the next change in

output status will be displayed.

The color indicates flashing items. SU MO TU WE TH FR SA



e example, output will In the ab turn ON at 1:15 pm on Monday

SUMOTU WE TH FR SA

In the above example, output will turn OFF at 5:30 pm on Monday.

SU MO TU WE TH FR SA

PW

PW

Ę

- 2. Press the WRITE Key. The display will change to the day and time of the next change in output status. (Continue pressing the WRITE Key to display the days and times for one week.)
- 3. If the \fbox{WRITE} Key is pressed with the last setting for the week displayed, End is displayed for 2 s and then the Time Switch automatically returns to run mode.

Note: 1. The program check can be started from run mode only.

- 2. Press the TEST Key again to return to run mode before reaching the end of the program check function display seauence.
- з. The ON and OFF symbols (-/--) displayed during program check have no effect on the present operation.
- 4. Only ON times are displayed for pulse-output operation.

Setting Examples

As shown in the following examples, continuous operation for more than 24 hours is possible by combining two or more settings. Refer to Setting Precautions for more details.

Example 1: Use the settings given below to turn ON output from 8:30 am on Monday right through to 0:30 pm on Saturday.





Operation time settings:

▲ 1:00 pm to 8:00 am (specified day operation)
 ● 7:00 am to 2:00 pm

Operation day settings:

Specified day (\triangle): Monday Operation day (\bigcirc): Tuesday, Wednesday, Thursday, Friday

Example 3: Use the settings given below to turn ON output from 8:00 pm to 7:00 am from Monday to Thursday and from 8:00 pm on Friday right through to 7:00 am on Monday.



Operation time settings:

▲ 1:00 pm to 8:00 am (specified day operation)

• 7:00 am to 2:00 pm

Operation day settings:

Specified day (\triangle): Monday Operation day (\bigcirc): Tuesday, Wednesday, Thursday, Friday

Setting Precautions

1. If settings overlap, the earliest ON time and the latest OFF time will be used.



- Output will stay ON continuously without interruption.
- If an ON and OFF setting are made for the same time, the output status will not change at that time.
- 2. If there is a switch between timer operation and pulse-output operation, the operation time, operation day, and pulse width settings will all be cleared.

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

In the interest of product improvement, specifications are subject to change without notice.

Read and Understand This Catalog

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranty and Limitations of Liability

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

Application Considerations

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- · Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this catalog.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- · Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

Disclaimers

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the products may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

PERFORMANCE DATA

Performance data given in this catalog is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

ERRORS AND OMISSIONS

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

2008.11

In the interest of product improvement, specifications are subject to change without notice.

OMRON Corporation Industrial Automation Company

http://www.ia.omron.com/