

SPARE PARTS LIST

MODEL NO. 6270D

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	125102-2	SPEED CHANGE LEVER ASSY BHP4606317/37/47DWDE/6260-6280D		
002	183823-2	HOUSING SET 6270D INC. 15	1	
003	860440-2	NAME PLATE 6270D	1	
004	266130-9	*TAPPING SCREW BIND 3X 16 10PK6313DW	9	
005	232182-2	LEAF SPRING 5PK	1	
006	417283-9	F/R CHANGE LEVER 6503DW/BTD0426260D-6280D	1	
007	650556-9	SWITCH C3NA-1-M1 SINGLE VA/REV	1	
008	643909-9	BATTERY HOLDER 5093DW/UH3000D 6074D/6795D	1	
009	251468-5	*-FLAT HD SCREW M6X22 5PK	1	
010	763185-0	KEYLESS CHUCK 10 6260/70/80D	1	
011	125237-9	GEAR ASSY 6260D	1	
012	629817-8	DC MOTOR 6270D	1	
013	911003-8	*PAN HD SCREW M3X6 10PK W. CAPTIVE WASHERS	2	
014	819001-5	MAKITA LABEL	1	
015	183823-2	HOUSING SET 6270D INC. 2	1	
A01	414938-7	BATTERY COVER UC120DW/VR250DW 5093DW/LS800DWB	2	
A03	784636-0	+BIT 2-65 8270D/8280D	1	
A04	824581-8	PLASTIC CASE 6270DWPLE	1	
A05	193981-6	BATTERY PA12 SET	2	
A06	345261-8	HOOK BUTTON ML702/902/903/180	2	
A07	417926-3	STRAP ML702/902/903/180	1	
A08	193981-6	BATTERY PA12 SET	2	

SERVICE DRAWING

MODEL NO. 6270D

