AX2200 Portable CD Player

Shockproof

• 25-second Electronic skip protection

Long battery playing time

• 14-hour playback (with 2 x AA Alkaline batteries)

Rich and clear sound experience

- Digital dynamic bass boost
- 1-Bit D/A converter

Playback all kinds of discs

Plays CD, CDR and CDRW discs

Amplifier/ system

- Output power (in-ear headphone)
- 2 x 4mW RMS
- 1-Bit D/A convertor for pure sound reproduction
- Digital dynamic bass boost
- Rotary volume control
- S/N ratio (A weighted) >82 dB
- Frequency response 20 Hz 20 kHz
- · Audible feedback

CD player

- 30-Track programmable, shuffle, repeat one/ all
- · Search forward/ backward with sound
- · Resume and hold

LCD display

· Indications for track, time, DBB and CD functions

Connections

- · Headphone/ line out stereo, 3.5 mm
- DC in 4.0 mm, 4.5V, centre '+'

Power supply

- Batteries 2 x 1.5V, type
- AA/LR6/UM3 cell
- Battery playing time 14 hours (regular AA size, alkaline batteries)
- · Automatic power switch-off

General

- · Weight 240g (excluding
- batteries)
- Product dimensions (mm) 135 D x 125 W x 30 H
- D-box dimensions 164 D x 140 W x 49 H /00 (mm)
- Master carton 304 D x 172 W x 156 H dimensions /00 (mm)
- · Master carton quantity 6

Accessories

· Stereo in-ear headphone

25-second Electronic skip protection


Electronic skip protection detects shocks automatically and allows music play continuously with 25-second music buffer.

14-hour playback (with 2 x AA Alkaline batteries)

Powersaving technology extends battery playing time to 14 hours with two regular LR6-size (AA) alkaline

Digital dynamic bass boost

Enhances bass at low, mid and high volume, to give



deep, rich sounds.

Plays CD, CDR and CDRW discs

Ensures that both CD-Recordable and CD-Rewritable discs, made by any CD-Recorder, can be played.

All CD program modes

Let you enjoy various CD program modes (repeat one/ repeat all/ shuffle/ repeat shuffle).

1-Bit D/A converter

Advanced digital conversion technology ensures crystal-clear sound.

Hold

Locks all buttons to prevent interruption of play or change of program settings.

Resume

Bookmark function that ensures the CD starts precisely from the point it was stopped

Automatically switches off the CD player at the end of a compact disc.

CD next/ previous

Plays the next or previous track at the touch of a button.

CD music search

Searches the CD at high speed while still producing low-volume sound so you know exactly when to stop.

Repeat one/ all

Repeat the current track or the total CD.

Shuffle

Plays disc selection randomly, giving you each time a new sequence of tracks.

30-track programmable

Stores up to 30 of your favourite tracks for playing back in your order of preference.

Audible feedback

Confirms any key-push with friendly beep to acknowledges that a command has been given. Printed in Hong Kong 2002-09-18 Specifications subject to modification without notice 2002 © Koninklijke Philips Electronics N.V. All rights reserved

www.philips.com

www.audio.philips.com

A