Expanders



This series offers a standard steel expander which is natural colour nylon 6 and is

fitted to an M10 hexagonal headed set screw.

EXP 21/23R:



EXP 24/27R:



EXP 18/20S:



EXP 21/23S and EXP 24/27S:



Recommended Uses:

For attaching a bolt hole type castor to a tube or square hollow section. It is important not to overtighten as this can damage the expander causing the castor to become loose.

We advise an expander should not to be used where there are large temperature variations.

Feature:

The maximum recommended load for these expander fittings is 100kg.

Specifications

Material	Internal Tube Size	Part Number
Nylon	21 to 23*	EXP 21/23R
	24 to 27*	EXP 24/27R
	18 to 20**	EXP 18/20S
	21 to 23**	EXP 21/23S
	24 to 27**	EXP 24/27S

Dimensions : Millimetres

Disclaimer This data sheet and its contents (the "Information") belong to the Premier Farnell Group (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. DURATOOL is the registered trademark of the Group. © Premier Farnell plc 2009.



Page 1 05/05/09 V1.0

^{*}Round expander for tube.

^{**} Square expander for square hallow section.