

PRO-CRIMPER*II Hand Tool Assembly 1285002-1 With Die Assembly 1285002-2

INSTRUCTION SHEET

411-3239

O


RELEASED: 09/02/1999

REVISED:

REVISED: REVISION:

PROPER USE GUIDELINES

Cumulative Trauma Disorders can result from the prolonged use of manually powered hand tools. AMP hand tools are intended for occasional use and low volume applications. AMP offers a wide selection of powered application equipment for extended-use, production operations.



		_	WIRE			_
DIE ASSEMBLY PART NUMBER	LOCATOR ASSEMBLY PART NUMBER†	CONTACT FAMILY‡	SIZE (AWG)	INSUL. DIA (mm [in.])	STRIP LENGTH mm [in.])	
1285002-2	58516-1	AMP MODU I CONTACT 181299-1 182198-1	22 - 18	2.29 (0.090") MAX	3.35 - 4.16 (0.132") - (0.164")	

[†] Supplied with die assembly, also available separately.

Figure 1

1. INTRODUCTION

AMP* PRO-CRIMPER II Hand Tool Assembly 1285002-1 consists of Die Assembly 1285002-2 and AMP PRO-CRIMPER II Hand Tool Frame 354940-2. The die assembly consists of crimping dies and a locator assembly. Read these instructions thoroughly before crimping any contacts.

Dimensions on this sheet are in millimeters (with inch equivalents provided in brackets). Figures and illustrations are for identification only and are not drawn to scale.

This AMP controlled document is subject to change.

©Copyright 1998 by AMP Incorporated. All Rights Reserved.

*Trademark

‡ Product Information Centre + 44 0800 267666

Contact the AMP Product Information Centre (see above) for specific contact part numbers.