### Timers - ENYA series

- Timers multifunctional
- Up to 7 functions
- 7 time ranges
- Wide input voltage range
- 2 change-over contacts
- Width 35 mm
- Installation design

### Technical data

#### 1. Functions

The function has to be set before connecting the relay to the supply voltage. 

E	ON delay
R	OFF delay
Ws	Single shot leading edge with control input
Wa	Single shot trailing edge with control input
Es	ON delay with control input
Wu	Single shot leading edge voltage controlled
Вр	Flasher pause first

### 2. Time ranges

Time range	Adjustment range		
1s	50ms	1s	
10s	500ms	10s	
1min	3s	1min	
10min	30s	10min	
1h	3min	1h	
10h 100h	30min 5h	10h 100h	

#### 3. Indicators

Subject to alterations and errors

Green LED U/t ON: indication of supply voltage Green LED U/t flashes: indication of time period Yellow LED R ON/OFF: indication of relay output

#### 4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN-rail TS 35 according to EN 50022

Mounting position: any

Shockproof terminal connection according to VBG 4 (PZ1 required), IP rating IP20 max. 1Nm

Tightening torque:

- Terminal capacity:
  - 1 x 0.5 to 2.5mm<sup>2</sup> with/without multicore cable end
  - 1 x 4mm<sup>2</sup> without multicore cable end
  - 2 x 0.5 to 1.5mm<sup>2</sup> with/without multicore cable end 2 x 2.5mm<sup>2</sup> flexible without multicore cable end
- 5. Input circuit

S

Supply voltage:	terminals A1(+)-A2
Type E3Z12-240VAC/DC:	12 to 240V AC/DC
Tolerance:	12V-10% to 240V+10%
Rated consumption:	6VA (2W)
Rated frequency:	AC 48 to 63Hz
Duty cycle:	100%
Reset time:	100ms
Residual ripple for DC:	10%
Drop-out voltage:	>30% of minimum rated supply voltage
Overvoltage category:	III (according to IEC 60664-1)
Rated surge voltage:	4kV

### 6. Output circuit

2 potential free change-over contacts Rated voltage: Switching capacity: Fusing Mechanical life:

250V AC 2000VA (8A / 250V) 8A fast acting 20 x 10<sup>6</sup> operations

### Electrical life:

Switching frequency:

Overvoltage category: Rated surge voltage:

#### 7. Control input

Input not potential free: Loadable: Max. line length: Trigger level (sensitivity): Min. control pulse length:

### 8. Accuracy

Base accuracy: Adjusting accuracy: Repetition accuracy: Voltage influence: Temperature influence:

#### 9. Ambient conditions


Ambient temperature: Storage temperature: Transport temperature: Relative humidity:

Pollution degree:

Vibrations resistance:

Shock resistance:

### 10. Dimensions



11. Weight Single packing:

106g

2 x 10<sup>5</sup> operations at 1000VA resistive load max. 60/min at 100VA resistive load max. 6/min at 1000VA resistive load (according to IEC 947-5-1) III. (according to IEC 60664-1)

terminals A1-B1 ves 10m automatic adaption to supply voltage DC 50ms / AC 100ms

±1% of maximum scale value <5% of maximum scale value <0.5% or ±5ms

≤0.01% / °C

-25 to +70°C -25 to +70°C 15% to 85% (according to IEC 721-3-3 Klasse 3K3) 2, if built-in 3 (according to IEC 664-1) 10 bis 55 Hz 0.35mm (according to IEC 68-2-6) 15g 11ms

4kV

-25 to +55°C (according to IEC 68-1) (according to IEC 68-2-27)



### E3ZM20

## Functions


### ON delay (E)

When the supply voltage U is applied, the set interval t begins (green LED U/t flashes). After the interval t has expired (green LED U/t illuminated) the output relay R switches into on-position (yellow LED illuminated). This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the expiry of the interval t, the interval already expired is erased and is restarted when the supply voltage is next applied.



### OFF delay (R)

The supply voltage U must be constantly applied to the device (green LED U/t illuminated). When the control contact S is closed, the output relay R switches into on-position (yellow LED illuminated). If the control contact is opened, the set interval t begins (green LED U/t flashes). After the interval t has expired (green LED U/t illuminated) the output relay switches into off-position (yellow LED not illuminated). If the control contact is closed again before the interval t has expired, the interval already expired is erased and is restarted.




### Single shot leading edge with control input (Ws)

The supply voltage U must be constantly applied to the device (green LED U/t illuminated). When the control contact S is closed, the output relay R switches into on-position (green LED U/t illuminated) and the set interval t begins (green LED U/t flashes). After the interval t has expired (green LED U/t illuminated) the output relay switches into off-position (yellow LED not illuminated). During the interval, the control contact can be operated any number of times. A further cycle can only be started when the cycle run has been completed.



### **Connections**




### Ordering information

Types	Functions	Supply voltage	Part Nr. (PQ 1)
E3ZM20 12-240V AC/DC	E, R, Ws, Wa, Es, Wu, Bp	12-240V AC/DC	111100

### The supply voltage U must be constantly applied to the device (green LED U/t illuminated).

Single shot trailling edge with control input (Wa)

Closing the control contact S has no influence on the condition of the output R. When the control contact is opened, the output relay switches into on-position (yellow LED illuminated) and the set interval t begins (green LED U/t flashes). After the interval t has expired (green LED U/t illuminated), the output relay switches into off-position (yellow LED not illuminated). During the interval, the control contact can be operated any number of times. A further cycle can only be started when the cycle run has been completed.



### ON delay with control input (Es)

The supply voltage U must be constantly applied to the device (green LED U/t illuminated).

When teh control contact S is closed, the set interval t begins (green LED U/t flashes). After the interval t has expired (green LED U/t illuminated) the output relay R switches into on-position (yellow LED illuminated). This status remains until the control contact is opened again.

If the control contact is opened before the interval t has expired , the interval already expired is erased and is restarted with the next cycle.



### Single shot leading edge voltage controlled (Wu)


When the supply voltage U is applied, the output relay R switches into on-position (yellow LED illuminated) and the set interval t begins (green LED U/t flashes). After the interval t has expired (green LED U/t illuminated) the output relay switches into off-position (yellow LED not illuminated). This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the interval t has expired, the output relay switches into off-position. The interval a lready is erased and is restarted when the supply voltage is next applied.



### Flasher pause first (Bp)

When the supply voltage U is applied, the set interval t begins (green LED U/t flashes). After the interval t has expired, the output relay R switches into on-position (yellow LED illuminated) and the set interval t begins again. After the interval t has expired, the output relay switches into off-position (yellow LED not illuminated).

The output relay is triggered at a ratio of 1:1 until the supply voltage is interrupted.





# www.tele-power-net.com