
# **Miniature Waterproof Plastic Connectors**

#### HR30 Series





#### **■**Features

#### 1. Small size

Short in length when fully terminated and mated.

#### 2. Water and dust protected

IP67 protection rating: Complete protection against dust penetration and against water penetration when submerged 1 meter deep for half hour. Mated with corresponding connector or protective cap.

#### 3. Simple pull lock release

Built-in lock/release mechanism securely locks mated connectors while allowing quick disconnection by simply pulling on the plug's release collar. Molded-in grooves prevent hand slippage when pulled.

The round configuration of the collar allows easy side-byside panel mounting and will not snag on objects when the cable is pulled-out.

#### 4. Light weight, corrosion resistant

Glass reinforced thermoplastic compounds and noncorrosive components are used in all assemblies.

#### 5. Contact protection and self- alignment

Multiple polarizing keys protect the contacts from missalignment or attempted insertion of the wrong connector, while assuring correct mating between the corresponding connectors.

#### 6. Visual alignment indicators

Permanent alignment indicators in a contrasting color on all connectors aid in correct alignment and engagement.

#### 7. Built-in cable strain relief

#### Applications

Test and measuring equipment, portable devices, instrumentation, industrial devices, recreational equipment, I/O applications and other applications requiring use of lightweight, corrosion resistant quick mate/ release cable connections.


# Lock/release operation Push-pull- single action lock



# **■Plugs**

#### Solder Type






Part Number	CL No.	Α	В	Solder pot inner diameter	Applicable cable diameter range	Weight	RoHS
HR30-6P-3S(71)	130-0004-1-71	00.0		1.1 mm			
HR30-6P-6S(71)	130-0010-4-71	29.8		0.0	4.2 to 5		
HR30-6P-6P(71)	130-0009-5-71	30.3	12.6	0.8 mm		- 4g	YES
HR30-6PA-3S(71)	130-0021-0-71	20.0	12.0	1.1 mm			
HR30-6PA-6S(71)	130-0019-9-71	29.8		0.0	3.5 to 4.3		
HR30-6PA-6P(71)	130-0020-8-71	30.3		0.8 mm			
HR30-7P-12S(71)	130-0027-7-71	20.0	15.5	0.6 mm	6.2 to 7	6.7g	
HR30-8P-12P(71)	130-0026-4-71	39.8	15.5	0.6 mm	0.2 10 7	0.79	

# Crimp Type






Part Number	CL No.	Α	Crimp contact	Applicable cable diameter range	Weight	RoHS
HR30-7P-10SC(71)	130-0013-2-71		HR30-SC-211			YES
HR30-7P-12SC(71)	130-0014-5-71	39.8	11130-30-211	6.2 to 7	6g	
HR30-8P-12PC(71)	130-0015-8-71		HR30-PC-211			

Note: Crimp contacts are not included. Please order applicable contacts separately.


# **■**Receptacles

# Solder Type





Part Number	CL No.	Α	В	С	D	Е	F	Solder pot inner diameter Weight	RoHS
HR30-6R-3P(71)	130-1003-4-71	16		3 12	8.9 N		×0.75 10	1.1mm	
HR30-6R-6P(71)	130-1009-0-71	10	8.3			M8×0.75		0.0000	
HR30-6R-6S(71)	130-1008-8-71	18.4						0.8mm ——	
HR30-7R-12P(71)	130-1016-6-71	18.6	9.3	15	11.5	M11×1	13	0.6mm 3.4g	
HR30-8R-12S(71)	130-1018-1-71	10.0	9.3   15   11.5   W11 \ 1		13	0.6mm 3.4g			



# Through hole Type




Part Number	CL No.	Α	В	С	D	E	F	Weight	RoHS
HR30-6R-6PD(71)	130-1020-3-71	14.9	8.3	12	8.9	M8×0.75	10	2g	
HR30-6R-6SD(71)	130-1021-6-71	15.2	0.5	12	0.9	1010/10.75	10	_ 2g	YES
HR30-7R-12PD(71)	130-1017-9-71	16	9.3	15	11.5	M11×1	13	3.4g	ILO
HR30-8R-12SD(71)	130-1019-4-71	10	9.5	15	11.5	IVITIAT	13	3.4g	

#### **■**Jacks

## Solder Type






Part Number	CL No.	Α	В	Applicable cable diameter range	Solder pot inner diameter	Weight	RoHS
HR30-6J-6P(71)	130-2009-6-71	12	28.9	4.2 to 5	0.8 mm	3g	- YES
HR30-6JA-6P(71)	130-2018-7-71	12	20.9	3.5 to 4.3	0.0 111111		
HR30-7J-12P(71)	130-2020-9-71	15	37.3	6.2 to 7	0.6 mm	5.7g	
HR30-8J-12S(71)	130-2019-0-71	13	37.3			5.9g	

## Crimp Type






Part Number	CL No.	Crimp contact	Applicable cable diameter range	Weight	RoHS
HR30-7J-10PC(71)	130-2015-9-71	HR30-PC-211		5g	YES
HR30-7J-12PC(71)	130-2017-4-71	11K30-FG-211	6.2 to 7		
HR30-8J-12SC(71)	130-2016-1-71	HR30-SC-211			

Note: Crimp contacts are not included. Please order applicable contacts separately.

## **■**Caps

#### For Plugs






Part Number	CL No.	Applicable connector	Α	В	С	D	Е	Weight	RoHS
		HR30-6P-3S(71)							
LID20 CD C(74)		HR30-6P-6S(71)	13		8.9	4		1g	YES
	120 2000 7 71	HR30-6P-6P(71)		8.4			8.8		
HR30-6P-C(71)	130-3000-7-71	HR30-6PA-3S(71)		0.4	0.9				
		HR30-6PA-6S(71)							
		HR30-6PA-6P(71)							
		HR30-7P-10SC(71)							
HR30-7P-C(71)	130-3004-8-71	HR30-7P-12S(71)							
		HR30-7P-12SC(71)	16	10.4	10.5	6	11.4	2g	
LID20 0D C(74)	130-3003-5-71	HR30-8P-12P(71)							
HR30-8P-C(71)		HR30-8P-12PC(71)							

### For Receptacle






Part Number	CL No.	Applicable connector	Α	В	С	D	Е	Weight	RoHS
		HR30-6R-3P(71)							
HR30-6R-C(71)		HR30-6R-6P(71)				12.1	9.1	1g	YES
	130-3001-0-71	HR30-6R-6PD(71)	12.6	11.8	7.5				
		HR30-6R-6S(71)							
		HR30-6R-6SD(71)							
		HR30-7R-10PC(71)							
		HR30-7R-12P(71)							
		HR30-7R-12PC(71)							
HR30-7R-C(71)	130-3002-2-71	HR30-7R-12PD(71)	15.5	14.8	8.5	15	12.1		
		HR30-8R-12S(71)							
		HR30-8R-12SC(71)							
		HR30-8R-12SD(71)							


Note: When using these caps, do not use the gasket that is normally supplied with the receptacle. The "B" diameter end of the receptacle cap will serve as the gasket.

## **■Crimp Contacts**

#### **Male contact**

#### **Female contact**








Part Number	CL No.	Packaging type	Weight	RoHS
HR30-PC-111	130-0022-3	100pcs/bag	0.03g/1per pin	YES
HR30-PC-211	130-0016-0	10,000pcs/reel	0.03g/1per pin	

Part Number	CL No.	Packaging type	Weight	RoHS
HR30-SC-111	130-0023-6	100pcs/bag	0.03g/1 pin	YES
HR30-SC-211	130-0017-3	10,000pcs/reel	0.03g/1 pin	153

Note: Use wire size AWG 26 to 30 with a jacket diameter of 1 mm max.

# **●**Connecting Combinations



Note 1: When selecting connectors, take into account the shell size, contact count and gender of the contacts.

Note 2: When using the protective caps for the receptacles, do not use the gaskets normally supplied with the receptacle. Protective caps must be fully inserted to assure specified IP67 water and dust protection.

# **♠** Applicable Fixtures

#### Solder termination fixture

Part Number	CL No.	Applicable Connectors
HR30-6P-3S-T01	150-0220-1	HR30-6P-3S(71)
HK30-0P-35-101	150-0220-1	HR30-6PA-3S(71)
HR30-6P-6S-T01	150-0214-9	HR30-6P-6S(71)
HK30-0F-03-101	150-0214-9	HR30-6PA-6S(71)
HR30-6P-6P-T01	150-0221-4	HR30-6P-6P(71)
HK30-0P-0P-101	150-0221-4	HR30-6PA-6P(71)
HR30-7P-10SC-T01	150-0228-3	HR30-7P-10SC(71)
HR30-7P-12SC-T01	150-0223-0	HR30-7P-12S(71)
	150-0223-0	HR30-7P-12SC(71)
HR30-8P-12PC-T01	150-0227-0	HR30-8P-12P(71)
HK30-0P-12PC-101	150-0227-0	HR30-8P-12PC(71)
HR30-6R-3P-T01	150-0225-5	HR30-6R-3P(71)
		HR30-6R-6P(71)
HR30-6R-6P-T01	150-0218-0	HR30-6J-6P(71)
		HR30-6JA-6P(71)
HR30-6R-6S-T01	150-0222-7	HR30-6R-6S(71)
HR30-7J-10PC-T01	150-0231-8	HR30-7J-10PC(71)
HR30-7J-12PC-T01	150-0230-5	HR30-7J-12PC(71)
HR30-8J-12SC-T01	150-0226-8	HR30-8J-12SC(71)

Note: The back shell tightening collar is used to tighten the back shell to the specified torque. Refer to assembly procedures.

#### Tightening collar for back shell

Part Number	CL No.	Applicable Connectors
HR30-6P-T02	150-0216-4	3 and 6 pos.
HR30-8P-T02	150-0224-2	10 and 12 pos.

Note: The back shell tightening collar is used to tighten the back shell to specified torque. Refer to assembly procedures.




#### **■**Applicable Tools


Туре	Description	Part Number	CL No.	Applicable contact	Applicable wire
Manual	Manual crimping tool	HT-102/HR30-1	150-0229-6	HR30-SC-111	- AWG#26~#30
				HR30-PC-111	
Automatic	Automatic crimping machine	CM-105	901-0005-4		
	Applicator	AP105-HR30-1	901-2015-9	HR30-SC-211	AWG#26~#30
				HR30-PC-211	
Extraction tool		HR30-TP	150-0219-2	HR30-SC-111	
				HR30-SC-211	<del></del>
				HR30-PC-111	
				HR30-PC-211	







# ♠ Receptacle, Board Mounting Through Hole Pattern




- Notes 1.The receptacle through hole configuration depicts a view from the mating side of the connector.
  - 2. The recommended board maximum thickness: 1.2 mm.
  - 3. Tolerance of +0.03 mm is recommended for the plated through hole location.
    - Tolerance of +0.02 mm is recommended for the plated through hole diameter.

# **●** Contact Position Arrangement

#### Alignment mark 1 3 4 3 HR30-6P-3S(71) HR30-6P-6S(71) HR30-6P-6P(71) 321 (n) (a) (a) 321 7654 4567 7654 (10) (9) (8) (8)(9)(0)10 9 8 12 (1) 11 12 HR30-7P-10SC(71) HR30-7P-12SC(71) HR30-8P-12PC(71)

# **●**Panel Cutout



	Α	В	С	D	Panel Thishness
3,6 pos	1.25	6.45	8.05	3.95	0.7~2
10,12 pos	1.35	9.25	11.05	5.45	0.7~3

Notes 1. The contact configuration depicts a view from the wiring side.


2. Mounting to the panel is accomplished by tightening the hexagonal nut from the rear side of the panel.

# Assembly Procedures

#### Plug Assembly Sequence

1


Thread the back shell, strain relief, seal bushing, spring and push/pull locking collar over the cable as shown above.



2 Solder type

- 1. Pre-solder the exposed cable conductors (dia. A). The diameter of the pre-soldered conductors should not exceed 0.7 mm for 6 contact plug and 1.0 mm for 3 contact plug.
- 2. Insert the insulator body over the applicable solder termination fixture.
- 3. Insert the pre-soldered conductors in the contact soldering pot and solder them in place. Soldering iron temperature should be  $280 \pm 10^{\circ}$ C applied for 3-4 second.


Crimp type



- 1. To prevent accidental loosening of the back shell it is recommended that a small amount of primer (Loctite® 7649) and adhesive (Loctite® 271) be applied to the threads of the insulator body before proceeding.
- 2. Keeping the terminated insulator body on the fixture, re-assembly the plug in order shown.
- 4. Using the correct back-tightening collar tighten the back shell to the specified torque. When tightening the collar make sure that the cable will NOT turn.
- 5. Remove the assembly from the fixture.


Note: Loctite is a registered trademark of the Henkel Loctite Corporation.

# **●**General usage notes



#### Precautions

1. Do NOT apply force in excess of 30N in the directions shown below.



- 2. To maintain the water/dust protection performance and the cable clamp force, use a cable that is within the range of applicable cable diameter.
- 3. Consult HRS representative when using different cables.



# HIROSE ELECTRIC CO.,LTD.

5-23,OSAKI 5-CHOME,SHINAGAWA-KU,TOKYO 141-8587,JAPAN PHONE: 81-3-3491-9741, FAX: 81-3-3493-2933

http://www.hirose.com

http://www.hirose-connectors.com