# **FX Accessories**

## **FX Programming Tools**

Specifications	FX-10P-E	FX-20P-E-SET-0	FX0-10LDR
Stocked Item	S	S	S
Rating	-	CE (EMC only)	_
Purpose	For online PLC programming	For online or offline PLC programming	For program up/download
Display	2x16 LCD	4x16 backlit LCD	N/A
Off Line Programming	No	Yes	N/A
Compatible PLCs	All FX	All FX (*1)	All FX (*2)
Cable Required	FX-20P-CAB + FX-20P-CADP	Supplied (FX-20P-CAB0)	Supplied

Note: This table excludes programming software. Please refer to the Software Selection Guide for these products.

1. For connection to F / F1 / F2 / FX, the FX-20P-ADP-KIT is also required.

<sup>2.</sup> Program download size for FXTN/2N is 8k step unless otherwise specified; an FX-EEPROM-4 cannot be used with these PLCs unless the programming area is reduced (GX-Developer/View/Project/Data List/Parameter/Memory Capacity)

Specifications	FX-20P-RWM	FX-ROM-SOC-1	SC09
Stocked Item	_	-	S
Rating	_	_	_
Purpose	Writing to EPROM memory cassette from FX-20P-E	EPROM to FX-20P-RWM adapter	For program up/download from PC
Display	N/A	N/A	N/A
Off Line Programming	N/A	N/A	N/A
Compatible PLCs	FX0N, FX2N	FX0N, FX2N	All FX
Cable Required	N/A	N/A	N/A

Note: This table excludes programming software. Please refer to the Software Selection Guide for these products.

#### **FX Network Accessories**

Specifications	FX-485PC-IF-KIT	
Stocked Item	-	
Rating	CE (EMC only)	
Applicable PLCs	FX / FX0N / FX2N / FX2NC	
Purpose	RS-232-422/485 converter for multi-drop network connection to PC	
Power Supply	Supplied	

### **FX Battery Back-Up**

Specifications	F2-40BL	FX2NC-32BL	FX0N-40B
Stocked Item	S	S	S
Rating	_	_	_
Purpose	Maintains base unit memory during power down	Maintains base unit memory during power down	Maintains RTC data during power down (if RTC option installed)
Compatible PLCs	FX2N	FX2NC	FX0N

#### **FX Accessory Cables**

Specifications	FX0N-30EC	FX0N-65EC	FX2N-CNV-BC
Stocked Item	S	S	S
Rating	_		_
Purpose	For extending distance between base unit and powered extension units.		
Length (mm)	300	650	
Compatible PLCs	FX0N, FX1N, FX2N; FX2NC (when used with FX2NC-CNV-IF)		Use with FX0N-30EC and FX-0N-65EC